









Ribbon cartridge

Printer Specifications

Printing

Print method:

9-pin impact dot matrix

R,int speed:

Quality	Character per inch	Character/second/line	Ī
High-speed draft	10	200	Ī
	10	150]
Normal draft	12	160	
NLO	10	25]
NEC	12	30	Ī

Printing direction:

Bidirectional logic-recking for text printing. Unidirectional for graphics (can **also** be switched to bidirectional by using the **proper** software command).

Line spacing:

1/6 or 1/8 inch, or programmable in increments of 1/216th of an inch.

Paper feed speed:

Approx. 75 ms/line at 1/6-inch line spacing during continuous feeding. Appmx. 95 ms/line at 1/6-inch line spacing during intermittent feeding.

Printable columns:

Character sizes	Maximum printed characters
10 cpi	80
10 cp: condensed	137
12 cpi	96
12 cpi condensed	160

Input buffer:

4K byte

Character fonts:

Font	Available sizes (Character per inch)
Epson High-speed draft	1 0
Epson Draft	10. 12
Epson NLQ Roman	10. 12
Epson NLQ Sans Serif	10, 12

Characters:

96 standard ASCII character set (including italic characters)

13 international character sets (including

italic characters)

Epson Extended Graphics character set

Paper


Paper width and length:


Paper		Width and length
Single sheet	Width: Length:	162 to 257 mm (7.2 to 10.1") 162 to 364 mm (7.2 to 14.3")
Continuous paper	width:	101 to 254 mm (4.0 to 10.0")
Roll paper	Width: Diameter:	216 ± 3 mm (6.5 ± 0 12") 127 mm (5.0") maximum
Envelope	No.6 MO.10	166 × 92 mm (6.5 × 3.6") 240 × 104 mm (9.4 × 4.1")
Labels		63.5 X 23.6 mm (2.5 X 0.94'') minimum

Printable area:


Single sheet


8.5 mm (0.33") or more





13 mm (0.15") or more (both sides) when the 101 mm to 242 mm (4 to 9.5") width paper is used. 26 mm (1.02") or more (left side) and 24 mm (0.94") or more fright side) when the 254 mm (10") width paper is used.





- Envelope printing is only available at normal temperature.
- Keep the longer side of the envelope horizontally at setting Align the left edge of the envelope to the guide mark of the

paper guide L X - 8 1 0 - 1

LX - 810 DOT - MATRIX PRINTER

Single sheet: 14 lb to 24 lb Paper weight:

(52 g/m² to 9-J g/m*)

14 lb to 22 lb Continuous paper: (52 g/m² to 62 g/m²)

[12 lb to 15 lb] X N Multi-part forms:

([45 g/m² to 56 g/m²]

× N)

N <u>≤</u> 3

14 lb to 17 lb Roll paper: $(52 \text{ g/m}^2 \text{ to } 64 \text{ g/m}^2)$

Envelope: 12 lb to 24 lb

(45 g/m² to 90 g/m*)

0.065 to 0.140 mm Paper thickness: Single sheet:

(0.0025 to 0.0055")

0.065 to 0.250 mm Continuous paper: (0.0025 to 0.0098")

Roll paper: 0.070 to 0.090 mm

(0.0028 to 0.0035") 0.160 to 0.520 mm

Envelope: (0.0063 to 0.0197")

0.160 to 0.190 mm (0.0063 to 0.0075") including the base

sheet

Copy capacity: Up to 3 sheets including the original. Total

thickness must not exceed 0.25 mm

(0.0098")

Label:

24 lb paper printing is only available at normal temperature.

Label with a Pressure sensitive paper jointed by dotted or pasting and its total thickness is less than or equal to 0.3 mm (0.0118") can be printed out under the condition of 5°C to 35°C and 10% to 80% RH.

Mechanical

Paper feeding

methods: Friction

Push tractor

Cut sheet feeder (optional) Pull tractor (optional) Roll paper holder (optional)

Ribbon: Cartridge ribbon, available in black:

#8750

Life expectancy at 14 dots/character:

3 million characters

MCBF: For all components excluding print head:

3 million lines

MTBF: 4000 power-on hours (duty 25%)

Print head life: 200 million strokes/wire

Dimensions

and wright: Height: 141 mm

> Width: 416 mm (excluding platen knob)

Depth: 339 mm

Weight: approx. 5.8 kg

Electrical

Voltage: 120 VAC ± 10% (120 V model)

220 VAC ± 10% (220 V model) **240** VAC ± 10% (240 V model)

Power consumption: 28 W (self test printing: draft mode)

Frequency: $50.0 \pm 0.5 \text{ Hz}, 60.0 \pm 0.5 \text{ Hz}$

Insulation resistance: 10M ohms between AC power line and

chassis

Dielectric strength (between AC line and

chassis): 120 V model can withstand I 00 kV rms

applied for one minute.

220/240 V model can withstand 1.25 kV

rms applied for one minute.

Environment

+5°C to +35°C Tempera ture: Operation: -30°C to +60°C Storage:

Operation: 10% to 80%

Humidity: (without condensation)

> Storage: 5% to 65% (without condensation)

Up to 1 G within lms

Shock: Operation: Up to 2 G within 1ms Storage:

Up to 0.25 **G** at **up** to Vibration: Operation:

55Hz

up to 0.50 G at up to Storage: 55Hz

Less than 15' (without cut sheet feeder) Operation angle:

0' (with cut sheet feeder)

Menu Selections

Because the family of Epson printers shares a great many commands. you can "se an application program even if it does not list the LX-810 on its printer selection men". If the LX-810 is not listed, choose one of the following printers. They are listed in order of preference.

LX-600

Lx-66 LX-80

FX-850

FX-86e

EX-800

FX-85

FX-80+

FX-80

If none of these printers is listed, select the first one available on the following list:

Lx

FX EX

RX

ΜX


Epson printer Standard printer

Draft printer

To "se all of the features of the LX-810, however, it is best to "se a program with the LX-810 on its men". If your program does not list any LX printers, contact the software manufacturer to see if an update is available.

The Control Panel

Lights



POWER (green)

On when the power switch is on and power is supplied.

READY (green)

On when the printer is ready to accept input data Flickers while data is printed.


PAPER OUT (red)

On when the printer is out of paper or when continuous paper is in a standby position. The printer also beeps when it is out of paper.

ON LINE (green)

On when the printer is on line and ready to accept data from the computer When this light is flickering, the micro-adjustment feature can be used.

Buttons



ON LINE

This button controls the printer's on line and off line status. Press this button to put the printer on line or take it off line.

FORM FEED

When the printer is off line. press this button to eject a single sheet of paper or to advance continuous paper to the top of the next page.


LINE FEED

When the printer is off line, press this button to advance the paper one line, or hold it down to advance the paper continuously.

LOAD/EJECT

This button is used to feed the paper to the loading position, or to eject paper that is already loaded. Paper is ejected forward if the paper release lever is set to the single sheet position and is ejected backward (removed from the paper path) if the release lever is set to the continuous paper position.

SelecType



NLQ

This button is used to select NLQ Roman and NLQ Sans Serif fonts. When you select Roman, the beeper sounds two times. When you select Sans Serif, the beeper sounds three times.

DRAFT

This button is used to select draft printing. When you select draft, the beeper sounds once.

CONDENSED

This button is used to select or deselect the condensed mode.

When you select the condensed mode, the beeper sounds once. In this mode all characters are printed at approximately 60% of their normal width. When you return to the normal mode, the beeper sounds twice.

Note: Condensed mode cannot be selected when either of the NLQ fonts have been selected.

Buttons	Number of b	eeps i	Typestyles		
 DRAFT J	Select	draft	font		
 NLO were dead		Selec	t NLQ Romanifont		
		Seiec	t NLQ Sans Serif fon	1	
CON- DENSED		Selec	! Condensed mode		
	3	Cancel	Condensed mode		

Other control panel features

Self test:

Both a draft and NLQ self test function are built into the printer. The self test printout lets you check the current DIP switch settings and operating status of the printer You can start the printer's self test by holding down the LINE FEED button or the FORM FEED button while switching the printer on See the section on running the self test in Chapter 1 for more information


Micro-adjustment:

By pressing the FORM FEED and LINE FEED buttons immediately after loading paper or when using short tear-off, you can make fine adjustments to the loading and short tear-off positions. See the sections on adjusting the loading position and using short tear-off later in this chapter.

Data dump:

By holding down both the LINE FEED and FORM FEED buttons while turning on the printer, you turn on the data dump mode. This feature allows advanced users to locate the source of communications problems between the computer and printer. See the section on using the data dump mode later in this chapter for more information.

Setting the DIP Switches



The DIP switch tables

DIP Switch 1

SW	Description	ON	OFF	Page
1-1	Character spacing	12 cpi	10 cpi	4-3
1.2	Shape of zero	Slashed	Not slashed	3-8
1-3	Character table	Graphics	Italics	3-25
1-4	Short tear-off	Invalid	Valid	3-15
1-5	Draft printing speed	Normal	High	3-8
1-6				
1-7	international character set	See table on	the next page	3-23
1-8				

DIP Switch 2

SW	Description	ON	OFF	Page
2-1	Page length	12 inches	11 inches	3-9
2-2	Cut sheet feeder mode on/off	ON	OFF	5-2
2-3	1-inch skip over perforation	ON	OFF	3-10
2-4	Auto line feed	ON	OFF	3-8

International character set

Country	SW 1-6	SW 1-7	SW 1-8
USA	ON	ON	ON
France	ON	ON	OFF
Germany	QN	OFF	ON
UK	ON	OFF	OFF
Denmark	OFF	ON	ON
Sweden	OFF	ON	OFF
Italy	OFF	OFF	ON
Spain	OFF	OFF	OFF

The DIP switch functions

Slashed zeros

When DIP switch 1-2 is ON, the printer prints slashed zeros(0); when OFF, the printer prints open zeros (0). This feature is useful for clearly distinguishing between uppercase 0 and zero when printing documents such as program lists.

LX-810 DOT- MATRIX PRINTER

Draft printing speed

When DIP switch 1-5 is OFF, the printer can print up to **200** draft characters per second: when ON, the printer can print up to 150 characters per second. The high speed **setting** is effective only when printing at **10** cpi (characters per inch). When printing at **a** different pitch, this switch is ignored and the printer prints up to 150 characters per second.

Auto line feed

When auto line feed is ON (DIP switch 2-4 ON), each carriage return code (CR) is automatically followed by a line feed code (LF)

Defaults

Item	Reset to:
Top of form position	Current paper position
Left and right margins	Cancelled
Line spacing	1/6-inch line spacing
Vertical tab position	Cleared
Horizontal tab positions	Every eight characters
VFU channel	Channel 0
Font selection	The current SelecType setting
Condensed mode	The current SelecType setting
Character spacing	The current DIP switch setting
Justification	Left justification
Special printing effects	Cancelled
Graphic mode assignment	ESC K = ESC = 0. ESC L = ESC = 1, ESC Y = ESC = 2. ESC Z = ESC = 3

Selecting Typestyles

HIGH-SPEED DRAFT

'"#\$%%'()*+,-./0123456789:;<=>?@ABCDEFGHIJK LMHOPORSTUVNXYZE\]^_'abcdefghijkimnopqrstuv wxyz{{}}^

We we just seen your excellent ad for miniature zebras in a recent back issue of trader's Times. What is the price schedule for quantities over one gross?

NORMAL DRAFT

!"#\$%&^()*+,~./0123456789:;(=:?@ABCDEFGHIJK LNHOFQRSTUVWXYZ[\] _ abcdetgh:jklmnapqrstuv wryz())*

We've just seen your excellent ad for miniature zebras in a recent back issue of https://doi.org/10.100/ens.what is the price schedule for grantities over one gross?

NLQ ROMAN

!"#\$%&^()*+,-./0123456789:;<=>?@ABCDEFGHIJK LMNOPQRSTUVWXYZ[\]^_ abcdefghijklmnopqrstuv wxyz{|}}~

We've just seen your excellent ad for miniature zebras in a recant back issue of Trader's Times. What is the price schedule for quantities over one. gross?

NLQ SANS SERIF

!"#\$%&`()#+,-./0123456789:;<=>?@ABCDEFGHIJK LMNOPORSTUVWXYZ[\]^_`abcdæfghijklmnopqrstuv wxyz(!)~

We've just seen your excellent ad for miniature zebras in a recent back issue of Trader's Times. What is the price schedule for quantities over one gross?

Selecting Character Sets

Italics

aeùòi*£;¿NfintAâçSpāmOg~ÄCUEÖüZé¥!"#\$%&`
()*+,-./0123456789:;<=>?!ABCDEFGHIJKLMNO
PQRSTUVWXYZ;N¿é_üabcdefghijklmnopqrstuvw
xyzifiìX0

Epson Extended Graphics

COGREGACES INARAGE COORDINATE CONTROL OF STREET CONTROL OF STREET

Country		ASCII code hex									I	DIP SW		
Country	23	24	40	58	5C	5D	5E	60	78	7c	70	7E	1-6	1.7 1-8
CUSA.	1	:	\$	•	<u>۲</u> ۱		•	,	{	;]	, ~	0	N O	N ON
1 France	*	:3	à	•	ັວ່	5	^	•	é	ù	è	**	ON	ON OFF
2 Germany	*	3	8	Ă	ŏ	U	-	•	Æ	8	ü	β	ΟN	OFF ON
3 U.K	£	1	, (• [. 1	^	٠	-{	:	}	~	ON	OFF OFF
, 4 Denmark	1	#	\$ (8 0	A	_	•	*	ø	ā	~	OFF	ON ; ON
! 5 Sweden	#	п	8	A	CI	Α	U	é	ä	ö	A	ű	OFF	ON OFF
6 taly	#	\$	•	•	\	é	^	ù	à	ò	à 1	0	FF C	FF ON
7 Spain 1	E	t	\$	•	i B	i ¿	•		••	ñ	}	~	OFF	OFF/OFF

0			_		AS	CII c	ode i	1 e x				
Country	23	24	40	5B	5C	5D	5E	60	78	7C	70	7E
8 Japan	#	3	•	τ	¥]	-	•	{	:	}	~
9 Norway	#		Ė	Æ	Ø	Ā	U	é	*	ø	ā	a
10 Denmark II	#	3	E	Æ	Ø	A	U	é	*	ø	ā	ū
11 Spain II	#	Š	á		R	Ł	é	•	1	ñ	Ó	ú
12 Latin America	#	3	á	i	R	ě	é	ũ	1	ñ	6	ű

Paper Handling

Using Short Tear-Off

When you are finished printing, the short tear-off feature automatically feeds the perforation of the continuous paper to the tear-off edge of the printer cover so that you can tear off the last sheet When you resume printing, the paper feeds backward to the loading position. This feature lets you save the paper normally lost between documents.

To use this feature, set DIP switch 1-4 to OFF and load continuous paper



WARNING: Never use the short tear-off feature with labels. Otherwise, labels may come off the backing and jam the printer.

Using micro-adjustment

- 1 Make sure that the printer is turned on and that either a single sheet or continuous paper is ready to be loaded.
- Press the LOAD/EJECT button to feed paper to the loading position. Then press the ON LINE button: the ON LINE light then begins to blink.




Note: You can use the FORM FEED and LINE FEED buttons for micro-adjustment only while the ON LINE light is blinking.

 Press the FORM FEED button to feed the paper forward or the LINE FEED button to feed the paper backward When you've set the desired loading position. you can begin printing; the ON LINE light stops blinking automatically

Paper Type	Lever Position
Paper (single sheets or continuous)	2
Thin paper	2
24 lb paper (single sheets)	3
Multi-part forms	
2-sheet	2
3-sheet	3
Labels	4
Envelopes	
Aı, mail	4 or 5
Plain	6
Bond (20 lb,	6
Bond 124 lb)	7

The Cut Sheet Feeder





Single-bin cut sheet feeder (optional)

Dimensions

and weight:

444 mm (W) x 434 mm (D) x 423 mm (H)

(mounted on the printer)

Approx. 1.1 kg

Bin capacity:

Single sheet:

Up to **100** sheets **of 90 g/m² (24** lb) paper up to **150 sheets** of **82 g/m² (22** lb) paper Up to **185** sheets of

 $\begin{tabular}{lll} \begin{tabular}{lll} \begin{$

Stacker capacity:

Single sheet:

Up to 55 sheets of 90 g/m² (24 lb) paper

Up to **80** sheets of **82 g/m²** (22 lb) paper Up to 100 sheets of **64 g/m²** (17 lb) paper

MCBF: 100,000 cycles

Environmental

condition:

Temperature

Operation: +5°C to +35°C storage: -30°C to +60°C

Humidity

Operation: 15% to 80%

(without condensation)
Storage: 5% to 85%

(without condensation)

Paper: Width.

idth. **182** to 216 mm (7.17 to 8.50")

Length: 257 to 364 mm (10.12 to 14.30")

Thickness: 0.07 to 0.14 mm (0.0028 to 0.0055")


Weight: 64 g/m² to 90 g/m² (17 lb to 24 lb)


Storage condition

of paper:

Temperature: + 18°C to +22°C Humidity. + 18°C to +22°C

Printable area:





Interface number	Name	
#8143	New Serial interface	
#8148	Intelligent serial interface	
#8165	Intelligent IEEE-488 interface	


Pin assignments for the parallel interface

Signal Pin	Return Pin	Signal	Direc- tion	Description
1	19	STROBE	IN	STROBE pulse to read data Pulse width must be more than 0.5 microseconds at the receiving terminal
2	20	DATA	'N	These signals represent informations of
3	21	DATA 2	IN	the 1st of 8 bits of parallel data.
A	22	DATA 3	iN	respectively
h	23	DATA 4	IN	Each signal is at HIGH level when data
6	24	DATA 5	١N	is logical 1 and LOW when it is logical
7	25	DATA 6	ίN	0
8	26	DATA 7	iN	!
9	27	DATA 8	OUT	I
10	28	ACRNEG	OUT	About a 12 microsecond pulse. LOW indicates that data has been received and that the printer is ready to accept more data.
1 1	29	BUSY	OUT	A HIGH signal indicates that the printer cannot receive data. The signal goes HIGH in the following cases: 1) During data entry real char time: 2) When off line: 3) During printer-error state
12	30	PE	OUT	A HIGH signal indicates that the printer is out of paper
13		-	- '	Pulled up to + 5 volts through 3 3K ohm resistance.
14	_	AUTO FEED XT	IN.	When this signal is LOW the paper is automatically fed 1 line after printing. (The signal level can be fixed to this by setting DIP switch 2-4 to ON.)
15	-	NC	_	Unused
16	-	0V	-	Logic ground level.
17	_	CHASSIS GND		Printer's chassis ground, which is isolated from the logic ground
18	-	NC	-	Unused
19-30		GND	-	Twisted-pair return signal ground level.

LX-810 DOT - MATRIX PRINTER

Signal Pin	Return Pin	Signal	Direc-	Description
31	_	īNiT	iN.	When this level becomes LOW, the printer controller is reset to its power-up state and the print buffer is cleared. This level is usually HiGH: its pulse width must be more than 50 microseconds at the receiving terminal
32	_	ERROR	OUT	This level becomes LOW when the printer is. 1) in paper out state. 2) off line 3) in error state.
33	1 — i	GND	- Sar	ne as for Pm 19.30
34	-	NC		Unused.
35	_	-	_ Pu	illed up to + 5V through 3 3K ohm resistance.
36	-	SLCT IN	!N	The DC1/DC3 code is valid only when this signal is "HIGH" (Internal fixing can be carried out with Jumper J1.)

Interface timing



Commands in Numerical Order

ASCII	Dec.	Hex.	Description	Page
BEL	7	07	Beeper	9-11
BS	8	08	Backspace	9-20
HT	9	09	Tab Horizontally	9-21
LF	10	OA	Line Feed	9-15
VT	11	οВ	Tab Vertically	9-17
FF	12	oC	Form Feed	.9-13
CR	13	OD	Carriage Return	9-12
s o	14	OE	Select Double-wide Mode	
			(one line)	9-25
SI	15	OF	Select Condensed Mode	
DC1	17	11	Select Printer	
DC2	18	12	Cancel Condensed Mode	
DC3	19	13	Deselect Printer	9-9
DC4	20	14	Cancel Double-wide Mode	
			(one line)	
CAN	24	18	Cancel Line	
DEL	127	7F	Delete Character	o-12
ESC SO	14	OE	Select Double-wide Mode	
			(one line)	
ESC SI	15	OF	Select Condensed Mode	9-24
ESC EM	25	19	Turn Cut Sheet Feeder Mode	
			On/Off	
ESC	33	21	Master Select	
ESC %	37	25	Select User-defined Set	
ESC &	38	26	Define User-defined Characters (dra	
			mode)	
			Define User-defined Characters (NI	
			mode)	
ESC 🗱	42	2A	Select Graphics Mode	.9-35
ESC -	45	2D	Turn Underlining Mode On/Off	
ESC /	47	2F	Select Vertical Tab Channel	
ESC o	48	30	Select 1/8-inch Line Spacing	
ESC 1	49	31	Select 7/72-inch Line Spacing	.9-15
ESC 2	50	32	select I/b-inch Line Spacing	
ESC 3	51	33	Set n/216-inch Line Spacing	
ESC 4	S2	34	Select Italic Mode	
ESC 5	53	35	Cancel Italic Mode	
ESC 6	54	36	Enable Printable Characters	
ESC 7	55	37	Enable Upper Control Codes	
ESC 8	56	38		9-10
ESC 9	57	39	Enable Paper Out Detection	.9-10

ASCII	Dec.	Hex.	Description Page
ESC:	58	3A	Copy ROM to RAM
ESC <	60	3 c	Select Unidirectional Mode
			(one line) 9-9
ESC?	63	3F	Reassign Graphics Mode 9-36
ESC @	64	40	Initialize Printer 9-8
ESC A	65	41	Set n/72-inch Line Spacing9-16
ESC B	66	42	Set Vertical Tabs
ESC C	67	43	Set Page Length in Lines
ESC C 0	67	43	Set page length in Inches 9-13
ESC D	68	44	Set Horizontal Tabs 9-21
ESC E	69	4s	Select Emphasized Mode
ESC F	70	46	Cancel Emphasized Mode
ESC G	71	47	Select Double-Strike Mode9-27 Cancel Double-Strike Mode9-27
ESC H	72 74	48 4A	Perform n/216-inch Line Feed9-17
ESC J ESC K	74 7s	4A 4B	Select Single-density Graphics
ESC K	15	4D	Mode 9-34
ESC L	76	4C	Select Double-density Graphics
ESC L	70		Mode 9-34
ESC M	77	4D	Select 12 cpi 9-23
ESC N	7.9	4E	Set Skip Over Perforation 9-14
ESC O	79	4F	Cancel Skip Over Perforation9-14
ESC P	80	so	Select 10 cpi 9-23
ESC Q	81	51	Set Right Margin 9-19
ESC R	82	52	Select an International Character Set 9-31
ESC S 0	83	53	Select Superscript Mode 9-27
ESC S 1	83	53	Select Subscript Mode 9-28
ESC T	a4	54	Cancel Superscript/Subscript <i>Mode</i> 9-2 8
ESC U	85	55	Turn Unidirectional Mode On/Off9-1 o
ESC W	а7	57	Turn Double-width Mode On/Off9-2 6
ESC Y	89	59	Select High-Speed Double-density Graphics Mode
ESC Z	90	SA	Select Quadruple-density Graphics
Loc Z	90	SA	Mode
ESC *	94	SE	Select Q-pin Graphics Mode 9-36
ESC d	97	61	Select Near Letter Quality
Loc u	•	01	Justification
ESC b	98	62	Set Vertical Tabs in Channels 9-18
ESC e	101	65	Set Tab Increments
ESC f	102	66	Horizontal/Vertical Skip 9-21
ESC k	107	6B	Select Typestyle Family 9-22
ESC I	108	6C	Set Left Margin 9-19
ESC s	11s	73	Turn Half-Speed Mode ON/Off9-9
ESC t	116	74	Select Character Table
ESC x ,	120	78	Select Near Letter Quality or Draft9-2 2

Installation/Support Tips

Software

The type of printer installed on your system must be identified for each software package. This is usually done through a setup menu. If this printer is not listed in your program, look in the printer User's Manual for the next – best model selection.

DIP Switch Settings

The default settings will usually work for most applications, but they should be checked before using the printer This will avoid unoxpacted raults.

Optional Serial Interface Operation

Epson's optional serial interfaces may be used in this printer, but the DIP switches on the interface board must be set to match the configuration of the serial port on the host computer.

Cut - Sheet Feeder Operation

The page length will have to be adjusted (shortened) if your software does not properly support cut-sheet paper. There will be lines from the first page printed on the top of the second page if the page length is not set correctly.

LX-810 DOT- MATRIX PRINTER

Information Reference List

Engineering Change Notices

None.

Product Support Bulletins

None.

Related Documentation

M - TM - LX810	LX-810 Technical Manual
M-PL-LX810	LX-810 Parts Price List
Y46399102000	LX-810 User's Manual

Technical Information Bulletins

None.