

**Panasonic**


# Operating Instructions

Impact Dot Matrix Printer

# KX-P3123

*Quiet*

*Printing*



Before operating this unit, please read these instructions completely.

## **FOR USER IN THE UNITED STATES ONLY**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The user may find the booklet "Something About Interference" available from FCC local regional offices helpful.

**FCC Warning:** To assure continued FCC emission limit compliance, the user must use only the recommended shield interfacing cable when connecting to a host computer. Also, any unauthorized changes or modifications to this equipment would void the users authority to operate this device.

## WARNING

- The power source voltage of this unit is listed on the nameplate. Plug the printer only into an outlet with the proper voltage.
- To prevent fire or shock hazard, do not expose this product to rain or any type of moisture.
- When you operate this equipment, the outlet should be near the equipment and should be easily accessible.

The serial number of the unit may be found on the label on the rear of the unit. For your convenience, note this number below, and retain this book, along with your proof of purchase, to serve as a permanent record of your purchase in the event of a theft, or for future reference.

MODEL NO.	<u>KX-P3123</u>	NAME OF DEALER	_____
SERIAL NO.	_____	DATE OF PURCHASE	_____

IBM and IBM-PC are registered trademarks of International Business Machines Corporation.

Proprinter is a trademark of International Business Machines Corporation.

Windows is a trademark of Microsoft Corporation.

Epson is a registered trademark of Seiko Epson Corporation.

Epson ESC/P2 is a trademark of Seiko Epson Corporation.

Adobe, ATM and the ATM logo are trademarks of Adobe Systems Inc., which may be registered in certain jurisdictions.

Any details given in these operating instructions are subject to change without notice.

# Table of Contents

---

Chap. 1

## Introduction

Features .....	7
----------------	---

### Chap. 1 Before You Start

---

Chap. 2

<b>Cautions</b> .....	<b>8</b>
Operating Environment .....	8
Precautions .....	9
<b>Unpacking</b> .....	<b>10</b>
Assembling the Parts .....	11
<b>Parts of the Printer</b> .....	<b>12</b>

Chap. 3

### Chap. 2 Setup

---

Chap. 4

<b>Connecting to a Computer</b> .....	<b>14</b>
<b>Ribbon Cassette</b> .....	<b>15</b>
Installing the Ribbon Cassette .....	15
Removing the Ribbon Cassette .....	18
<b>Paper Feed Selection</b> .....	<b>20</b>
<b>Installing Paper</b> .....	<b>21</b>
Fanfold Paper (Push Tractor Mode/Rear Feeding) .....	21
Fanfold Paper (Pull Tractor Mode/Bottom Feeding) .....	25
Single Sheets and Envelopes (Friction Mode) .....	29
Characters Alignment .....	31
<b>Printer-Driver Selection</b> .....	<b>32</b>
<b>Installing a Printer-Driver</b> (Windows Ver. 3.1) .....	<b>33</b>
<b>Self Test</b> .....	<b>35</b>

Chap. 5

Chap. 6

### Chap. 3 Using the Printer

---

Appendix

<b>SUPER QUIET Mode</b> .....	<b>36</b>
<b>Feeding Paper</b> .....	<b>37</b>
(Form Feed/Line Feed/Micro Line Feed/ Reverse Micro Line Feed) .....	37
Tear Off (Rear Feeding Only) .....	37
Paper Parking (Rear Feeding Only) .....	39
Setting the Top of Form (TOF) .....	41

<b>Setting the Control Table</b> .....	<b>43</b>
Printing Out the Current Settings in MACROs .....	43
Setting the FONT/PITCH/FORM LENGTH .....	44
Setting the LEFT/RIGHT MARGIN .....	46
Defining MACRO (MACRO Save) .....	48
Recalling a Defined MACRO (MACRO Recall) .....	50
Recalling FACTORY Settings (Default Settings) .....	51
Setting a COLOR .....	53

## Chap. 4 **Initial Setup Mode**

---

<b>Using the Control Panel</b> .....	<b>55</b>
Printing Out the Current Settings .....	58
Setting the Initial Setup Mode .....	59
Resetting to FACTORY Settings .....	61
<b>Using the Setup Disk</b> .....	<b>62</b>
Running the Initial Setup Program .....	65
Printing Settings .....	66
Setting Selections on Setup Disk .....	66
Save to Disk .....	68
Load from Disk .....	69
Send to Printer .....	69
Resetting to FACTORY Settings .....	71
Help .....	71

## Chap. 5 **Software Commands**

---

<b>Epson ESC/P2™ Mode</b> (Epson LQ-570 Mode) .....	<b>73</b>
<b>IBM Proprinter X24E Mode</b> .....	<b>79</b>
<b>Command Reference Program</b> (Using the Setup Disk) .....	<b>84</b>

## Chap. 6 **Maintenance & Troubleshooting**

---

<b>Periodic Maintenance</b> .....	<b>87</b>
<b>Troubleshooting</b> .....	<b>88</b>

# Table of Contents

---

## Appendix

---

<b>Printer Specifications</b> .....	<b>90</b>
<b>Paper Specifications</b> .....	<b>92</b>
Fanfold Paper .....	92
Single Sheets .....	92
Envelopes .....	92
Printing Area .....	93
<b>Interfacing</b> .....	<b>94</b>
Parallel Interfacing .....	94
<b>Initialization</b> .....	<b>97</b>
<b>Hex Dump</b> .....	<b>98</b>
<b>Character Set Tables</b> .....	<b>99</b>
<b>Glossary</b> .....	<b>105</b>
<b>Index</b> .....	<b>111</b>
<b>Options and Supplies</b> .....	<b>114</b>

Chap. 1

Chap. 2

Chap. 3

Chap. 4

Chap. 5

Chap. 6

Appendix

# Introduction

---

## **Congratulations on purchasing a Panasonic printer.**

This printer is a versatile, high quality 24-pin dot matrix printer which is designed to meet the needs of your office.

This printer has been factory set to operate with most of the popular software packages.

Your application software should control the printer functions. In most cases, there will be no need to change the initial printer settings.

## **Features**

**Printer Emulation:** Epson LQ-570 and IBM Proprinter X24E

**Setup Disk:** A printer-driver for Windows Ver. 3.1, initial setup program and command reference program

**ATM Disk:** Adobe Type Manager with 13 scalable Adobe fonts for Windows Ver. 3.0 or higher

**Super Quiet Mode:** Reduces printing noise

**Color Printing:** 7 colors with the optional color kit (KX-PCK11)

**Fonts:** 3 Draft ( Pica , Elite , Micron )  
6 Letter Quality ( Courier , Bold PS, Prestige , Script ,  
Sans Serif, Roman )  
1 Super Letter Quality ( Roman )  
4 Scalable fonts ( Roman , Sans Serif, Courier , Prestige )

**Printing Speed:** Draft — 192 characters per second (12 cpi)  
LQ — 64 characters per second (12 cpi)  
SLQ — 32 characters per second (12 cpi)

**Paper Handling:** Friction and Tractor (Pull and Push)

**Paper Paths:** Rear, Bottom, Top

**Tear Off:** Advances fanfold paper's perforation to tear position

**Paper Parking:** Allows single sheets/envelopes to be used without removing/wasting fanfold paper

**Cut Sheet Feeder Option (KX-PT10):** Provides fast and automatic feeding of single sheets


**Serial Interface Option (KX-PS13 and KX-PS14):** You may select parallel or serial when either serial interface board is installed

# Cautions


## Operating Environment

- Do not use the printer under the following conditions.


Extremely high or low temperature  
[temperature range: 10~35°C (50~95°F)]




Extremely high or low humidity  
(humidity range: 30~80% RH)




Areas of poor ventilation  
[a minimum of 4" (10 cm) clearance on all sides is necessary to insure proper ventilation]




Areas of high dust concentration



Areas with extreme vibration



Areas on an unstable or unlevel surface






# Precautions


The following precautions are recommended to extend the life of the printer.

**Keep all liquids away from the printer.**


— Accidental spillage of a liquid into the printer can cause severe damage.




**Do not place books, paper, or other items on top of the printer.**




**Do not operate the printer without paper and a ribbon cassette installed.**




**Avoid prolonged use without allowing the printhead time to cool.**



**Do not obstruct the movement of the printhead while in operation.**




**If the printer is not going to be used for an extended period, unplug the power cord.**




# Unpacking


Having unpacked the printer, make sure none of the contents shown below are missing or damaged. Report damages or shortages to the store from which the unit was purchased.




Printer (KX-P3123)




Ribbon cassette (KX-P150)




Platen knob



Operating manual



Setup disk



ATM disk

- This setup disk contains a printer-driver for Windows Ver. 3.1 ( P. 33), an initial setup program ( P. 55) and a command reference program ( P. 84).
- To use this setup disk you need to have an IBM-PC or a compatible computer with a 3.5" floppy disk drive.


- For detailed information on ATM disk, refer to ATM disk manual.

**Note:**


- It is recommended that you save the original carton and packing materials for proper shipping and transporting of the printer.

## Assembling the Parts


- 1 Insert the platen knob into the hole on the right side of the printer and rotate it slowly until it slips onto the shaft. Push the platen knob onto the platen shaft to secure.




- 2 Fold the smoked plastic cover forward, and remove the protective paper.




- 3 Open the smoked plastic cover.



- 4 Remove the top cover pad.



# Parts of the Printer



① **Control table**

This control table shows the details of the setting for each item.

② **Row indicators**

This indicates the selected item.

③ **Column indicators**

This indicates the elements of each item.

④ **SUPER QUIET (TOF) switch**

Pressing this switch reduces print noise, however, it also reduces the printing speed. Pressing this switch alternately turns the SUPER QUIET mode on/off. (P. 36)

In the FUNCTION mode, pressing this switch sets the Top of Form (TOF).  
(P. 41)

⑤ **TEAR OFF (OTHERS) switch**

Pressing this switch will advance or reverse the paper for tearing off in the OFF LINE mode, or when not printing in the ON LINE mode. (P. 37)

In the FUNCTION mode, pressing this switch will advance the column position for the OTHERS on the control table.

⑥ **LOAD/PARK (SET) switch**

Pressing this switch will load/park the paper in the OFF LINE mode, or when not printing in the ON LINE mode. (P. 39)

In the FUNCTION mode, pressing this switch will set or release the items on the control table.

⑦ **ON LINE (FONT) switch**

This switch opens and closes the communication lines with the computer.


In the FUNCTION mode, pressing this switch advances the column position for the FONT on the control table.

⑧ **FF (PITCH) switch**

Pressing this switch advances the paper to the top of form on next page in the OFF LINE mode or when the printer is not printing in the ON LINE mode (depending on your TOF setting).

In the FUNCTION mode, pressing this switch advances the column position for the PITCH on the control table.

## (Rear View)



### ⑨ LF (FORM LENGTH) switch

Pressing this switch advances the paper one line at a time. Holding this switch will advance the paper continuously until the switch is released. These functions are active in the OFF LINE mode or when not printing in the ON LINE mode.

**In the FUNCTION mode, pressing the switch advances the column for the FORM LENGTH on the control table.**

### ⑩ FUNCTION switch

This switch allows you to enter and exit the FUNCTION mode.

### ⑪ ON LINE/FUNCTION indicator

This indicator is lit when the printer is in the ON LINE mode, and is out in the OFF LINE mode. It blinks in the FUNCTION mode.

### ⑫ SUPER QUIET indicator


This indicator is lit when the printer is in the SUPER QUIET mode.

### ⑬ POWER/PAPER OUT indicator

This indicator is lit when the power is on and paper is installed. It blinks when paper is not installed.

# Connecting to a Computer

1a




Attach one end of the parallel interface cable to your printer as shown, and the other end to your computer. Be sure to secure the printer clips.

**Note:**


- If you do not have a parallel interface cable, you will need to purchase one from your local computer store or dealer.

1b



If the cable has a frame ground wire, connect it to the frame ground terminal.

2




Plug the printer into a grounded 3 prong AC socket.


When power is supplied to the printer, the power indicator on the control panel will light.

# Ribbon Cassette

## Installing the Ribbon Cassette




- 1 Turn the power switch off for safety.
- 2 Fold the smoked plastic cover forward by lifting tab on right side.



- 1 Raise the smoked plastic cover.
- 2 Remove the smoked plastic cover.

**Caution:**


- The printhead may be hot. Use caution when the cover is open.



- Gently slide the carriage toward the center of the unit.


# Ribbon Cassette

4




Move the head gap lever to the (+) position.

5



Rotate the knob on the ribbon cassette to remove any slack.


6



Slip the ribbon between the ribbon mask and the printhead nose.



7




Press down on rear of the cassette until the blue wing tab snaps into place.

8

Replace the smoked plastic cover to its original position.


9




Adjust the head gap lever for the thickness of the paper you are using.

Position	Use for
1 or 2	Thinner sheets
3, 4, 5 and 6	Thick or multiple sheets or envelopes

## Removing the Ribbon Cassette




- 1 Turn the power switch off for safety.
- 2 Fold the smoked plastic cover forward by lifting tab on right side.



- 1 Raise the smoked plastic cover.
- 2 Remove the smoked plastic cover.


**Caution:**

- The printhead may be hot. Use caution when the cover is open.




Gently slide the carriage toward the center of the unit.

4



Move the head gap lever to the (+) position.

5









Spread the blue wing tab and lift up the cassette.

# Paper Feed Selection

This printer has two paper feed mechanisms to support 3 paper paths. One mechanism is TRACTOR mode for continuously fed paper. In the tractor mode you can choose between PUSH or PULL.

The other paper feed mechanism is FRICTION mode. In the friction mode you can feed single sheets or envelopes through the top. The optional KX-PT10 Cut Sheet Feeder will accommodate automatic feeding of single sheets, from the top paper path.

<p><b>Push Tractor Mode “” (Rear Feeding)</b></p> <ul style="list-style-type: none"> <li>— fanfold paper (1 part)</li> <li>— multipart forms consisting of 2 parts</li> </ul>	 <p style="text-align: right;">Rear feeding</p>
<p><b>Pull Tractor Mode “” (Bottom Feeding)</b></p> <ul style="list-style-type: none"> <li>— multipart forms consisting of 3 or 4 parts</li> <li>— labels</li> <li>— fanfold paper (1 part)</li> </ul>	 <p style="text-align: center;">Bottom feeding</p>
<p><b>Friction Mode “”</b></p> <ul style="list-style-type: none"> <li>— single sheets</li> </ul> <p>(The KX-PT10 allows you to automatically feed up to 80 sheets of 20 lb paper.)</p> <ul style="list-style-type: none"> <li>— envelopes</li> </ul>	 <p style="text-align: right;">Top feeding</p>


**Note:**

- When feeding paper from the bottom, do not use reverse line feed. Paper may not feed correctly and print quality may not be optimum.
- Paper Parking is not available when the paper is installed from the bottom.
- Multipart forms consisting of 2 parts may be used for rear feeding (Push mode). For 3 or 4 part forms, we recommend bottom feeding (Pull mode) for optimum print quality.

# Installing Paper

## Fanfold Paper (Push Tractor Mode/Rear Feeding)

1



Head gap lever


- 1 Turn the power on.

You will hear a beep.  
The PAPER OUT indicator will flash indicating that paper is not installed in the printer.

- 2 Adjust the head gap lever for the thickness of paper you are using.

Position	Use for
1 or 2	Thinner sheets
3, 4, 5 and 6	Thick or multiple sheets


2



Paper feed selector

Set the paper feed selector to the "  " position.

3



Smoked plastic cover


Top cover

- 1 Fold the smoked plastic cover forward by lifting the tab on right side.

- 2 Remove the top cover.

# Installing Paper

4




- 1 Unlock the tractors by pulling the tractor clamping levers forward.
- 2 Slide the tractors to opposite ends of the printer.

**Note:**


- In most applications, you will find that the 0 indicator on the tear bar is a useful tool for predetermining your left most print position.

5



- 1 Move the paper support to the center position.
- 2 Open the tractor covers.

6




- 1 To set the tractors to the proper width, align the paper sprocket holes with the tractor pins by moving the tractors.

**Note:**

- Make sure the paper is straight before closing the tractor covers.

- 2 Close tractor covers.

7




❶ Adjust the tractors to remove any slack in the paper.

❷ Lock the tractor clamping levers.

8

Open the tractor covers and remove the paper, then close the tractor covers.

9




While holding down **ON LINE** , press **FF** .

**Note:**

- This will cause the tractors to rotate slowly for approximately 60 seconds.


# Installing Paper

10



While the tractors are rotating, insert the fanfold paper evenly behind the tractors, until the tractor pins catch the paper sprocket holes.

11



Press **LOAD/PARK** once.


**Note:**

- This will load the paper to the first print line.

12

Replace the top cover to its original position, then close the smoked plastic cover.

13



If the **ON LINE** indicator is not lit, press **ON LINE** to get ready to print.


**Note:**

- To avoid paper curl in push mode, park the paper after use.



## Fanfold Paper (Pull Tractor Mode/Bottom Feeding)

1



- 1 Turn the power on.


You will hear a beep.

The PAPER OUT indicator will flash indicating that paper is not installed in the printer.

- 2 Adjust the head gap lever for the thickness of the paper you are using.


Position	Use for
1 or 2	Thinner sheets
3, 4, 5 and 6	Thick or multiple sheets

2



- Set the paper feed selector to the "  " position.


3



- 1 Fold the smoked plastic cover forward by lifting the tab on the right side.
- 2 Remove the top cover.

# Installing Paper

4




- 1 Unlock the tractors by pulling the tractor clamping levers forward.
- 2 Slide the tractors to accommodate the approximate width of the paper you are using.

**Note:**

- In most applications, you will find that the 0 indicator on the tear bar is a useful tool for predetermining your left most print position.

5




**Remove the pull up roller unit.**

**Note:**


- Be sure to remove the pull up roller unit before using the bottom feeding.

6




- 1 Move the paper support to the center position.
- 2 Open the tractor covers.

7



Push the fanfold paper up through the bottom opening until it appears on the platen.


8



Align the paper sprocket holes with the tractor pins.

Make sure the paper is straight before closing the tractor covers.


9



① Adjust the tractors to remove any slack from the paper.

② Lock the tractor clamping levers.

## 10



Replace the pull up roller.


**Note:**

- Be sure to press down the pull up roller unit it snaps into place.

## 11

Replace the top cover to its original position, then close the smoked plastic cover.

## 12




If the ON LINE indicator is not lit, press **ON LINE** to get ready to print.

**Note:**

- In the pull tractor mode (Bottom feeding), reverse line feed will not feed paper correctly and the resulting printout may not be correct.

## Single Sheets and Envelopes (Friction Mode)




- ❶ Turn the power on.**


You will hear a beep.  
The PAPER OUT indicator will flash indicating that no paper is installed in the printer.

- ❷ Adjust the head gap lever for the thickness of the paper you are using.**



Position	Use for
1 or 2	Thinner sheets
3, 4, 5 and 6	Thick or multiple sheets or envelopes



- Set the paper feed selector to the "  position.**




- ❶ Fold the smoked plastic cover forward by lifting the tab on the right side.**
- ❷ Reposition the top cover into the single sheet position by inserting the top cover pins into the slots in the printer.**

These slots are indicated by black arrows (  ,  ) on the printer cabinet.

# Installing Paper

4




Separate the paper guides to the approximate width of your paper or envelope.

**Note:**

- To predetermine your left most print position, move the left paper guide until it clicks into place.

5



1 Insert a sheet of paper through the paper guides and behind the platen.


The paper will automatically load to the first print line position.

2 Fold the smoked plastic cover until it rests on the top cover.

**Note:**




- To disable Auto Load, turn Auto Load off in the initial setup mode. (P. 55)
- If Auto Load is disabled, press **LOAD/PARK** to automatically load paper to the first print line.

6




If the ON LINE indicator is not lit, press **ON LINE** to get ready to print.

**Note:**

- When Automatic load is set to off in the initial setup mode, press the **LOAD/PARK** switch to load the paper to the first print line.
- When the paper feed selector is in the "  " position, the buzzer will sound to inform you that the selector is in the wrong position.
- When loading an envelope, if the envelope will not load smoothly, move the paper feed selector to the "  " position and insert the envelope manually, then move the selector back to the "  " position.

## Characters Alignment

The center of all characters printed on this printer will be aligned with the ribbon mask line (RML). The RML is a useful marker that shows you exactly where your print line is located.

**Note:**

- Remember that once you rotate the platen knob, the top of form (TOF) will no longer be recognized.

# Printer-Driver Selection

The Printer-Driver Selection contains the software codes your application software program uses to access the printer's features.

This procedure is the final step before printing and is performed in your application software program. The steps will vary, depending on the software program. Consult your software package for proper procedures. The Panasonic KX-P3123 will be your first choice. However, if the Panasonic KX-P3123 printer is not listed in your software, you must select an alternative from the following table.

**Printer-Driver Selections (in order of priority)**

<b>Printer Selections</b>	<b>Color Printer Selections *2 (KX-PCK11 Color Kit must be installed)</b>
Panasonic KX-P3123	Panasonic KX-P3123
Panasonic KX-P3124	Panasonic KX-P3124
Epson LQ-570 (ESC/P2™)	Panasonic KX-P2123
Panasonic KX-P2123	Panasonic KX-P2124
Panasonic KX-P2124	Epson LQ-860
Panasonic KX-P1124i	Epson LQ-2500/2550
Epson LQ series	
IBM Proprinter X24E *1	
IBM Proprinter X24 *1	

- \*1 If selecting the IBM Proprinter X24E or IBM Proprinter X24 in your software, printer emulation must also be changed in the initial setup mode. (P. 55~72)
- \*2 To obtain color and utilize the internal scalable fonts, the Panasonic KX-P3123 printer-driver must be selected in your software.



# Installing a Printer-Driver (Windows Ver. 3.1)

If you are using Windows Ver. 3.1, please insert your setup disk in drive A or B and follow the directions below.


Before you use the setup disk, it is recommended that you make a back-up copy and store the original in a safe place.

**Note:**

- Use the DISKCOPY command of the operating system to make a back-up copy. Refer to your DOS manual for further information.


- 1** In "Main Group", select "Print Manager".
- 2** In "Options", select "Printer Setup".

- 3** Click **Add >>** .



- 4** In "List of Printers", select "Install Unlisted or Updated Printer".

- 5** Click **Install...** .




# Installing a Printer-Driver (Windows Ver. 3.1)

**6** Insert the setup disk into drive A.


If you choose to insert the setup disk into drive B, you must type B:\

**7** Click **OK** .



**8** Highlight your Panasonic Printer model.

**9** Click **OK** .



**10** Click **Set As Default Printer** .

**11** Click **Close** .

**12** Exit "Print Manager".


# Self Test

This printer has a self test feature which allows you to test the printer.

## 1 Load a sheet of paper (fanfold or single sheet), then turn the power off.

(See P. 21~31)


## 2



While pressing **LF**, turn the power on, then release.

Do not release **LF** until printing has started.

## 3 A sample printout will begin, which serves as a self test.



## 4 If the printer is functioning properly, you may turn the power off during the self test, or you may run the entire test. (approximately 20 minutes.)

# SUPER QUIET Mode

The SUPER QUIET mode is a useful feature for further reducing print noise, however, it also reduces the printer's speed.

The printer can store this function in the MACRO as one of the printing conditions. To simplify the MACRO setting process, you should set the SUPER QUIET mode before setting any other item on the control table.


## Turning on the SUPER QUIET mode:

**1** Be sure the power is on.

**Note:**

- Make sure the ON LINE/FUNCTION indicator is not blinking. If it is blinking, press **FUNCTION**.

**2**




Press **SUPER QUIET** to turn the SUPER QUIET mode on.

You will hear a beep and the SUPER QUIET indicator will light.

## Turning off the SUPER QUIET mode:

**1** Be sure the power is on.

**2**



Press **SUPER QUIET** again to turn the SUPER QUIET mode off.

The SUPER QUIET indicator will not be lit.

# Feeding Paper

You can adjust the paper position by using the front panel switches when the printer is in the OFF LINE mode or when the printer is not printing in the ON LINE mode.

## Form Feed

With paper installed, pressing **FF** moves the printhead to the center and advances the paper to the next Top of Form (TOF) position.

## Line Feed

With paper installed, pressing **LF** once advances the paper one line. Holding the switch will move the printhead to the center and advances the paper continuously until you release the switch.

## Micro Line Feed

With paper installed, while pressing **ON LINE**, press **FF** once to advance the paper one micro line (1/180"). Holding the switch will advance the paper continuously until you release the switch.

## Reverse Micro Line Feed

With paper installed, while pressing **ON LINE**, press **LF** once to reverse the paper one micro line (1/180"). Holding the switch will reverse the paper continuously until you release the switch. The printer cannot reverse the paper past the printable area. (P. 93)

### Note:

- Reverse Micro Line Feed will not work correctly in the pull tractor mode.
- When pressing **FF** or **LF**, the amount of paper which is fed is determined by the current setting for lines per inch (lpi). The lpi is specified by the software command or through the control panel.

## Tear Off (Rear Feeding Only)

This function allows you to advance your fanfold paper's perforation to the tear position. This is not dependent on your Top of Form (TOF) position, but is dependent on your form length. After tearing off the page, you can return your paper to your Top of Form. This function can be automatic through the FUNCTION mode.


**1** Be sure the power is on.

### Note:

- Make sure the ON LINE/FUNCTION indicator is not blinking. If it is blinking, press **FUNCTION**.


# Feeding Paper

2




Press **TEAR OFF** to advance the paper's perforation to the tear bar.

3




Fold the smoked plastic cover forward by lifting tab on right side.

4



Tear off the page, using the tear bar.

5



Press **TEAR OFF** to reverse the paper back to the Top of Form.

6

Close the smoked plastic cover.


### Note:


- A Top of Form setting (see P. 41) in the non-printable area is ignored by Tear Off. Tear Off will use the Top of Form setting that was last saved.
- If you do not press **TEAR OFF** the second time, once data is received, the printer will automatically reverse the paper to the top of form position, if you choose the automatic Tear Off function.

## Paper Parking (Rear Feeding Only)




This function allows you to use single sheets or envelopes without removing or wasting your fanfold paper.

### Parking the Fanfold Paper

- 1 Be sure power is on and the paper feed selector is in the “” position.
- 2 Tear off the printed page(s) of the fanfold paper being used.
- 3 If the ON LINE/FUNCTION indicator is blinking, press **FUNCTION** .
- 4 Press **LOAD/PARK** to reverse the fanfold paper to the park position.




### Loading Single Sheets or Envelopes

- 1  Move the paper feed selector to “” (Friction mode).
- 2 
  - ① Fold the smoked plastic cover by lifting tab on right side.
  - ② Raise the top cover to single sheet position.

# Feeding Paper

3




Separate the paper guides and load a single sheet or an envelope.

(See P. 29 "Single Sheets and Envelopes") When you are finished printing, remove the sheet (or envelope) from the printer.

## Reloading the Fanfold Paper


1




❶ Lower the top cover for fanfold paper.


❷ Replace the smoked plastic cover to its original position.

2



Move the paper feed selector to "  " (Push Tractor mode).



3




Press **LOAD/PARK** to reload the fanfold paper to the Top of Form.




## Setting the Top of Form (TOF)

This printer has a Top of Form (TOF) function which stores the first print line position and loads the paper to the designated position automatically. The first print line position will be stored even after the power is turned off. Additionally, the printer can store 3 different Top of Form positions depending on the paper feed method. [fanfold paper-push (  ), single sheet (  ) and single sheet using the cut sheet feeder (option: KX-PT10)]

### 1 Be sure the power is on.

If necessary, redefine the FORM LENGTH of the paper you are using through your application software or the printer's control table (  P. 44).

### 2




Press **LOAD/PARK** to load the paper.

### 3

To redefine your paper's first print line position, it is recommended to use your application software. If this feature is not provided in your software, adjust the paper position by using the Line Feed, Micro Line Feed, or Reverse Micro Line Feed.

(  P. 37)

### 4




Press **FUNCTION** to enter the FUNCTION mode.

#### Note:

- Do not rotate the platen knob, otherwise the printer will not be able to count the number of lines.

## 5




Press **SUPER QUIET** (TOF) to set the Top of Form for the current position.

**Note:**


- A Top of Form position (less than 5 inches from the top of page) will be saved even after the power is turned off. Pressing **LOAD/PARK** will advance the paper to the most recently saved Top of Form setting.
- A Top of Form position set in the area greater than 5 inches will not be saved after the power is turned off, after parking the paper, or after using Tear Off.
- Temporary Top of Form setting is indicated by one beep. Saved Top of Form is indicated by two beeps.
- When you use fanfold paper, the Top of Form position must be set on the first page because the printer does not accept a top margin which is longer than one page.
- When bottom feeding, do not use this function.

## 6



Press **FUNCTION** (EXIT) to exit the FUNCTION mode.

## 7



Press **ON LINE** to receive data.

# Setting the Control Table


While in the function mode, the black lettering (FONT, PITCH, FORM LENGTH, etc.) will help you navigate through the Control Table. These settings will be temporary, unless stored in a MACRO. Refer to page 48.

## Printing Out the Current Settings in MACROs

Before changing any settings on the control table, you should verify the current settings.

**1** Load a sheet of paper (fanfold or single sheet).


**2**



Press **FUNCTION** to enter the FUNCTION mode.


The ON LINE/FUNCTION indicator will blink.

**3**




Press and release **TEAR OFF** (OTHERS) until all the column indicators are blinking.

**4**



Press **LOAD/PARK** (SET) to print out the current settings.


**5**



Press **FUNCTION** (EXIT) to exit the FUNCTION mode.

## Setting the FONT/PITCH/FORM LENGTH


**1** Be sure the power is on.



Press **FUNCTION** to enter the FUNCTION mode.


The ON LINE/FUNCTION indicator will blink.

**3A** FONT




Press and release **ON LINE** (FONT) to reach the desired font. Go to step 4.

**3B** PITCH




Press and release **FF** (PITCH) to reach the desired pitch. Go to step 4.

**3C** FORM LENGTH



Press and release **LF** (FORM LENGTH) to reach the desired form length.

## 4




Press **LOAD/PARK** (**SET**) to store the setting into the temporary memory.

You will hear a beep. The ON LINE/FUNCTION indicator will stop blinking and be lit. If you wish to make additional changes, refer to step(s) 3A, B or C.

**Note:**

- When making multiple changes, **LOAD/PARK** (**SET**) must be pressed after each selection is made.

## 5




Press **FUNCTION** (**EXIT**) to exit the **FUNCTION** mode.

## Setting the LEFT/RIGHT MARGIN

**1** Be sure the power is on.


**2**



Press **FUNCTION** to enter the **FUNCTION** mode.


The ON LINE/FUNCTION indicator will blink.

**3**



Press and release **TEAR OFF** (**OTHERS**) until the column indicator is blinking over the desired margin.


**4**



Press **LOAD/PARK** (**SET**) to enter the **MARGIN** mode.

The column indicator will be lit.

## 5




- 1 Press **SUPER QUIET** (TOF) to move the printhead to the left.
- 2 Press **TEAR OFF** (OTHERS) to move the printhead to the right.

### NOTE:

- When the printhead is at the far left, press **SUPER QUIET** twice to move it to the far right. You will hear a beep a few times.
- When the printhead is at the far right, press **TEAR OFF** twice to move it to the far left. You will hear a beep a few times.

## 6




Press **LOAD/PARK** (SET) to specify the margin location, and to exit the MARGIN mode.

You will hear two beeps. The column indicator will blink.

### Note:

- If the left margin is set to the right of the right margin, the right margin is reset to 80 (10 cpi) automatically.
- If the right margin is set to the left of the left margin, the left margin is reset to 0 automatically.

## 7



Press **FUNCTION** (EXIT) to exit the FUNCTION mode.

### Note:

- You can set either the left or the right margin first.
- You can also change the margins by software commands. This will override the control table settings.


## Defining MACRO (MACRO Save)

A MACRO allows you to store a combination of your most frequently used Font, Pitch, Form Length, Left/Right Margin, Color, and Super Quiet mode settings into the printer's memory which can be easily recalled and/or changed. This will enable you to recall one of two combinations (MACROs #1, #2) at the touch of a button eliminating the need to reset all your features each time you have a print job that uses a previously set combination.

When you turn the power switch on, the printer reads MACRO #1 automatically. Therefore it is recommended to store the format you use most often in MACRO #1.

**1** Be sure the power is on.

**2**



Press **FUNCTION** to enter the **FUNCTION** mode.


The ON LINE/FUNCTION indicator will blink.

**3** Set the print features you wish to store as the current settings. [FONT/PITCH/FORM LENGTH (P.44), LEFT/RIGHT MARGIN (P.46), COLOR (P.53), SUPER QUIET (P.36)]

**Note:**

- COLOR can not be set without installation of the color kit (KX-PCK11).


**4**



Press and release **TEAR OFF** (OTHERS) until the column indicator is blinking over **MACRO #1** or **#2**.




5



Press **LOAD/PARK** (SET) to set the **MACRO** mode.

You will hear a beep. The column indicator over your desired **MACRO** will be lit.


6



Press **TEAR OFF** [SAVE] to save the **current settings to the MACRO**.

You will hear two beeps.


7



Press **FUNCTION** (EXIT) to exit the **FUNCTION** mode.


## Recalling a Defined MACRO (MACRO Recall)

**1** Be sure the power is on.




Press **FUNCTION** to enter the **FUNCTION** mode.

The ON LINE/FUNCTION indicator will blink.




Press and release **TEAR OFF** (OTHERS) until the column indicator is blinking over **MACRO #1** or **#2**.




Press **LOAD/PARK** (SET) to set the **MACRO** mode.

You will hear a beep. The column indicator over your desired **MACRO** will be lit.



Press **SUPER QUIET** [RECALL] to recall the **MACRO**.

You will hear a beep. The previously defined **MACRO** is recalled as a current setting.




Press **FUNCTION** (EXIT) to exit the **FUNCTION** mode.

## Recalling FACTORY Settings (Default Settings)

All of the original settings in the Function mode can be restored in the printer as they were originally set when the printer was shipped. You can recall the factory settings anytime. (You cannot change the factory settings. The MACROs settings are **not** canceled by recalling the factory settings.)

**1** Be sure the power is on.


**2**



Press **FUNCTION** to enter the **FUNCTION** mode.


The ON LINE/FUNCTION indicator will blink.

**3**



Press and release **TEAR OFF** (OTHERS) until the column indicator is blinking over **FACTORY**.

**4**




Press **LOAD/PARK** (SET) to set the **FACTORY** mode.

You will hear a beep. The column indicator over **FACTORY** will be lit.

# Setting the Control Table


5



Press **SUPER QUIET** [RECALL] to recall the **FACTORY** setting.

You will hear a beep. The **FACTORY** setting is recalled as a current setting.

6



Press **FUNCTION** (EXIT) to exit the **FUNCTION** mode.


Chap. 3

## Setting a COLOR

Before you use this function, make sure that the color kit (KX-PCK11) is installed in the printer.

**1** Be sure the power is on.


**2**



Press **FUNCTION** to enter the **FUNCTION** mode.


The ON LINE/FUNCTION indicator will blink.

**3**



Press and release **TEAR OFF** (**OTHERS**) until the column indicator is blinking over **COLOR** (**OPTION**).


**4**



Press **LOAD/PARK** (**SET**) to enter the **COLOR** mode.

You will hear a beep. The **OTHERS** row indicator will blink.


**5**



Press and release **TEAR OFF** (**OTHERS**) until the column indicator combination is blinking over your desired color.

# Setting the Control Table


6



Press **LOAD/PARK** (SET) to store this setting into the temporary memory and exit the **COLOR** mode.

You will hear two beeps. The OTHERS row indicator will be lit. The column indicator over **COLOR** will blink.

7



Press **FUNCTION** (EXIT) to exit the **FUNCTION** mode.

Chap. 3

Using the Printer

This printer allows you to select any one of the colors given in the table below.

COLOR	COLUMN indicator					
	C1	C2	C3	C4	C5	C6
BLACK	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
RED (MAGENTA)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
ORANGE	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
YELLOW	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
GREEN	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
BLUE (CYAN)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>
VIOLET	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>

(Control table)

= ON       = OFF

**Note:**

- C3, C4, C5 and C6 are used to represent the color selection C1 and C2 have no function when selecting color.
- Only one color can be printed at a time. Multi-color printing may be accessible through your application software.

# Using the Control Panel

Your Printer allows you to select 32 initial setup items.

You can use the control panel to select following 24 of all the initial setup items.

①	<b>Emulation</b>		
	Epson*	Epson LQ-570	
	IBM	IBM Proprinter X24E	
②	<b>Character Set</b> (☞ P. 99)		
	Italic*	(Epson only)	
	Graphic character set 1	Graphic character set 2	
③	<b>Code Page</b> (☞ P. 99)		
	PC-437 (USA)*		
	PC-850 (Multilingual)		
	PC-860 (Portugal)		
	PC-863 (Canada-French)		
	PC-865 (Norway)		
④	<b>International Character Set</b> (☞ P. 104)		
	USA*	Sweden	Denmark 2
	France	Italy	Spain 2
	Germany	Spain 1	Latin America
	U.K.	Japan	Korea
	Denmark 1	Norway	LEGAL
	<b>Zero Font</b>		
⑤	0*	(Normal zero)	
	ø	(Slashed zero)	
	0	(Point zero)	
⑥	<b>Download Buffer Control</b>		
	ON	Enable	
	OFF*	Disable	
⑦	<b>Cut Sheet Feeder</b>		
	ON	Enable	
	OFF*	Disable	
	[C.S.F. option (KX-PT10) is installed.]		
⑧	<b>Paper Out Detector</b>		
	ON*	Active	
	OFF	Ignored	
⑨	<b>Buzzer Sound Control</b>		
	ON*	Enable	
	OFF	Disable	
⑩	<b>Alternate Graphics Mode (AGM)</b>		
	ON	AGM is ON	
	OFF*	AGM is OFF	
	(This setting is effective only in the IBM mode.)		

⑪	<b>Auto LF</b>	
	ON	CR+LF
	OFF*	CR only
⑫	<b>Auto CR</b>	
	ON	LF, VT, ESC+"J"+CR
	OFF*	LF, VT, ESC+"J" only
	(This setting is effective only in the IBM mode.)	
⑬	<b>Skip Perforation</b>	
	ON	1 inch
	OFF*	No skip
⑭	<b>Graphic Direction</b>	
	Uni*	Uni-directional printing
	Bi	Bi-directional printing
⑮	<b>Auto Tear Off</b>	
	ON	Auto Tear Off
	OFF*	Manual Tear Off
	(using TEAR OFF switch)	
⑯	<b>Interface</b>	
	ON	Serial interface
	OFF*	Parallel interface
	(This setting is effective only when KX-PS14 is installed.)	
⑰	<b>Data Length</b>	
	ON	7 bit data length
	OFF*	8 bit data length
⑱	<b>Auto Loading</b>	
	ON*	Enabled
	OFF	Disabled
	(This setting is ineffective when using the fanfold paper or C.S.F.)	
⑲	<b>Baud Rate</b>	
	150	2400
	300	4800
	600	9600*
	1200	
⑳	<b>Parity Control</b>	
	None parity*	Odd parity
	Ignore parity	Even parity

\* denotes setting when shipped from factory.

⑳	<b>Protocol Select</b>
	ON ..... X/ON-X/OFF Protocol OFF* ..... DTR Protocol
㉑	<b>Remaining Buffer Capacity to Suspend Data Transfer (S.D.T.) (X/OFF)</b>
	ON* ..... 128 byte OFF ..... 512 byte
㉒	<b>Remaining Buffer Capacity to Resume Data Transfer (R.D.T.) (X/ON)</b>
	— When the S.D.T. is set to ON
	ON* ..... 256 byte OFF ..... 384 byte
	— When the S.D.T. is set to OFF
	ON* ..... 640 byte OFF ..... 768 byte


㉓	<b>Designation of Signal Polarity for DTR Protocol Mode</b>
	NO ..... When the signal is "space", the printer tells the computer that it cannot accept transferring data.  OFF* ..... When the signal is "mark", the printer tells the computer that it cannot accept transferring data.

**Note:**

- Items ⑲ ~ ㉒ will only appear when the optional KX-PS14 serial interface board is installed.

\* denotes setting when shipped from factory.

The control table is replaced with the following table.



**Note:**

- The rightmost column indicator is ignored.
- Each indicator is controlled by using the keys below.



	<b>SUPER QUIET</b>	<b>TEAR OFF</b>	<b>LOAD PARK</b>	<b>ON LINE</b>	<b>FF</b>	<b>LF</b>
		C1 <input type="checkbox"/>	C2 <input type="checkbox"/>	C3 <input type="checkbox"/>	C4 <input type="checkbox"/>	C5 <input type="checkbox"/>
R1 <input type="checkbox"/> R2 <input type="checkbox"/> R3 <input type="checkbox"/> R4 <input type="checkbox"/>	Print Current Initial Setup Condition					Factory Read
R1 <input checked="" type="checkbox"/> R2 <input type="checkbox"/> R3 <input type="checkbox"/> R4 <input type="checkbox"/>	① Epson	IBM				
R1 <input type="checkbox"/> R2 <input checked="" type="checkbox"/> R3 <input type="checkbox"/> R4 <input type="checkbox"/>	② Italic	G1	G2			
R1 <input checked="" type="checkbox"/> R2 <input checked="" type="checkbox"/> R3 <input type="checkbox"/> R4 <input type="checkbox"/>	③ USA	Multilingual	Portugal	Canada-French	Norway	
R1 <input type="checkbox"/> R2 <input type="checkbox"/> R3 <input checked="" type="checkbox"/> R4 <input type="checkbox"/>	Turkey					
R1 <input checked="" type="checkbox"/> R2 <input checked="" type="checkbox"/> R3 <input checked="" type="checkbox"/> R4 <input type="checkbox"/>	④ USA	France	Germany	U.K.	Denmark 1	
R1 <input type="checkbox"/> R2 <input checked="" type="checkbox"/> R3 <input checked="" type="checkbox"/> R4 <input type="checkbox"/>	Sweden	Italy	Spain 1	Japan	Norway	
R1 <input checked="" type="checkbox"/> R2 <input checked="" type="checkbox"/> R3 <input checked="" type="checkbox"/> R4 <input type="checkbox"/>	Denmark 2	Spain 2	Latin America	Korea	Legal	
R1 <input type="checkbox"/> R2 <input type="checkbox"/> R3 <input type="checkbox"/> R4 <input checked="" type="checkbox"/>	⑤ 0	∅	∅			
R1 <input checked="" type="checkbox"/> R2 <input type="checkbox"/> R3 <input type="checkbox"/> R4 <input checked="" type="checkbox"/>	⑥ Download Buffer	⑦ C.S.F.	⑧ P.O. Detector	⑨ Buzzer	⑩ A.G.M.	
R1 <input type="checkbox"/> R2 <input checked="" type="checkbox"/> R3 <input type="checkbox"/> R4 <input checked="" type="checkbox"/>	⑪ Auto LF	⑫ Auto CR	⑬ Skip Perf.	⑭ G. Direction	⑮ Auto Tear Off	
R1 <input checked="" type="checkbox"/> R2 <input checked="" type="checkbox"/> R3 <input type="checkbox"/> R4 <input checked="" type="checkbox"/>	⑯ Interface	⑰ Data Length	⑱ Auto Loading			
R1 <input type="checkbox"/> R2 <input type="checkbox"/> R3 <input checked="" type="checkbox"/> R4 <input checked="" type="checkbox"/>	⑲ 150	300	600	1200	2400	
R1 <input checked="" type="checkbox"/> R2 <input type="checkbox"/> R3 <input checked="" type="checkbox"/> R4 <input checked="" type="checkbox"/>	4800	9600				
R1 <input type="checkbox"/> R2 <input checked="" type="checkbox"/> R3 <input checked="" type="checkbox"/> R4 <input checked="" type="checkbox"/>	⑳ None Parity	Ignore Parity	Odd Parity	Even Parity		
R1 <input checked="" type="checkbox"/> R2 <input checked="" type="checkbox"/> R3 <input checked="" type="checkbox"/> R4 <input checked="" type="checkbox"/>	㉑ Protocol	㉒ S.D.T.	㉓ R.D.T.	㉔ Signal Polarity		


ROW indicator condition:

=light is lit     =light is not lit     =light is blinking

## Printing Out the Current Settings


Before changing the items of the initial setup mode, you should get a print out to verify the current settings.

1



- 1 Load a sheet of paper (fanfold or single sheet).
- 2 Turn the power switch off.


2



While pressing **FUNCTION**, turn the power switch on.

The ON LINE/FUNCTION indicator will blink, and all the row indicators will be lit.


3



Press **TEAR OFF**, **LOAD/PARK**, **ON LINE**, or **FF**.

All current settings will be printed.


4



Press **FUNCTION** (EXIT) to exit the **FUNCTION** mode, or continue by proceeding to page 59, step 2, if you wish to make changes.

## Setting the Initial Setup Mode


1



While pressing **FUNCTION**, turn the power switch on.

The ON LINE/FUNCTION indicator will blink, and all the row indicators will be lit.

2




Press and release **SUPER QUIET** until your desired row indicator combination is lit. (P. 57)

**Note:**

- Row indicators will switch each time you press **SUPER QUIET**.

3




Use **TEAR OFF** (C1), **LOAD/PARK** (C2), **ON LINE** (C3), **FF** (C4), and **LF** (C5) to change the settings of the column indicators. (P. 57)

**Note:**

- Each column indicator is simply controlled by pressing one of the 5 switches.

4



Press **FUNCTION** (EXIT) to store your selection(s) and exit the initial setup mode.

## Examples

1. While pressing **FUNCTION** , turn the power on.
2. Press and release **SUPER QUIET** until the desired row indicator combination is lit.
3. Use **TEAR OFF** (C1), **LOAD/PARK** (C2), **ON LINE** (C3), **FF** (C4), and **LF** (C5) to change the settings of the column indicators.
4. Press **FUNCTION** (**EXIT**) to store the settings and exit the initial setup mode.


Emulation: Press **SUPER QUIET** once.




Code Page: Press **SUPER QUIET** 3 times.




Download Buffer Control: Press **SUPER QUIET** 8 times.



Cut Sheet Feeder: Press **SUPER QUIET** 8 times.




Auto Loading: Press **SUPER QUIET** 10 times.



Indicators condition:  
 ■ = light is lit  
 □ = light is not lit


## Resetting to FACTORY Settings

You can reset all the initial setup mode settings to the FACTORY settings anytime. Follow the steps below.




While pressing **FUNCTION**, turn the power switch on.

The ON LINE/FUNCTION indicator will blink, and all the row indicators will be lit.



Press **LF**.



You will hear a beep.



Press **FUNCTION** (EXIT) to exit the initial setup mode.

# Using the Setup Disk

This printer allows you to select 32 initial setup items shown in the table below. You can select all these items by using the setup disk.

Menu	Item	Setting		
PRINT STYLE	FONT	PROGRAM* DRAFT BOLD PS COURIER PRESTIGE ROMAN SANS SERIF	SCRIPT SUPER LQ COURIER SC PRESTIGE SC ROMAN SC SANS SERIF SC	"SC" is a scalable font.
	PITCH	PROGRAM* 10 CPI 12 CPI	15 CPI 17 CPI PROPORTION	When -SC sequences are selected, PITCH is automatically set to PROPORTION.
	POINT SIZE	8* to 96 with 10.5 and 21 (every 2 points)		POINT SIZE is displayed only when -SC sequences are selected in FONT.
EMULATION	EMULATION	EPSON*	IBM	
PAGE FORMAT	SKIP PERF.	1 INCH*	NO SKIP	(This condition can also be changed through software commands.)
	P. LENGTH	11 INCHES* 12 INCHES 14 INCHES	8 INCHES 8.5 INCHES 11 $\frac{2}{3}$ INCHES	
	L. MARGIN	0* to 78 (10 CPI)		
	R. MARGIN	2 to 80* (10 CPI)		
PRINT MODE	G. DIRECTION	UNI*	BI	
TEXT ENHANCEMENT	ZERO FONT	NORMAL* POINT	SLASH	
CHARACTER SET	COUNTRY	USA* FRANCE GERMANY U.K. DENMARK 1 SWEDEN ITALY SPAIN 1	JAPAN NORWAY DENMARK 2 SPAIN 2 L. AMERICA KOREA LEGAL	(  P. 104 "International Character Set")
	CHARACTER SET	ITALIC* GRAPHIC 1	GRAPHIC 2	
	CODE PAGE	USA* MULTILINGUAL PORTUGAL CANADA FRENCH NORWAY TURKEY		(  P. 99 "Character Set Tables")

\* denotes setting when shipped from factory.

Menu	Item	Setting		
INSTALL	AGM/IBM	OFF*	ON	(This setting is effective only in the IBM mode.)
	AUTO CR/IBM	OFF*	ON	(This setting is effective only in the IBM mode.)
	AUTO LF	OFF*	ON	(This condition can also be changed through software commands.)
	AUTO LOADING	ON*	OFF	(This setting is effective only when the paper feed selector is in position.)
	BUZZER	ON*	OFF	(This setting is available only for BEL command.)
	P. O. DETECTOR	OFF*	ON	
	QUIET MODE	OFF*	ON	
	TEAR OFF	MANUAL*	AUTO	
	CSF MODE	OFF*	ON	[This setting is effective only when C.S.F. option (KX-PT10) is installed.]
	DOWNLOAD	OFF*	ON	
	COLOR	BLACK* BLUE GREEN ORANGE	RED VIOLET YELLOW	[This setting is effective only when Color Kit option (KX-PCK11) is installed.]
INTERFACE	INTERFACE	PARALLEL*	SERIAL	(This setting is effective only when KX-PS14 is installed.)
	DATA LENGTH	8 BIT*	7 BIT	
	BAUD RATE	150 300 600 1200	2400 4800 9600*	(These settings are effective only when KX-PS14 is installed.)
	PARITY	NONE* IGNORE	ODD EVEN	
	PROTOCOL	DTR*	XNO/OFF	
	RDT	SDT+128*	SDT+256	
	SDT	RBC 128*	RBC 512	
	SIGNAL POLARITY	MARK*	SPACE	

\* denotes setting when shipped from factory.

# Using the Setup Disk

This setup disk can only be used in an IBM-PC or a compatible computer with a 3.5" floppy disk drive.

Before you use the setup disk, it is recommended that you make a back-up copy and store the original in a safe place.

This printer has been factory set to operate with most of the popular software packages. In most cases there will be no need to change the initial setup items. Refer to page 62 to verify that the factory settings meet your requirements. If no changes are required, you should be ready to print.

**Note:**

- Use the DISKCOPY command of the operating system to make a back-up copy. Refer to your DOS manual for further information.
- You may find it convenient to install the Setup Disk programs directly onto your C Drive, rather than reading them from the Setup Disk each time a change is necessary. Either method is acceptable.

To perform an automatic installation of the Setup Disk files onto your C Drive, follow the steps below:

1. Insert the Setup Disk into drive A or B.
2. Type A: (or B:) and press **Enter**.
3. Type INSTALL and press **Enter**.

This procedure automatically creates a directory called 3123 and copies all of the programs from your Setup Disk onto your C Drive.

At your C:\>prompt, type CD 3123 and press **Enter**.

Type SETUP and press **Enter** to complete the procedure. Be sure to type this instruction as one word.

If not, you will receive a Syntax error message.



## Running the Initial Setup Program

**1** Insert your setup disk into either drive A or B.

<For DOS>

**2** Type A: (or B:) and press **Enter**.

**3** Type SETUP

**4** Press **Enter**.

<For WINDOWS>

**2** Select Run from the File menu.


**3** Type A:\SETUP (or B:\SETUP)

**4** Click **OK** (or Press **Enter**).

You will receive a "Please Wait" message until your first screen automatically appears.

**5** The first screen is an introduction to the operation of the Setup Disk. Please read it through and press any key to continue.

**6** The <Menu> window will be highlighted.



### Note:

- You can proceed through the Setup Disk using a computer mouse or your arrow keys.
- **ESC** exits you to DOS when you are at the <Menu> window.

### Using the keyboard:

- **↓** / **↑** to move within the current window.
- **→** to advance to <Item> and <Setting> windows.
- **Enter** to make selection in <Setting> window.
- **←** to return to previous window.

### Using the mouse:

- Highlight the selection and click the left mouse button.
- Click the right mouse button to move to the previous screen.

## Printing Settings

Before you change the initial setup mode settings, you can verify the settings by printing them.


**1** Press **F5**.

A Print Setting window will be displayed.

**2** Press **Y** or **N**.

"Y": All the settings (current, MACROs, FACTORY) will be printed.

"N": The display will return to previous screen.



## Setting Selections on Setup Disk

**1** In the <Menu> window, press **↑** or **↓**.


Select your desired menu (ex; PRINT STYLE).

**2** Press **→**.

The <Item> window will be highlighted.

**3** Press **↑** or **↓**.

Highlight the desired item (ex; FONT).



**4** Press **→** .


The <Setting> window will be highlighted.

**5** Press **↑** or **↓** .

Highlight the desired setting (ex; DRAFT).

**6** Press **Enter** .


The desired item has been set. A √ will appear next to the new setting.



**7** Press **←** .

The <Item> window will be highlighted.


To make additional changes in the <Item> window, repeat steps 3 to 6.



**8** Press **←** .

The <Menu> window will be highlighted.

To make additional changes in the <Menu> window, repeat steps 1 to 6.



## 9 When all changes have been made, you may perform any one of the following operations:


- Save to Disk - **F3** (P. 68)
- Print Settings - **F5** (P. 66)
- Send to Printer - **F10** (P. 69)

## 10 Press **ESC**.

An Exit window will be displayed.

## 11 Press **Y** or **N**.

- "Y": You have exited the Initial Setup program.
- "N": The display will return to the <Menu> window.



## Save to Disk

### 1 Press **F3**.


A Save to Disk window will be displayed.

### 2 Enter a file name (up to 8 characters, upper or lower case).

### 3 Press **Enter**.

All the settings will be saved on the disk and the display will return to the <Menu> window.

### 4 Press **ESC**, **Y** to exit to DOS.



## Load from Disk


**1** Press **F4** .

A Load from Disk window will be displayed.

**2** Use **↑** or **↓** to highlight your desired file name.

**3** Press **Enter** .

All the settings in the file will be loaded to your screen. To transfer these settings to your printer, you must perform the **F10** Send to Printer operation: (P. 71)




## Send to Printer

**1** Press **F10** .

A Port Selection window will be displayed.

**Note:**

- Before setting the Port selections, it is recommended to print out the current settings of your printer (P. 58). Set the Port selections so as to match the settings of your printer.



**2** Press **↑** or **↓** .

Select the desired Port selection item. (ex; PORT)

# Using the Setup Disk

**3** Press **→** .

A Selection window will be displayed.

**4** Press **↑** or **↓** .

Highlight the desired setting (ex; LPT1).

**5** Press **Enter** .

The desired item has been set.

**6** Press **←** .

To make additional changes in the Port selection menu, repeat steps 2 to 5.



**7** Press **↓** until **YES** is highlighted.

**8** Press **Y** or **N** .

"Y": All the settings will be sent to the printer.

"N": The display will return to the <Menu> window.

**9** Press **ESC** , **Y** to exit to DOS.



## Resetting to FACTORY Settings

**1** Press **F2** .

**2** Press **Y** or **N** .

"Y": All the settings will be reset to FACTORY settings.

"N": The display will return to the <Menu> window.


**3** If **Y** was selected, you may perform one of the following operations:

Save to Disk — **F3** ( P. 68)

Print Settings — **F5** ( P. 66)

Send to printer — **F10** ( P. 69)

**4** Press **ESC** , **Y** to exit to DOS.



## Help


When you cannot remember what a particular function is, HELP will show you the explanations of the functions.

**1** Press **F1** .

A Help Item screen will be displayed.

**2** Press **←** / **→** / **↑** / **↓** .

Highlight your desired item.  
(ex; AGM/IBM)



**3** Press **Enter** .


A definition will be displayed.

**4** Press **ESC** .

The Help Item screen will be displayed.

**5** Press **ESC** .

The display will return to the <Menu> window.





# Epson ESC/P2 Mode (Epson LQ-570 Mode)

This section is for the development of programs and printer-drivers and assumes the reader is proficient in programming. More detailed information has been stored in the command reference program on the setup disk.

## Font Selection

Function	Name	Parameter
Selects print quality	ESC "x" n	n=0: Draft font n=1: LQ font n=2: SLQ mode (Roman 5, 10, 6, and 12 CPI fonts only)
Selects print typeface	ESC "k" n	n=0: Roman n=1: Sans Serif n=2: Courier n=3: Prestige n=4: Script n=6: Bold PS
Selects sub/superscript printing	ESC "S" n	n=0: Superscript n=1: Subscript
Releases sub/superscript printing	ESC "T"	
Selects font by pitch and point	ESC "X" m n <sub>1</sub> n <sub>2</sub>	0 ≤ m ≤ 127 except 2,3 and 4 m=0: No change to character spacing m=1: Character spacing is set to PS m>4: Sets character spacing to <sup>360</sup> /m CPI (0 ≤ n <sub>1</sub> ≤ 255)DEC (0 ≤ n <sub>2</sub> ≤ 127)DEC n <sub>1</sub> =0 n <sub>2</sub> =0: No change to point size [Total points]=-(n <sub>1</sub> +n <sub>2</sub> ×256)/2

## Character Pitch Selection

Function	Name	Parameter
Sets pica pitch (10 cpi) printing	ESC "P"	
Sets elite pitch (12 cpi) printing*	ESC "M"	
Sets micron (15 cpi) printing	ESC "g"	
Sets compressed (17 cpi) printing*	SI or ESC SI	
Releases compressed printing	DC2	
Sets/Releases proportional spacing	ESC "p" n	n=0: Release n=1: Set
Sets programmable pitch/ highlighting based on the value of n	ESC "!" n	(0 ≤ n ≤ 255)DEC n=0: Pica      n=16: Double-strike n=1: Elite     n=32: Double-width n=2: PS        n=64: Italic n=4: Comp.    n=128: Underlining n=8: Emphasized

\* When elite and compressed pitches are set simultaneously, subsequent output is printed in 20 cpi (up to 160 cpl).

## Character Highlight Selection

Function	Name	Parameter
Sets emphasized printing	ESC "E"	
Releases emphasized printing	ESC "F"	
Sets/Releases double high printing	ESC "w" n	n=0: Release n=1: Set
Sets single-line double wide printing	SO or ESC SO	
Releases single-line double wide printing	DC4	
Sets/Releases double wide printing	ESC "W" n	n=0: Release n=1: Set
Sets outline and shadow printing	ESC "q" n	n=0: Releases outline/shadow n=1: Outline n=2: Shadow n=3: Outline with Shadow
Sets double strike printing	ESC "G"	
Releases double strike printing	ESC "H"	
Sets/Releases underlining	ESC "-" n	n=0: Release n=1: Set
Sets/Releases score	ESC "(" "-" 3 0 1 d1 d2	d1=1: Underline d1=2: Strikethrough d1=3: Overscore  d2=0: Cancel the score line selected by d1 d2=1: Single continuous line d2=2: Double continuous line d2=5: Single broken line d2=6: Double broken line

## Word Processing Mode Selection

Function	Name	Parameter
Sets character dots spacing	ESC SP n	$(0 \leq n \leq 127)_{DEC}$
Sets unit	ESC "(" "U" 1 0 m	m=10, 20, 30, 40, 50, 60 (unit= $\frac{m}{3600}$ inch)
Sets horizontal motion index (HMI)	ESC "c" n1 n2	HMI= $n1+n2 \times 256$ $(0 \leq n1 \leq 255)_{DEC}$ $(0 \leq n2 \leq 4)_{DEC}$

## Character Set Selection

Function	Name	Parameter
Sets Italic printing	ESC "4"	
Releases Italic printing	ESC "5"	
Sets international character set	ESC "R" n	n=0: USA            n=8: Japan n=1: France        n=9: Norway n=2: Germany      n=10: Denmark 2 n=3: UK            n=11: Spain 2 n=4: Denmark 1   n=12: Latin n=5: Sweden                   America n=6: Italy            n=13: Korea n=7: Spain 1        n=64: Legal
Selects graphic character set 1	ESC "7"	
Selects graphic character set 2	ESC "6"	
Selects alternate character set	ESC "t" n	n=0: Italic n=1: PC437 (US) n=2: User-defined characters n=3: PC437 (US)
Assign character table	ESC "(" "t" 3 0 n1 n2 0	(0 ≤ n1 ≤ 3) (48 ≤ n1 ≤ 51) (0 ≤ n2 ≤ 255) n2=0: Italic n2=1: PC437 (US) n2=3: PC850 (Multilingual) n2=5: PC853 (Turkey) n2=7: PC860 (Portugal) n2=8: PC863 (Canada-French) n2=9: PC865 (Norway)
Prints data as character	ESC "(" "A" n1 n2 Data	(0 ≤ n1 ≤ 255)DEC (0 ≤ n2 ≤ 125)DEC

## Bit Image (Graphics) Mode Selection

Function	Name	Parameter														
Sets 8-pin image standard density (60 dpi)	ESC "K" n1 n2 Data															
Sets 8-pin image double density (120 dpi)	ESC "L" n1 n2 Data															
Sets 8-pin image double density/double speed (120 cpi)	ESC "Y" n1 n2 Data															
Sets 8-pin bit image quadruple density (240 dpi)	ESC "Z" n1 n2 Data															
Sets bit image mode selection	ESC "*" m n1 n2 Data	<table style="width: 100%; border: none;"> <tr> <td style="text-align: center;"><b>8-pin Dots/Inch</b></td> <td style="text-align: center;"><b>24-pin Dots/Inch</b></td> </tr> <tr> <td>m=0: 60</td> <td>m=32: 60</td> </tr> <tr> <td>m=1: 120</td> <td>m=33: 120</td> </tr> <tr> <td>m=2: 120D</td> <td>m=38: 90</td> </tr> <tr> <td>m=3: 240</td> <td>m=39: 180</td> </tr> <tr> <td>m=4: 80</td> <td>m=40: 360</td> </tr> <tr> <td>m=6: 90</td> <td></td> </tr> </table>	<b>8-pin Dots/Inch</b>	<b>24-pin Dots/Inch</b>	m=0: 60	m=32: 60	m=1: 120	m=33: 120	m=2: 120D	m=38: 90	m=3: 240	m=39: 180	m=4: 80	m=40: 360	m=6: 90	
<b>8-pin Dots/Inch</b>	<b>24-pin Dots/Inch</b>															
m=0: 60	m=32: 60															
m=1: 120	m=33: 120															
m=2: 120D	m=38: 90															
m=3: 240	m=39: 180															
m=4: 80	m=40: 360															
m=6: 90																

## Bit Image (Graphics) Mode Selection (Continued)

Function	Name	Parameter
Reassigns graphics mode density	ESC "?" n m	n=75: Reassign Standard Density (ESC "K" n1 n2) n=76: Reassign Double Density (ESC "L" n1 n2) n=89: Reassign Double Speed, Double Density (ESC "Y" n1 n2) n=90: Reassign Quadruple Density (ESC "Z" n1 n2) m is same as m of "Sets bit image mode selection"
Selects graphics mode	ESC "(" "G" 1 0 n	n=1, 49
Prints raster graphics	ESC "." c v h m n1 n2 Data	c=0, 1 v=10, 20 h=10, 20 (1 ≤ m ≤ 24) (0 ≤ n1 ≤ 255)DEC (0 ≤ n2 ≤ 127)DEC

## Paper Feed Selection—Amount

Function	Name	Parameter
Sets paper feed to 1/8 inch (3.2 mm)	ESC "0"	
Sets paper feed to 1/6 inch (4.2 mm)	ESC "2"	
Sets paper feed to n/60 inch	ESC "A" n	(0 ≤ n ≤ 127)DEC
Sets paper feed to n/180 inch	ESC "3" n	(0 ≤ n ≤ 255)DEC
Sets paper feed to n/360 inch	ESC "+" n	(0 ≤ n ≤ 255)DEC

## Paper Feed Selection

Function	Name	Parameter
Feeds paper one line	LF	
Feeds paper to next Top of Form	FF	
Executes paper feed of n/180 inch for one line	ESC "J" n	(0 ≤ n ≤ 255)DEC
Executes reverse paper feed of n/180 inch for one line	ESC "j" n	(0 ≤ n ≤ 255)DEC

## Page Format Selection

Function	Name	Parameter
Sets page length in inches	ESC "C" 0 n	(0 ≤ n ≤ 22)DEC
Sets page length in lines	ESC "C" n	(1 ≤ n ≤ 127)DEC
Sets left margin	ESC "f" n	0 ≤ n ≤ 78: Pica 0 ≤ n ≤ 93: Elite 0 ≤ n ≤ 117: Micron 0 ≤ n ≤ 133: Compressed
Sets skip perforation	ESC "N" n	(1 ≤ n ≤ 127)DEC

## Page Format Selection (Continued)

Function	Name	Parameter
Sets right margin	ESC "Q" n	2 ≤ n ≤ 80: Pica 3 ≤ n ≤ 96: Elite 3 ≤ n ≤ 120: Micron 4 ≤ n ≤ 137: Compressed
Releases skip perforation	ESC "O"	
Sets page length in defined unit	ESC "(" "C" 2 0 n1 n2	n=n1+n2×256
Sets page format	ESC "(" "c" 4 0 m1 m2 n1 n2	m=m1+m2×256 m: Top margin in defined units n+n1+n2×256 n: Bottom margin in defined units

## Tabulation—Horizontal

Function	Name	Parameter
Sets horizontal tab	ESC "D" n1 ... nx 0	(1 ≤ x ≤ 32)
Releases horizontal tab	ESC "D" 0	
Executes horizontal tab	HT	

## Tabulation—Vertical

Function	Name	Parameter
Sets vertical tab	ESC "B" n1 ... nx 0	(1 ≤ x ≤ 16)
Releases vertical tab	ESC "B" 0	
Executes vertical tab	VT	

## Carriage Control

Function	Name	Parameter
Prints, then backspaces one character	BS	
Prints a line, then returns carriage	CR	
Unidirection mode (single line)	ESC "<"	
Sets/Releases single direction printing	ESC "U" n	n=0: Release    n=1: Set
Sets/Releases half speed printing	ESC "s" n	n=0: Release    n=1: Set
Moves the print position to an absolute horizontal position	ESC "\$" n1 n2	n=n1+n2×256 (0 ≤ n1 ≤ 255)DEC    (0 ≤ n2 ≤ 127)DEC
Moves the print position to a relative horizontal position	ESC "^" n1 n2	n=n1+n2×256 (0 ≤ n1 ≤ 255)DEC    (0 ≤ n2 ≤ 127)DEC

# Epson ESC/P2 Mode (Epson LQ-570 Mode)

## Carriage Control (Continued)

Function	Name	Parameter
Sets absolute vertical print position	ESC "(" "V" 2 0 n1 n2	(0 ≤ n1 ≤ 255)DEC (0 ≤ n2 ≤ 127)DEC
Sets relative vertical print position	ESC "(" "v" 2 0 n1 n2	(0 ≤ n1 ≤ 255)DEC (0 ≤ n2 ≤ 127)DEC

## Data Control

Function	Name	Parameter
Clears data in line buffer	CAN	
Selects printer remotely	DC1	
Deselects printer remotely	DC3	
Deletes last printable character	DEL	
Sets MSB on	ESC ">"	
Sets MSB off	ESC "="	
Cancels MSB setting	ESC "#"	

## Download Character Selection

Function	Name	Parameter
Defines download font	ESC "&" 0 n m do d1 d2 Data	
Selects ROM CG	ESC "%" n	n=0: Select ROM Character Generator
Selects download CG		n=1: Select download CG
Copies internal ROM CG font into download CG	ESC ":" 0 n 0	n=0: Roman      n=3: Prestige n=1: Sans Serif    n=4: Script n=2: Courier        n=6: Bold PS

## Miscellaneous

Function	Name	Parameter
Initializes the printer	ESC "@"	
Cut sheet feeder control	ESC EM n	n="R": Eject a sheet n="0": Cut sheet feeder mode is OFF n="4": Cut sheet feeder mode is ON
Sounds the buzzer	BEL	

## Color Selection

Function	Name	Parameter
Selects print color	ESC "r" n	n=0: Black    n=4: Yellow n=1: Red      n=5: Orange n=2: Blue     n=6: Green n=3: Violet

# IBM Proprinter X24E Mode

This section is for the development of programs and printer-drivers and assumes the reader is proficient in programming. More detailed information has been stored in the command reference program on the setup disk.

## Font Selection

Function	Name	Parameter
Selects print quality	ESC "I" n	n=0: Internal Draft 10 cpi font n=2: Internal LQ 10 cpi font n=3: Internal Proportional LQ font n=4: Download Draft 10 cpi font n=6: Download LQ 10 font n=7: Download Proportional LQ font n=8: Internal Draft 12 cpi font n=10: Internal LQ 12 cpi font n=12: Download Draft 12 cpi font n=14: Download LQ 12 cpi font n=16: Internal Draft 17 cpi font n=18: Internal LQ 17 cpi font n=20: Download Draft 17 cpi font n=22: Download LQ 17 cpi font
Selects print typeface	ESC "k" n	n=0: Roman n=1: Sans Serif n=2: Courier n=3: Prestige n=4: Script n=6: Bold PS
Selects subscript printing Selects superscript printing	ESC "S" n	n=0: Superscript n=1: Subscript
Releases sub/superscript printing	ESC "T"	

## Character Pitch Selection

Function	Name	Parameter
Sets elite pitch (12 cpi) printing	ESC ":"	
Sets compressed (17 cpi) printing	SI or ESC SI	
Releases elite and compressed printing	DC2	
Sets/Releases proportional spacing	ESC "P" n	n=0: Release n=1: Set

## Character Highlight Selection

Function	Name	Parameter																														
Sets emphasized printing	ESC "E"																															
Releases emphasized printing	ESC "F"																															
Sets double strike printing	ESC "G"																															
Releases double strike printing	ESC "H"																															
Sets single-line double wide printing	SO or ESC SO																															
Releases single-line double wide printing	DC4																															
Sets/Releases double wide printing	ESC "W" n	n=0: Release n=1: Set																														
Sets double high & double wide printing	ESC [" "@" 4 0 0 0 m3 m4	<table border="0"> <tr> <td><b>m3</b></td> <td><b>Line feed</b></td> <td><b>Character height</b></td> </tr> <tr> <td>0:</td> <td>Unchanged</td> <td>Unchanged</td> </tr> <tr> <td>1:</td> <td>Unchanged</td> <td>Single-line</td> </tr> <tr> <td>2:</td> <td>Unchanged</td> <td>Double-high</td> </tr> <tr> <td>16:</td> <td>Single</td> <td>Unchanged</td> </tr> <tr> <td>17:</td> <td>Single</td> <td>Single-high</td> </tr> <tr> <td>18:</td> <td>Single</td> <td>Double-high</td> </tr> <tr> <td>32:</td> <td>Double</td> <td>Unchanged</td> </tr> <tr> <td>33:</td> <td>Double</td> <td>Single-high</td> </tr> <tr> <td>34:</td> <td>Double</td> <td>Double-high</td> </tr> </table> m4=0: No change m4=1: Single-wide m4=2: Double-wide	<b>m3</b>	<b>Line feed</b>	<b>Character height</b>	0:	Unchanged	Unchanged	1:	Unchanged	Single-line	2:	Unchanged	Double-high	16:	Single	Unchanged	17:	Single	Single-high	18:	Single	Double-high	32:	Double	Unchanged	33:	Double	Single-high	34:	Double	Double-high
<b>m3</b>	<b>Line feed</b>	<b>Character height</b>																														
0:	Unchanged	Unchanged																														
1:	Unchanged	Single-line																														
2:	Unchanged	Double-high																														
16:	Single	Unchanged																														
17:	Single	Single-high																														
18:	Single	Double-high																														
32:	Double	Unchanged																														
33:	Double	Single-high																														
34:	Double	Double-high																														
Sets/Releases underlining	ESC "-" n	n=0: Release n=1: Set																														
Sets/Releases overlining	ESC "_" n	n=0: Release n=1: Set																														

## Character Set Selection

Function	Name	Parameter																
Selects alternate character set 1	ESC "7"																	
Selects alternate character set 2	ESC "6"																	
Changes the current code page	ESC [" "T" 4 0 0 0 n1 n2	<table border="0"> <tr> <td>n1=00H and n2=00H:</td> <td>Current</td> </tr> <tr> <td>n1=01H and n2=B5H:</td> <td>USA</td> </tr> <tr> <td>n1=03H and n2=52H:</td> <td>Multilingual</td> </tr> <tr> <td>n1=03H and n2=5CH:</td> <td>Portugal</td> </tr> <tr> <td>n1=03H and n2=5FH:</td> <td>Canada French</td> </tr> <tr> <td>n1=03H and n2=61H:</td> <td>Norway</td> </tr> <tr> <td>n1=03H and n2=59H:</td> <td>Turkey</td> </tr> <tr> <td>Except the above:</td> <td>Download font</td> </tr> </table>	n1=00H and n2=00H:	Current	n1=01H and n2=B5H:	USA	n1=03H and n2=52H:	Multilingual	n1=03H and n2=5CH:	Portugal	n1=03H and n2=5FH:	Canada French	n1=03H and n2=61H:	Norway	n1=03H and n2=59H:	Turkey	Except the above:	Download font
n1=00H and n2=00H:	Current																	
n1=01H and n2=B5H:	USA																	
n1=03H and n2=52H:	Multilingual																	
n1=03H and n2=5CH:	Portugal																	
n1=03H and n2=5FH:	Canada French																	
n1=03H and n2=61H:	Norway																	
n1=03H and n2=59H:	Turkey																	
Except the above:	Download font																	



**Bit Image (Graphics) Mode Selection**

Function	Name	Parameter														
Sets 8-pin image standard density (60 dpi)	ESC "K" n1 n2 Data															
Sets 8-pin image double density (120 dpi)	ESC "L" n1 n2 Data															
Sets 8-pin image double density/double speed (120 dpi)	ESC "Y" n1 n2 Data															
Sets 8-pin image quadruple density (240 dpi)	ESC "Z" n1 n2 Data															
Sets bit image mode selection (A.G.M. mode only)	ESC "*" m n1 n2 Data	<table border="0"> <tr> <td><b>8-pin Dots/Inch</b></td> <td><b>24-pin Dots/Inch</b></td> </tr> <tr> <td>m=0: 60</td> <td>m=32: 60</td> </tr> <tr> <td>m=1: 120</td> <td>m=33: 120</td> </tr> <tr> <td>m=2: 120D</td> <td>m=38: 90</td> </tr> <tr> <td>m=3: 240</td> <td>m=39: 180</td> </tr> <tr> <td>m=4: 80</td> <td>m=40: 360</td> </tr> <tr> <td>m=6: 90</td> <td></td> </tr> </table>	<b>8-pin Dots/Inch</b>	<b>24-pin Dots/Inch</b>	m=0: 60	m=32: 60	m=1: 120	m=33: 120	m=2: 120D	m=38: 90	m=3: 240	m=39: 180	m=4: 80	m=40: 360	m=6: 90	
<b>8-pin Dots/Inch</b>	<b>24-pin Dots/Inch</b>															
m=0: 60	m=32: 60															
m=1: 120	m=33: 120															
m=2: 120D	m=38: 90															
m=3: 240	m=39: 180															
m=4: 80	m=40: 360															
m=6: 90																
Sets bit image mode selection	ESC "[ "g" n1 n2 m Data	<table border="0"> <tr> <td><b>8-pin Dots/Inch</b></td> <td><b>24-pin Dots/Inch</b></td> </tr> <tr> <td>m=0: 60</td> <td>m=8: 60</td> </tr> <tr> <td>m=1: 120</td> <td>m=9: 120</td> </tr> <tr> <td>m=2: 120D</td> <td>m=11: 180</td> </tr> <tr> <td>m=3: 240</td> <td>m=12: 360</td> </tr> </table>	<b>8-pin Dots/Inch</b>	<b>24-pin Dots/Inch</b>	m=0: 60	m=8: 60	m=1: 120	m=9: 120	m=2: 120D	m=11: 180	m=3: 240	m=12: 360				
<b>8-pin Dots/Inch</b>	<b>24-pin Dots/Inch</b>															
m=0: 60	m=8: 60															
m=1: 120	m=9: 120															
m=2: 120D	m=11: 180															
m=3: 240	m=12: 360															

**Paper Feed Selection—Amount**

Function	Name	Parameter
Sets paper feed to 1/8 inch (3.2 mm)	ESC "0"	
Sets paper feed to 7/72 inch (2.5 mm)	ESC "1"	
Executes line spacing set by ESC "A" n	ESC "2"	
Sets paper feed to n/72 inch (or n/60 inch in A.G.M. mode)	ESC "A" n	(0 ≤ n ≤ 255)DEC
Sets paper feed to n/216 inch (or n/180 inch in A.G.M. mode)	ESC "3" n	(0 ≤ n ≤ 255)DEC
Selects the base line feed unit for ESC "3" and ESC "J"	ESC "[ "v" 4 0 0 0 0 n	n=180: 1/180 inch base unit n=216: 1/216 inch base unit
Sets/Release automatic line feed	ESC "5" n	n=0: Release n=1: Set

## Paper Feed Selection

Function	Name	Parameter
Feeds paper one line	LF	
Feeds paper to next top of form	FF	
Executes one-line paper feed of $\frac{n}{216}$ inch (or $\frac{n}{180}$ inch in A.G.M. mode)	ESC "J" n	$(0 \leq n \leq 255)_{DEC}$

## Page Format Control

Function	Name	Parameter
Sets page length in inches	ESC "C" 0 n	$(1 \leq n \leq 255)_{DEC}$
Sets page length in lines	ESC "C" n	$(1 \leq n \leq 255)_{DEC}$
Sets left and right margins	ESC "X" n1 n2	Pica: $1 \leq n1 \leq 78$ $3 \leq n2 \leq 80$ Elite: $1 \leq n1 \leq 93$ $4 \leq n2 \leq 96$ Comp.: $1 \leq n1 \leq 133$ $5 \leq n2 \leq 137$
Sets skip perforation	ESC "N" n	$(0 \leq n \leq 255)_{DEC}$
Releases skip perforation	ESC "O"	
Sets Top of Form	ESC "4"	

## Tabulation—Horizontal

Function	Name	Parameter
Sets horizontal tab	ESC "D" n1 n2 ...nx 0	$(1 \leq x \leq 32)$
Releases horizontal tab	ESC "D" 0	
Executes horizontal tab	HT	

## Tabulation—Vertical

Function	Name	Parameter
Sets vertical tab	ESC "B" n1 n2 ... nx 0	$(1 \leq x \leq 64)$
Releases vertical tab	ESC "B" 0	
Executes vertical tab	VT	
Returns to default tabs	ESC "R"	

### Carriage Control

Function	Name	Parameter
Prints, then backspaces on character	BS	
Prints a line, then returns carriage	CR	
Sets/Release single direction printing	ESC "U" n	n=0: Release n=1: Set
Moves the print position to a relative horizontal position ( $\frac{1}{120}$ inch)	ESC "d" n1 n2	Position: $n1+(256 \times n2)$

### Data Control

Function	Name	Parameter
Clears data in line buffer	CAN	
Selects printer remotely	DC1	
Deselects printer remotely	ESC "Q" 36	

### Download Character Selection

Function	Name	Parameter
Defines download font	ESC "=" n1 n2 35 A1 A2 Data	

### Miscellaneous

Function	Name	Parameter
Prints continuously from All Character Chart	ESC "^" n1 n2	Total count: $n2 \times 256 + n1$
Prints one character from All Character Chart	ESC "A"	
Sets OFF LINE mode	ESC "I"	
Resets to initial state	ESC "T" "K" n1 0 m 36 p1 p2	
Sounds the buzzer	BEL	

### Color Selection

Function	Name	Parameter
Select print color	ESC "r" n	n=0: Black n=1: Red n=2: Blue n=3: Violet n=4: Yellow n=5: Orange n=6: Green

# Command Reference Program

The command reference program allows you to access a detailed explanation of each software command or the proportional spacing tables on your computer screen. Each displayed explanation can be printed out if required.

Before you use the setup disk, it is recommended that you make a back-up copy and store the original in a safe place.

**Note:**

- Use the DISKCOPY command of the operating system to make a back-up copy. Refer to your DOS manual for further information.
- You may find it convenient to install the Setup Disk programs directly onto your C Drive, rather than reading them from the Setup Disk each time a change is necessary. Either method is acceptable.

To perform an automatic installation of the Setup Disk files onto your C Drive, refer to page 64.

## 1 Insert your setup disk into either drive A or B.

<For DOS>

**2** Type **A:** (or **B:**) and press **Enter**.

**3** Type **CMDREF**

**4** Press **Enter**.  
Screen 1 will be displayed.

<For WINDOWS>

**2** Select **Run** from the File menu.

**3** Type **A:\CMDREF** (or **B:\CMDREF**)

**4** Click **OK** (or Press **Enter**).  
Screen 1 will be displayed.

Screen 1

```
<< Panasonic KX-P3123 command reference utility (xxxxxxxxxxx) >>
-- SELECT EMULATION --
=====
|EPSON|
|IBM|
=====

[↑]/[↓] : Select emulation
[Enter] : Set emulation
[E]     : Exit to DOS
```

**5** Press **↑** or **↓** .

Select an emulation.

**6** Press **Enter** .

The emulation will be set and screen 2 will be displayed.

**7** Press **Pg.Up** / **Pg.Down** or **↑** / **↓** .

Select a command.

## Screen 2

```

<< Panasonic KX-P3123 command reference utility (xxxxxxxxxx) >>
-- SELECT COMMAND-- (EPSON)
=====
FONT SELECTION
ESC+X+n      Selects print quality
ESC+k+n      Selects print font style
ESC+S+1      Selects subscript printing
ESC+S'+0     Selects superscript printing
ESC+T        Releases sub/superscript printing

CHARACTER PITCH SELECTION
ESC+P        Sets pica pitch (10 cpi) printing
ESC+M        Sets elite pitch (12 cpi) printing
ESC+g        Sets micron (15 cpi) printing
SI           Sets compressed (17 cpi) printing
ESC+SI       Sets compressed (17 cpi) printing
DC2          Releases compressed printing
ESC+p'+1     Sets proportional spacing
=====
[↑]/[↓]      : Select command
[Pg.Up]/[Pg.Down] : Go to previous/next category
[Enter]       : View command description
[Esc]         : SELECT EMULATION mode
[E]           : Exit to DOS
    
```

[↑]/[↓]	Moves the cursor one line up/down
[Pg.Up] / [Pg.Down]	Moves the cursor to the first command of the previous/next item
[Enter]	Displays the explanation of the command
[Esc]	Returns to screen 1
[E]	Exits to DOS

### Note:

- There is a list of proportional spacing tables after the software commands list. If you want to see a proportional spacing table, select your desired table and press **Enter** .

## 8 Press **Enter**.

The screen will show the detailed explanation of the command.

If you want to exit the Command Reference Program, go to step 9.

If you want to print out this explanation, press **Enter** again and press **Y**.

"Y": The explanation will be printed.

"N": The display will return to screen 3.

## 9 Press **E**.

You have exited the Command Reference Program.

### Screen 3

```

<< Panasonic KX-P3123 command reference utility (xxxxxxxxxxxx) >>
[ESC+X+n] Selects print quality [EPSON]
=====
<PRINT QUALITY>
Selects print quality

Name:  ESC    x    n
Dec.:  27    120  n
Hex.:  1B    78   n

Comment:
*The following values of n can be used:
n=0: Draft font
n=1: LQ font
n=2: SLQ mode (Roman 5, 10, 6 and 12 CPI fonts only)
      -- END --
=====
[↑]/[↓]      : Text scroll-down/up
[Pg.Up]/[Pg.Down] : Go to previous/next command
[Esc]        : SELECT COMMAND mode
[Enter]      : Print current command description
    
```

### Screen 4

```

<< Panasonic KX-P3123 command reference utility (xxxxxxxxxxxx) >>
[ESC+X+n] Selects print quality [EPSON]
=====
<PRINT QUALITY>
Selects print quality

Name:  ESC    x    n
Dec.:  27    120  n
Hex.:  1B    78   n

Comment:
*The following values of n can be used:
n=0: Draft font
n=1: LQ font
n=2: SLQ mode (Roman 5, 10, 6 and 12 CPI fonts only)
      -- END --
=====
Print current command description ? (Y/N)
      YES          NO
    
```

[↑]/[↓]	Scrolls the text one line down/up
[Pg.Up]/[Pg.Down]	Displays the explanation of previous/next command
[Esc]	Returns to screen 2
[Enter]	Prints the detailed explanation of the command
[E]	Exits to DOS

#### Note:

- You can proceed through the Command Reference Program using a computer mouse or your keyboard. Highlight the desired item and click the left mouse button, or follow the directions on your screen for keyboard operation.


# Periodic Maintenance

The printer does not require any routine maintenance. However, reasonable care of the printer will extend its life. The following periodic measures are recommended:

- Cleaning the unit is the most important operation the user can perform. The frequency of cleaning is dependent upon the environment.
  - Turn the power off.
  - Clean the case and covers with a soft cloth. Use any mild commercial cleaner on the cloth, do not spray directly on to the printer.
  - Remove the top and the smoked plastic covers. Vacuum or dust the inside area of the unit. Be very careful not to damage the printhead ribbon cable or the carriage drive belt.
  - The platen should be cleaned with denatured alcohol only.
  - The carriage guide bar can be lubricated with a very light oil. Contact your authorized Panasonic Service Center for advice on lubrication.

## Ribbon Cassette

A single ribbon permits the printing of approximately 3 million total draft characters. When the printing starts to fade, gently push the counter spring in the ribbon cassette hole with the tip of a ballpoint pen or other object. Once the ribbon cassette is mounted onto the carriage and printing is performed for a short time, the characters will become darker.



### Note:

- Do not re-ink the ribbon until printing starts to fade. If the ribbon has too much ink, the characters may smear when printed.
- If the ribbon begins to catch, snag, or tear from the printhead, your printer requires servicing.

## Self Test

After re-inking the ribbon, to make sure that the characters are no longer smearing, you may perform steps 1~3 of "Self Test". (P. 35)

# Troubleshooting

Most problems associated with the printer can be traced to improper setup, installation, or cabling. The following table 5.1 will assist the user in identifying and correcting some of the more common problems. If you need additional help, contact the store from which the unit was purchased.

Table 5.1 — Troubleshooting

Symptom	Possible Cause	Probable Solution
Ink smears	Head gap lever is not in the proper position	Move the lever toward the (+) position until ink does not smear ( P. 13)
Printout is faint	Head gap lever is not in the proper position	Set the lever to the proper position ( P. 13)
Carriage moves but there is no printing	Ribbon is not installed correctly	Re-insert ribbon ( P. 15)
	Head gap lever is not in proper position	Set the lever to the proper position ( P. 13)
Paper out detector inoperative	P.O. Disable	Set P.O. Enable ( P. 55, 63)
Printer does not power up	No AC power	Check power cord ( P. 13)
Power is on but printer does not print	Printer is not ON LINE	Press ON LINE switch
	Interface cable is not properly connected	Secure connection ( P. 14)
	Out of paper	Install new paper ( Note on next page)
	Printhead has become overheated	Allow the printhead some time to cool down. The printer will automatically resume printing
Carriage stops moving, all indicators start blinking	Path of printhead is blocked	Turn the power off. Clear the path then turn the power back on to resume printing
Paper wrinkles when using tractor feed	No reverse tension on paper	Set paper supply lower than printer
	Selector switch is in " " position	Set selector to " " position
Printer cannot load single sheet in Friction mode	Cut sheet feeder is Enable	Set cut sheet feeder to Disable when not using the cut sheet feeder ( P. 55, 63)
	Paper feed selector is in " " position	Set selector to " " position
Cut sheet feeder does not work	Cut sheet feeder is Disable	Set cut sheet feeder to Enable ( P. 55)
	Paper feed selector is in the " " position	Set paper feed selector to the " " position
Unexpected characters appear in printing	Emulation is set incorrectly	Check printer software pack emulation accord ( P. 32)
Printout is double-spaced	Auto LF is ON	Set Auto LF to C ( P. 55, 63)

(Continued)



Symptom	Possible Cause	Probable Solution
Keeps printing on the same line	Computer is not sending a LF command	Set Auto LF to ON (☞ P. 55, 63)
Cannot change form length	Cut sheet feeder is Enable	Set cut sheet feeder in Disable (☞ P. 55, 63)
Cannot print ASCII characters with code above 127	Data length is set incorrectly	Set data length as required (☞ P. 55, 63)
Wrong character set is printed	Wrong character set is selected	Set the character set as required (☞ P. 55, 62)
Cannot change print mode from computer	FONT and PITCH modes are set incorrectly	Set to PROGRAM mode (☞ P. 62)
Fanfold paper is jamming	Paper not installed correctly in tractors	Set selector switch to " <input type="checkbox"/> " position to easily remove jammed paper Reinstall paper correctly into the tractors (☞ P. 21~31)
*Printer does not print in color	Color kit (KX-PCK11) is not installed	Install the color kit (KX-PCK11)
	Incorrect emulation is set	Select proper printer driver in your software (☞ P. 32)
*Prints in 2 different colors	Yellow color gap lever of color kit is not in the proper position	Set color gap lever of color kit to the proper position (☞ "Color Adjustment" in the color kit installation manual) Reinstall the color kit (☞ "Installing the Color Kit" in the color kit installation manual)

(\* Option)

**Note:**

- Your printer has a paper out detector. When an out of paper condition occurs, printing stops, the printer goes to the OFF LINE mode, and the PAPER OUT light starts blinking. To continue printing to the end of the current page, follow the steps below.
  - ① Press **ON LINE** repeatedly until the page is completed.
  - ② Install the new paper.
  - ③ Press **ON LINE**.
- The paper out detector can be disabled through the initial setup mode.

# Printer Specifications

Power requirements:	Refer to the nameplate located on the rear of the printer.																						
Frequency:																							
Current:																							
Interface:	Centronics parallel RS-232C/Serial interface board [KX-PS14, KX-PS13] (option)																						
Print fonts:	3 Draft (Pica, Elite, Micron) 6 Letter Quality (Courier, Bold PS, Prestige Elite, Sans Serif, Script, Roman) 1 Super Letter Quality (Roman) 4 Scalable Font (Roman, Courier, Prestige, Sans Serif)																						
Software emulation:	Epson LQ-570 IBM Proprinter X24E																						
Buffer:	46K (standard)																						
Character sets:	96 ASCII characters, ITALIC 33 International characters (14 countries + LEGAL Set no Science) 158 (IBM-PC special characters 38 Multilingual characters																						
Dot configuration:	<table border="0"> <tr> <td></td> <td><b>Draft</b></td> <td><b>LQ</b></td> <td><b>SLQ</b></td> </tr> <tr> <td><b>Matrix</b> (Hor. × Ver)</td> <td>9 × 24</td> <td>30 × 24</td> <td>30 × 48</td> </tr> <tr> <td><b>Dot pitch</b> (Hor.)</td> <td>1/120" (0.21 mm)</td> <td>1/360" (0.07 mm)</td> <td>1/360" (0.07 mm)</td> </tr> <tr> <td>(Ver.)</td> <td>1/180" (0.14 mm)</td> <td>1/180" (0.14 mm)</td> <td>1/360" (0.07 mm)</td> </tr> </table>					<b>Draft</b>	<b>LQ</b>	<b>SLQ</b>	<b>Matrix</b> (Hor. × Ver)	9 × 24	30 × 24	30 × 48	<b>Dot pitch</b> (Hor.)	1/120" (0.21 mm)	1/360" (0.07 mm)	1/360" (0.07 mm)	(Ver.)	1/180" (0.14 mm)	1/180" (0.14 mm)	1/360" (0.07 mm)			
	<b>Draft</b>	<b>LQ</b>	<b>SLQ</b>																				
<b>Matrix</b> (Hor. × Ver)	9 × 24	30 × 24	30 × 48																				
<b>Dot pitch</b> (Hor.)	1/120" (0.21 mm)	1/360" (0.07 mm)	1/360" (0.07 mm)																				
(Ver.)	1/180" (0.14 mm)	1/180" (0.14 mm)	1/360" (0.07 mm)																				
Maximum number of characters per line (cpl):	<table border="0"> <tr> <td>Pica [10 cpi (characters per inch)]</td> <td>80 cpl</td> </tr> <tr> <td>Elite (12 cpi)</td> <td>96 cpl</td> </tr> <tr> <td>Micron (15 cpi)</td> <td>120 cpl</td> </tr> <tr> <td>Compressed (17 cpi)</td> <td>137 cpl</td> </tr> <tr> <td>Elite compressed (20 cpi)</td> <td>160 cpl</td> </tr> <tr> <td>Pica elongated (5 cpi)</td> <td>40 cpl</td> </tr> <tr> <td>Elite elongated (6 cpi)</td> <td>48 cpl</td> </tr> <tr> <td>Micron elongated (7.5 cpi)</td> <td>60 cpl</td> </tr> <tr> <td>Compressed elongated (8.5 cpi)</td> <td>68 cpl</td> </tr> <tr> <td>Elite compressed elongated (10 cpi)</td> <td>80 cpl</td> </tr> </table>			Pica [10 cpi (characters per inch)]	80 cpl	Elite (12 cpi)	96 cpl	Micron (15 cpi)	120 cpl	Compressed (17 cpi)	137 cpl	Elite compressed (20 cpi)	160 cpl	Pica elongated (5 cpi)	40 cpl	Elite elongated (6 cpi)	48 cpl	Micron elongated (7.5 cpi)	60 cpl	Compressed elongated (8.5 cpi)	68 cpl	Elite compressed elongated (10 cpi)	80 cpl
Pica [10 cpi (characters per inch)]	80 cpl																						
Elite (12 cpi)	96 cpl																						
Micron (15 cpi)	120 cpl																						
Compressed (17 cpi)	137 cpl																						
Elite compressed (20 cpi)	160 cpl																						
Pica elongated (5 cpi)	40 cpl																						
Elite elongated (6 cpi)	48 cpl																						
Micron elongated (7.5 cpi)	60 cpl																						
Compressed elongated (8.5 cpi)	68 cpl																						
Elite compressed elongated (10 cpi)	80 cpl																						
Printing speed [characters per second (cps)]: With Black Ribbon	<table border="0"> <tr> <td></td> <td><b>Micron</b></td> <td><b>Elite</b></td> <td><b>Pica</b></td> </tr> <tr> <td><b>Draft</b></td> <td>240 cps</td> <td>192 cps</td> <td>160 cps</td> </tr> <tr> <td><b>LQ</b></td> <td>80 cps</td> <td>64 cps</td> <td>53 cps</td> </tr> <tr> <td><b>SLQ</b></td> <td></td> <td>32 cps</td> <td>26 cps</td> </tr> </table>				<b>Micron</b>	<b>Elite</b>	<b>Pica</b>	<b>Draft</b>	240 cps	192 cps	160 cps	<b>LQ</b>	80 cps	64 cps	53 cps	<b>SLQ</b>		32 cps	26 cps				
	<b>Micron</b>	<b>Elite</b>	<b>Pica</b>																				
<b>Draft</b>	240 cps	192 cps	160 cps																				
<b>LQ</b>	80 cps	64 cps	53 cps																				
<b>SLQ</b>		32 cps	26 cps																				
Printing direction:	Bi-directional character & graphics Uni-directional character & graphics ..... Color printing																						
Line feed time:	Approx. 100 msec [with 1/6 inch (4.2 mm) line feeding]																						
Paper feed:	Pull/Push tractor feed (with fanfold paper) (user selectable) Friction feed (with single sheets or envelopes)																						

(Continued)

# Printer Specifications

Operating environment:	Temperature: 10°C~35°C (50°F~95°F) Humidity: 30~80% RH (Please allow the printer to stabilize at room temperature within the operating temperature range before operation)
Power consumption:	MAX — 150 W Stand by — 11 W Self Test — 49 W
Storage environment:	Temperature: -20°C~60°C (-4°F~140°F) Humidity: 10~90% RH
Head service life:	Black ribbon: Approx. 200 million strokes in DRAFT mode Color ribbon: Approx. 100 million strokes in DRAFT mode
Ribbon:	Cassette seamless fabric ribbon Black ribbon cassette KX-P150: Life expectancy (in DRAFT mode) (rolling ASCII) Approx. 3 million characters Color ribbon cassette KX-P150C (option): Life expectancy (in DRAFT mode) (rolling ASCII) Black: Approx. 0.7 million characters Red (Magenta)/Blue (Cyan): Approx. 0.7 million characters Yellow: Approx. 0.4 million characters
Detectors:	Paper out detector Overheat detector Overload detector
Dimensions:	459 (W) × 365 (D) × 149 (H) mm {18.1" × 14.3" × 5.8"}
Mass {Weight}:	Approx. 8.6 kg {19 lbs}

# Paper Specifications

Paper which may be used with this unit must be within the specifications provided below.

## Fanfold Paper

Width: 4 ~ 10 inches (102 ~ 254 mm)

Quality and number of sheets:

Type of paper	Sheets	Weight			
		lbs		g/m <sup>2</sup>	
		push	pull	push	pull
Fine-quality paper	1	16 ~ 24	16 ~ 22	60 ~ 90	60 ~ 82.5
Non-carbon	2 ~ 4	11 ~ 14 (17*)		41 ~ 53 (64*)	
Multi-layered with carbon	2	11 ~ 14 (17*)		41 ~ 53 (64*)	

(\* only for the last sheet)

**Note:**

- When using multi-part fanfold paper especially in environments that have very high or low temperature and/or humidity, we recommend the use of the bottom feed pull mode to optimize paper handling and print quality.
- To insure optimum print quality, 16 ~ 22 lbs (60 ~ 82.5 g/m<sup>2</sup>) is recommended for graphic printing.
- In multi-layered paper with carbon, the carbon is equivalent to a sheet of paper.
- "Weight in pounds" represents the weight of 500 [17x22 inches (432x559 mm)] sheets.
- The printer will handle multipart papers up to 0.013 inch (0.32 mm) thick. Up to 4 copies of 14 lb. chemical release paper can be used.
- Multipart forms consisting of 2 parts may be used for rear feeding (Push mode). For 3 or 4 part forms, we recommend bottom feeding for optimum print quality.

## Single Sheets

Width: 4 ~ 11.7 inches (102 ~ 297 mm)

Height: 5 ~ 14.3 inches (127 ~ 363 mm)

Weight in pounds (g/m<sup>2</sup>): 14 ~ 24 lbs (53 ~ 90 g/m<sup>2</sup>)

**Note:**

- Paper should be within operating temperature and humidity ranges at least 24 hours prior to use.

## Envelopes


#6 and #10 size envelopes are recommended. Since envelopes vary in size, paper weight and construction, we cannot guarantee print quality and paper handling for all types of envelopes.

**Note:**

- To optimize print quality, printing should not occur in areas where the edges overlap.

## Printing Area

### Fanfold Paper



	Push	Pull
<b>A</b>	1" (25.4 mm)	
<b>B</b>	0.7" (17.8 mm)	
<b>C</b>	0.6" (15.2 mm)	5.4" (137 mm)
<b>D</b>	1" (25.4 mm)	


**A:** Value A indicates the area near the paper perforations where the quality may not be optimum.

**B:** Value B indicates the minimum distance between the sprockets and first printable character. (When the left tractor is set on the left end and the margin is set to 0.)

**C:** Value C indicates the area from the top edge of the paper to the top of the first printed character.

**D:** Value D indicates the position where paper out is detected and printing may not be optimum.

### Single Sheets and Envelopes



	Single Sheets and Envelopes
<b>B</b>	1.5" (38 mm)
<b>C</b>	0.6" (15.2 mm)
<b>D</b>	1" (25.4 mm)

**B:** Value B indicates the minimum distance between the edge of the paper and the first printable character. (When the left paper guide is set to the left end and the margin is set to 0.)

**C:** Value C indicates the area from the top edge of the paper to the top of the first printed character.

**D:** Value D indicates the position where paper out is detected and printing may not be optimum. (When printing on envelopes, do not print on area where edges overlap. Print quality may not be optimum.)

# Interfacing

## Parallel Interfacing

A method of transferring data from a computer to a printer through a parallel interface based on the centronics standard.


### Specifications:

- data transfer speed: 1000 cps minimum
- synchronization: external STROBE pulse
- logic levels: TTL (Transistor-Transistor-Logic) levels
- handshaking: BUSY and  $\overline{\text{ACK}}$  signals
- connector type: 57-30360 (AMPHENOL) or equivalent
- cable: use a shielded cable (6'5"/1.95 meters) or less in length.

When the printer is processing data, the BUSY signal is high. The printer will not accept new data from the computer. After the processing is completed, the BUSY signal goes low. (The BUSY signal is also high when the printer is OFF LINE). When the BUSY signal occurs, the  $\overline{\text{ACK}}$  signal goes low indicating to the computer that the data has been processed and the printer is ready to accept more data. This handshaking routine occurs each time a character is sent to the printer.

	BUSY	SLCT	PO	ERROR
<b>ON LINE</b>	LOW	HIGH	LOW	HIGH
<b>OFF LINE</b>	HIGH	LOW	LOW	LOW
<b>PAPER OUT</b>	HIGH	LOW	HIGH	LOW

Printer status signals



Parallel interface connector (printer side)

Signal pin	Return side pin	Signal	Direction
1	19	$\overline{\text{STB}}$	Input
2	20	DATA 1	
3	21	DATA 2	
4	22	DATA 3	
5	23	DATA 4	
6	24	DATA 5	
7	25	DATA 6	
8	26	DATA 7	
9	27	DATA 8	
10	28	$\overline{\text{ACK}}$	Output
11	29	BUSY	
12		PO	

Signal pin	Return side pin	Signal	Direction
13		SLCT	Output
14		$\overline{\text{AUTO FEED XT}}$	Input
15			
16		SG	
17		FG	
18		+5 V	Output
31	30	$\overline{\text{PRIME}}$	Input
32		$\overline{\text{ERROR}}$	Output
33		SG	
34			
35			
36			

Pin configuration (Parallel)

## Connector Pin Signals

### $\overline{\text{STB}}$ ...STROBE

- This is a synchronizing input signal to read data into the printer.
- This signal is normally high. Data is read in when it is low.

### DATA1-DATA8

- These are the input signals which carry the 8 data bits of information.
- The signal is read in synchronization with the STROBE pulse. A high level indicates a logical "1".

### $\overline{\text{ACK}}$ ...ACKNOWLEDGE

- This is an output signal to the computer indicating that the printer is ready to receive the next data. When the condition becomes true, the signal goes low.
- The  $\overline{\text{ACK}}$  signal is automatically sent whenever the printer is switched ON LINE and the BUSY signal drops from high to low.

### BUSY

- This output signal indicates the status on which the printer cannot receive data.
- The signal is high under the following conditions:
  1. receive buffer full
  2. printer is processing data
  3. printer is OFF LINE
  4. printer is in an error condition

### PO...PAPER OUT

- This output signal indicates the absence of paper and goes high during a "Paper Out" condition.

### SLCT...SELECT

- This output signal is high in the ON LINE mode and low when OFF LINE.
- The printer enters the ON LINE mode:
  1. When the printer is turned on
  2. when PRIME is received
  3. when the RESET command is received
  4. when the ON LINE switch is pressed
- The printer enters the OFF LINE mode:
  1. when the printer is out of paper
  2. when the printer is switched OFF LINE

### $\overline{\text{AUTO FEED XT}}$ ( $\overline{\text{AFXT}}$ )

- While this input signal is low, one line feed (LF) command will be added to each carriage return (CR).
- Auto LF setting in the FUNCTION mode can alter the response by the printer to an  $\overline{\text{AFXT}}$  signal. If auto LF is ON, the printer will perform a CR+LF regardless of the level of the  $\overline{\text{AFXT}}$  signal. When auto LF is OFF, automatic action is disabled.

## SG...SIGNAL GROUND

- The twisted pair return wires (pins 19–30) are connected to signal ground.

## FG...FRAME GROUND

- Frame ground is the same as chassis ground.

## +5V

- This is for evaluation only. It should not be used to supply power for external equipment.


## PRIME

- This input signal is normally high and goes low to reset the printer. It can be received anytime during printer operation.

## ERROR

- This output signal is normally high, and goes low when an error occurs. An error condition can be caused by:
  1. A "Paper Out" condition
  2. The printer is OFF LINE
  3. An overload condition exists

### Timing Chart (When normal printing code is received)



- T1...0.5  $\mu$ s (Min)
- T2...1  $\mu$ s (Min)
- T3...0.5  $\mu$ s (Min)
- T4...5  $\mu$ s (Max)
- T5...1 ms or less when buffer is not full  
1 s or less when buffer is full

Timing diagram



# Initialization

The printer is initialized under the following conditions:

- the AC power is turned on
- the  $\overline{\text{PRIME}}$  signal is received
- the RESET PRINTER command is received
- the clear buffer function is used


When the printer is initialized, the following conditions are set:

- the print buffer is cleared
- the receive buffer is cleared (not cleared by RESET PRINTER command)
- the download character buffer is cleared (not cleared by  $\overline{\text{PRIME}}$  signal in IBM Proprinter X24E mode or by RESET PRINTER command)
- the initial setup modes are read and set
- horizontal tabs are set every 8 columns
- vertical tab settings are cleared
- all modes set by control and escape commands will be cleared
- present form position is designated as Top of Form
- the self test mode is cleared
- the control panel settings are read and set
- control panel settings are not changed by  $\overline{\text{PRIME}}$  signal or RESET PRINTER command\*
- the printhead goes to the home position


\* Some software packages send  $\overline{\text{PRIME}}$  signal at the beginning of their programs. Print modes set by the control panel will not change.

## User Clear Function


This function initializes the printer from the control panel. This feature is very useful when you want to clear the receive buffer (information recently sent from the computer and is currently printing) without changing the control panel.



Press **ON LINE** to stop the printing and enter the OFF LINE mode.



While pressing **FUNCTION**, press **LF** to clear the data in the receive buffer.




Press **ON LINE** to re-enter the ON LINE mode.

# Hex Dump


In this mode, all data received from the computer is printed in hex code instead of the normal ASCII characters. Function codes for the printer (CR, LF, HT, etc.) are not executed. This mode is very useful to debug programs.

## To Enter the Hex Dump Mode:



While pressing both **LF** and **FF** , turn the **power on**.

## To Release the Hex Dump Mode:



Turn the **power off**, then back on.

# Character Set Tables

## Epson Italic Character Set (USA) PC-437

Dec.	0	16	32	48	64	80	96	112	128	144	160	176	192	208	224	240
Hex.	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
0	0	NUL	SP	0	⊙	P	·	p		SP	0	⊙	P	·	p	
1	1	DC1	!	1	A	Q	a	q		DC1	!	1	A	Q	a	q
2	2	DC2	²	2	B	R	b	r		DC2	²	2	B	R	b	r
3	3	DC3	#	3	C	S	c	s		DC3	#	3	C	S	c	s
4	4	DC4	\$	4	D	T	d	t		DC4	\$	4	D	T	d	t
5	5		%	5	E	U	e	u		%	5	E	U	e	u	
6	6		&	6	F	V	f	v		&	6	F	V	f	v	
7	7	BEL		7	G	W	g	w		BEL		7	G	W	g	w
8	8	BS CAN	(	8	H	X	h	x		BS CAN	(	8	H	X	h	x
9	9	HT EM	)	9	I	Y	i	y		HT EM	)	9	I	Y	i	y
10	A	LF	.	:	J	Z	j	z		LF	.	:	J	Z	j	z
11	B	VT ESC	+	:	K	[	k	{		VT ESC	+	:	K	[	k	{
12	C	FF	.	<	L	\	l			FF	.	<	L	\	l	
13	D	CR	-	=	M	]	m	}		CR	-	=	M	]	m	}
14	E	SO	.	>	N	^	n	~		SO	.	>	N	^	n	~
15	F	SI	/	?	O	_	o	DEL		SI	/	?	O	_	o	NUL

## Epson Graphic Character Set 2 (USA)

Dec.	0	16	32	48	64	80	96	112	128	144	160	176	192	208	224	240
Hex.	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
0	0	NUL	SP	0	⊙	P	·	p	Ç	É	á	☼	L	ll	α	≡
1	1	DC1	!	1	A	Q	a	q	ú	æ	í	☼	L	ll	β	±
2	2	DC2	²	2	B	R	b	r	ê	Æ	ó	☼	L	ll	Γ	≥
3	3	DC3	#	3	C	S	c	s	à	ò	ú	☼	L	ll	π	≤
4	4	DC4	\$	4	D	T	d	t	á	ó	ñ	☼	L	ll	Σ	∫
5	5		%	5	E	U	e	u	à	ò	Ñ	☼	L	ll	σ	∫
6	6		&	6	F	V	f	v	á	ó	á	☼	L	ll	μ	±
7	7	BEL		7	G	W	g	w	ç	ú	ø	☼	L	ll	τ	≡
8	8	BS CAN	(	8	H	X	h	x	ê	ÿ	¿	☼	L	ll	Φ	·
9	9	HT EM	)	9	I	Y	i	y	ë	Ö	☼	☼	L	ll	θ	·
10	A	LF	.	:	J	Z	j	z	è	Ü	☼	☼	L	ll	Ω	·
11	B	VT ESC	+	:	K	[	k	{	í	¼	½	☼	L	ll	δ	√
12	C	FF	.	<	L	\	l		í	¼	½	☼	L	ll	∞	°
13	D	CR	-	=	M	]	m	}	í	¼	½	☼	L	ll	ø	?
14	E	SO	.	>	N	^	n	~	Ä	Pr	<<	☼	L	ll	ε	■
15	F	SI	/	?	O	_	o	DEL	Ä	f	>>	☼	L	ll	∩	SP

**Note:**

- Set 1 is the same one which 80H~9FH is switched to 00H~1FH.

## Epson Character Set 2 (Multilingual) PC-850

Dec.	0	16	32	48	64	80	96	112	128	144	160	176	192	208	224	240
Hex.	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
0	0	NUL	SP	0	⊙	P	·	p	Ç	É	á	☼	L	ll	Ó	-
1	1	DC1	!	1	A	Q	a	q	ú	æ	í	☼	L	ll	β	±
2	2	DC2	²	2	B	R	b	r	ê	Æ	ó	☼	L	ll	Γ	≥
3	3	DC3	#	3	C	S	c	s	à	ò	ú	☼	L	ll	π	≤
4	4	DC4	\$	4	D	T	d	t	á	ó	ñ	☼	L	ll	Σ	∫
5	5		%	5	E	U	e	u	à	ò	Ñ	Ä	L	ll	σ	∫
6	6		&	6	F	V	f	v	á	ó	á	Ä	L	ll	μ	±
7	7	BEL		7	G	W	g	w	ç	ú	ø	Ä	L	ll	τ	≡
8	8	BS CAN	(	8	H	X	h	x	ê	ÿ	¿	☼	L	ll	Φ	·
9	9	HT EM	)	9	I	Y	i	y	ë	Ö	☼	☼	L	ll	θ	·
10	A	LF	.	:	J	Z	j	z	è	Ü	☼	☼	L	ll	Ω	·
11	B	VT ESC	+	:	K	[	k	{	í	¼	½	☼	L	ll	δ	√
12	C	FF	.	<	L	\	l		í	¼	½	☼	L	ll	∞	°
13	D	CR	-	=	M	]	m	}	í	¼	½	☼	L	ll	ø	?
14	E	SO	.	>	N	^	n	~	Ä	x	<<	☼	L	ll	ε	■
15	F	SI	/	?	O	_	o	DEL	Ä	f	>>	☼	L	ll	∩	SP

## Epson Character Set 2 (Portugal) PC-860

Dec.	0	16	32	48	64	80	96	112	128	144	160	176	192	208	224	240
Hex.	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
0	0	NUL	SP	0	⊙	P	·	p	Ç	É	á	☼	L	ll	α	≡
1	1	DC1	!	1	A	Q	a	q	ú	Ä	í	☼	L	ll	β	±
2	2	DC2	²	2	B	R	b	r	ê	Ê	ó	☼	L	ll	Γ	≥
3	3	DC3	#	3	C	S	c	s	à	ò	ú	☼	L	ll	π	≤
4	4	DC4	\$	4	D	T	d	t	á	ó	ñ	☼	L	ll	Σ	∫
5	5		%	5	E	U	e	u	à	ò	Ñ	☼	L	ll	σ	∫
6	6		&	6	F	V	f	v	á	ó	á	☼	L	ll	μ	±
7	7	BEL		7	G	W	g	w	ç	ú	ø	☼	L	ll	τ	≡
8	8	BS CAN	(	8	H	X	h	x	ê	ÿ	¿	☼	L	ll	Φ	·
9	9	HT EM	)	9	I	Y	i	y	ë	Ö	☼	☼	L	ll	θ	·
10	A	LF	.	:	J	Z	j	z	è	Ü	☼	☼	L	ll	Ω	·
11	B	VT ESC	+	:	K	[	k	{	í	¼	½	☼	L	ll	δ	√
12	C	FF	.	<	L	\	l		í	¼	½	☼	L	ll	∞	°
13	D	CR	-	=	M	]	m	}	í	¼	½	☼	L	ll	ø	?
14	E	SO	.	>	N	^	n	~	Ä	Pr	<<	☼	L	ll	ε	■
15	F	SI	/	?	O	_	o	DEL	Ä	f	>>	☼	L	ll	∩	SP

**Note:**

- Set 1 is the same one which 80H~9FH is switched to 00H~1FH.

# Character Set Tables

## Epson Character Set 2 (Canada-French) PC-863

Dec.	0	16	32	48	64	80	96	112	128	144	160	176	192	208	224	240
Hex.	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
0	0	NUL		SP	0	⊙	P	·	p	Ç	É	Ì	⋮	⋮	α	≡
1	1	DC1	!	1	A	Q	a	q	û	Ë	·	⋮	⋮	β	±	
2	2	DC2	"	2	B	R	b	r	é	Æ	ó	⋮	⋮	Γ	≥	
3	3	DC3	#	3	C	S	c	s	à	ò	ù	⋮	⋮	π	≤	
4	4	DC4	\$	4	D	T	d	t	â	ê	·	⋮	⋮	Σ	∫	
5	5		%	5	E	U	e	u	â	ô	ñ	⋮	⋮	σ	∫	
6	6		&	6	F	V	f	v	â	ô	ñ	⋮	⋮	μ	÷	
7	7	BEL	'	7	G	W	g	w	ç	ü	·	⋮	⋮	τ	≡	
8	8	BS CAN	(	8	H	X	h	x	â	ô	ï	⋮	⋮	φ	·	
9	9	HT EM	)	9	I	Y	i	y	ê	ô	·	⋮	⋮	θ	·	
10	A	LF	*	:	J	Z	j	z	ê	ú	·	⋮	⋮	Ω	·	
11	B	VT ESC	+	:	K	[	k	[	ï	ç	½	⋮	⋮	δ	√	
12	C	FF	,	<	L	\	l	\	ï	ç	½	⋮	⋮	∞	°	
13	D	CR	-	=	M	]	m	]	ï	ç	½	⋮	⋮	ø	²	
14	E	SO	.	>	N	^	n	^	À	Ù	<<	⋮	⋮	ε	■	
15	F	SI	/	?	O	_	o	_	À	Ù	>>	⋮	⋮	∩	SP	

## Epson Character Set 2 (Norway) PC-865

Dec.	0	16	32	48	64	80	96	112	128	144	160	176	192	208	224	240
Hex.	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
0	0	NUL		SP	0	⊙	P	·	p	Ç	É	Ì	⋮	⋮	α	≡
1	1	DC1	!	1	A	Q	a	q	û	Ë	·	⋮	⋮	β	±	
2	2	DC2	"	2	B	R	b	r	é	Æ	ó	⋮	⋮	Γ	≥	
3	3	DC3	#	3	C	S	c	s	à	ò	ù	⋮	⋮	π	≤	
4	4	DC4	\$	4	D	T	d	t	â	ê	·	⋮	⋮	Σ	∫	
5	5		%	5	E	U	e	u	â	ô	ñ	⋮	⋮	σ	∫	
6	6		&	6	F	V	f	v	â	ô	ñ	⋮	⋮	μ	÷	
7	7	BEL	'	7	G	W	g	w	ç	ü	·	⋮	⋮	τ	≡	
8	8	BS CAN	(	8	H	X	h	x	â	ô	ï	⋮	⋮	φ	·	
9	9	HT EM	)	9	I	Y	i	y	ê	ô	·	⋮	⋮	θ	·	
10	A	LF	*	:	J	Z	j	z	ê	ú	·	⋮	⋮	Ω	·	
11	B	VT ESC	+	:	K	[	k	[	ï	ç	½	⋮	⋮	δ	√	
12	C	FF	,	<	L	\	l	\	ï	ç	½	⋮	⋮	∞	°	
13	D	CR	-	=	M	]	m	]	ï	ç	½	⋮	⋮	ø	²	
14	E	SO	.	>	N	^	n	^	À	Ù	<<	⋮	⋮	ε	■	
15	F	SI	/	?	O	_	o	_	À	Ù	>>	⋮	⋮	∩	SP	

**Note:**

- Set 1 is the same one which 80H-9FH is switched to 00H-1FH.

## Epson Character Set 2 (Turkey) PC-853

Dec.	0	16	32	48	64	80	96	112	128	144	160	176	192	208	224	240
Hex.	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
0	0	NUL		SP	0	⊙	P	·	p	Ç	É	Ì	⋮	⋮	α	≡
1	1	DC1	!	1	A	Q	a	q	û	Ë	·	⋮	⋮	β	±	
2	2	DC2	"	2	B	R	b	r	é	Æ	ó	⋮	⋮	Γ	≥	
3	3	DC3	#	3	C	S	c	s	à	ò	ù	⋮	⋮	π	≤	
4	4	DC4	\$	4	D	T	d	t	â	ê	·	⋮	⋮	Σ	∫	
5	5		%	5	E	U	e	u	â	ô	ñ	⋮	⋮	σ	∫	
6	6		&	6	F	V	f	v	â	ô	ñ	⋮	⋮	μ	÷	
7	7	BEL	'	7	G	W	g	w	ç	ü	·	⋮	⋮	τ	≡	
8	8	BS CAN	(	8	H	X	h	x	â	ô	ï	⋮	⋮	φ	·	
9	9	HT EM	)	9	I	Y	i	y	ê	ô	·	⋮	⋮	θ	·	
10	A	LF	*	:	J	Z	j	z	ê	ú	·	⋮	⋮	Ω	·	
11	B	VT ESC	+	:	K	[	k	[	ï	ç	½	⋮	⋮	δ	√	
12	C	FF	,	<	L	\	l	\	ï	ç	½	⋮	⋮	∞	°	
13	D	CR	-	=	M	]	m	]	ï	ç	½	⋮	⋮	ø	²	
14	E	SO	.	>	N	^	n	^	À	Ù	<<	⋮	⋮	ε	■	
15	F	SI	/	?	O	_	o	_	DEL	À	Ù	>>	⋮	⋮	∩	SP

**Note:**

- Set 1 is the same one which 03H-06H and 15H are switched to NUL, and 80H-9FH is switched to 00H-1FH.

## IBM Character Set 2 (USA)

Dec.	0	16	32	48	64	80	96	112	128	144	160	176	192	208	224	240	
Hex.	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F	
0	0	NUL		SP	0	@	P	'	p	Ç	É	á		L	ll	α	■
1	1		DC1		1	A	Q	a	q	ü	æ	í		T	T	β	±
2	2		DC2	*	2	B	R	b	r	é	Æ	ó		T	T	Γ	≥
3	3	▼		#	3	C	S	c	s	â	ô	ú		T	T	π	≤
4	4	♦	DC4	\$	4	D	T	d	t	á	ò	ñ	-	-	E	Σ	J
5	5	▲	§	%	5	E	U	e	u	à	ò	Ñ	=	F	F	σ	J
6	6	▲		&	6	F	V	f	v	á	ó	á		T	T	μ	+
7	7	BEL		'	7	G	W	g	w	ç	ú	ø		T	T	τ	-
8	8	BS		(	8	H	X	h	x	ê	ÿ	¿		T	T	Φ	*
9	9	HT		)	9	I	Y	i	y	ë	Ö			T	T	θ	*
10	A	LF		.	:	J	Z	j	z	è	Ü			T	T	Ω	*
11	B	VT	ESC	+	:	K	[	k	{	í	¼	½		T	T	δ	√
12	C	FF		.	<	L	\	l		í	£	½		T	T	∞	°
13	D	CR		-	=	M	]	m	}	ï	¥	í		T	T	σ	?
14	E	SO		.	>	N	^	n	~	Ä	Pl	<<		T	T	ε	■
15	F	SI		/	?	O	_	o	Δ	Ä	f	>>		T	T	∩	SP

**Note:**

- Set 1 is the same one which 03H~06H and 15H are switched to NUL, and 80H~9FH is switched to 00H~1FH.

## IBM All Character Chart (USA)

Dec.	0	16	32	48	64	80	96	112	128	144	160	176	192	208	224	240	
Hex.	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F	
0	0	Ø	▶	SP	0	@	P	'	p	Ç	É	á		L	ll	α	■
1	1	◊	◀		1	A	Q	a	q	ü	æ	í		T	T	β	±
2	2	•	↑	*	2	B	R	b	r	é	Æ	ó		T	T	Γ	≥
3	3	▼		#	3	C	S	c	s	â	ô	ú		T	T	π	≤
4	4	♦	¶	\$	4	D	T	d	t	á	ò	ñ	-	-	E	Σ	J
5	5	▲	§	%	5	E	U	e	u	à	ò	Ñ	=	F	F	σ	J
6	6	▲	-	&	6	F	V	f	v	á	ó	á		T	T	μ	+
7	7	•	↑	'	7	G	W	g	w	ç	ú	ø		T	T	τ	-
8	8	◻	↑	(	8	H	X	h	x	ê	ÿ	¿		T	T	Φ	*
9	9	◊	↓	)	9	I	Y	i	y	ë	Ö			T	T	θ	*
10	A	◻	→	.	:	J	Z	j	z	è	Ü			T	T	Ω	*
11	B	◊	←	+	:	K	[	k	{	í	¼	½		T	T	δ	√
12	C	◊	L	.	<	L	\	l		í	£	½		T	T	∞	°
13	D	◊	↔	-	=	M	]	m	}	ï	¥	í		T	T	σ	?
14	E	◊	▲	.	>	N	^	n	~	Ä	Pl	<<		T	T	ε	■
15	F	◊	▼	/	?	O	_	o	Δ	Ä	f	>>		T	T	∩	SP

## IBM Character Set 2 (Multilingual)

Dec.	0	16	32	48	64	80	96	112	128	144	160	176	192	208	224	240	
Hex.	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F	
0	0	NUL		SP	0	@	P	'	p	Ç	É	á		L	ö	Ó	-
1	1		DC1		1	A	Q	a	q	ü	æ	í		T	Ø	β	±
2	2		DC2	*	2	B	R	b	r	é	Æ	ó		T	É	Ö	—
3	3	▼		#	3	C	S	c	s	â	ô	ú		T	É	Ö	‡
4	4	♦	DC4	\$	4	D	T	d	t	á	ò	ñ	-	-	E	ø	¶
5	5	▲	§	%	5	E	U	e	u	à	ò	Ñ	Á	T	i	Ó	§
6	6	▲		&	6	F	V	f	v	á	ó	á	Á	á	í	μ	+
7	7	BEL		'	7	G	W	g	w	ç	ú	ø	Á	Á	í	þ	.
8	8	BS	CAN	(	8	H	X	h	x	ê	ÿ	¿	•	T	i	þ	*
9	9	HT		)	9	I	Y	i	y	ë	Ö	•		T	ü	-	
10	A	LF		.	:	J	Z	j	z	è	Ü			T	ü	*	
11	B	VT	ESC	+	:	K	[	k	{	í	ø	½		T	ü	'	
12	C	FF		.	<	L	\	l		í	£	½		T	ý	»	
13	D	CR		-	=	M	]	m	}	ï	Ø	í	¼		T	ÿ	»
14	E	SO		.	>	N	^	n	~	Ä	x	<<		T	ı	•	■
15	F	SI		/	?	O	_	o	Δ	Ä	f	>>		T	ı	'	SP

**Note:**

- Set 1 is the same one which 03H~06H and 15H are switched to NUL, and 80H~9FH is switched to 00H~1FH.

## IBM All Character (Multilingual)

Dec.	0	16	32	48	64	80	96	112	128	144	160	176	192	208	224	240	
Hex.	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F	
0	0	Ø	▶	SP	0	@	P	'	p	Ç	É	á		L	ö	Ó	-
1	1	◊	◀		1	A	Q	a	q	ü	æ	í		T	Ø	β	±
2	2	•	↑	*	2	B	R	b	r	é	Æ	ó		T	É	Ö	—
3	3	▼		#	3	C	S	c	s	â	ô	ú		T	É	Ö	‡
4	4	♦	¶	\$	4	D	T	d	t	á	ò	ñ	-	-	E	ø	¶
5	5	▲	§	%	5	E	U	e	u	à	ò	Ñ	Á	T	i	Ó	§
6	6	▲	-	&	6	F	V	f	v	á	ó	á	Á	á	í	μ	+
7	7	•	↑	'	7	G	W	g	w	ç	ú	ø	Á	Á	í	þ	.
8	8	◻	↑	(	8	H	X	h	x	ê	ÿ	¿	•	T	i	þ	*
9	9	◊	↓	)	9	I	Y	i	y	ë	Ö	•		T	ü	-	
10	A	◻	→	.	:	J	Z	j	z	è	Ü			T	ü	*	
11	B	◊	←	+	:	K	[	k	{	í	ø	½		T	ü	'	
12	C	◊	L	.	<	L	\	l		í	£	½		T	ý	»	
13	D	◊	↔	-	=	M	]	m	}	ï	Ø	í	¼		T	ÿ	»
14	E	◊	▲	.	>	N	^	n	~	Ä	x	<<		T	ı	•	■
15	F	◊	▼	/	?	O	_	o	Δ	Ä	f	>>		T	ı	'	SP

# Character Set Tables

## IBM Character Set 2 (Portugal)

Dec.			0	16	32	48	64	80	96	112	128	144	160	176	192	208	224	240
	Hex.	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F	
0	0	NUL		SP	0	●	P	.	p	Ç	É	á						
1	1		DC1	!	1	A	Q	a	q	ú	À	í						
2	2		DC2	"	2	B	R	b	r	é	Ê	ó						
3	3	▼		#	3	C	S	c	s	â	ô	û						
4	4	◄	DC4	\$	4	D	T	d	t	ã	õ	ñ						
5	5	▲		%	5	E	U	e	u	ä	ö	ñ						
6	6	▲		&	6	F	V	f	v	Á	Ú	ã						
7	7	BEL		'	7	G	W	g	w	ç	ù	º						
8	8	BS		(	8	H	X	h	x	ê	ï	¿						
9	9	HT		)	9	I	Y	i	y	ê	ó	ô						
10	A	LF		*	:	J	Z	j	z	è	ù							
11	B	VT	ESC	+	:	K	[	k	[	í	ç	½						
12	C	FF		.	<	L	\	l		í	ç	½						
13	D	CR		-	=	M	]	m	]	ì	ú	î						
14	E	SO		.	>	N	^	n	^	Ä	Ö	«						
15	F	SI		/	?	O	_	o	_	Å	Ó	>>						

**Note:**

- Set 1 is the same one which 03H~06H and 15H are switched to NUL, and 80H~9FH is switched to 00H~1FH.

## IBM All Character (Portugal)

Dec.			0	16	32	48	64	80	96	112	128	144	160	176	192	208	224	240
	Hex.	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F	
0	0	◀		SP	0	●	P	.	p	Ç	É	á						
1	1	◀		!	1	A	Q	a	q	ú	À	í						
2	2	◀		"	2	B	R	b	r	é	Ê	ó						
3	3	▼		#	3	C	S	c	s	â	ô	û						
4	4	◄		\$	4	D	T	d	t	ã	õ	ñ						
5	5	▲		%	5	E	U	e	u	ä	ö	ñ						
6	6	▲		&	6	F	V	f	v	Á	Ú	ã						
7	7	◄		'	7	G	W	g	w	ç	ù	º						
8	8	◄		(	8	H	X	h	x	ê	ï	¿						
9	9	◄		)	9	I	Y	i	y	ê	ó	ô						
10	A	◄		*	:	J	Z	j	z	è	ù							
11	B	◄		+	:	K	[	k	[	í	ç	½						
12	C	◄		.	<	L	\	l		í	ç	½						
13	D	◄		-	=	M	]	m	]	ì	ú	î						
14	E	◄		.	>	N	^	n	^	Ä	Ö	«						
15	F	◄		/	?	O	_	o	_	Å	Ó	>>						

## IBM Character Set 2 (Canada-French)

Dec.			0	16	32	48	64	80	96	112	128	144	160	176	192	208	224	240
	Hex.	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F	
0	0	NUL		SP	0	●	P	.	p	Ç	É	í						
1	1		DC1	!	1	A	Q	a	q	ú	È	'						
2	2		DC2	"	2	B	R	b	r	é	Ê	ó						
3	3	▼		#	3	C	S	c	s	â	ô	û						
4	4	◄	DC4	\$	4	D	T	d	t	ã	õ	ñ						
5	5	▲		%	5	E	U	e	u	ä	ö	ñ						
6	6	▲		&	6	F	V	f	v	Á	Ú	ã						
7	7	BEL		'	7	G	W	g	w	ç	ù	º						
8	8	BS		(	8	H	X	h	x	ê	ï	¿						
9	9	HT		)	9	I	Y	i	y	ê	ó	ô						
10	A	LF		*	:	J	Z	j	z	è	ù							
11	B	VT	ESC	+	:	K	[	k	[	í	ç	½						
12	C	FF		.	<	L	\	l		í	ç	½						
13	D	CR		-	=	M	]	m	]	ì	ú	î						
14	E	SO		.	>	N	^	n	^	Ä	Ö	«						
15	F	SI		/	?	O	_	o	_	Å	Ó	>>						

**Note:**

- Set 1 is the same one which 03H~06H and 15H are switched to NUL, and 80H~9FH is switched to 00H~1FH.

## IBM All Character (Canada-French)

Dec.			0	16	32	48	64	80	96	112	128	144	160	176	192	208	224	240
	Hex.	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F	
0	0	◀		SP	0	●	P	.	p	Ç	É	í						
1	1	◀		!	1	A	Q	a	q	ú	È	'						
2	2	◀		"	2	B	R	b	r	é	Ê	ó						
3	3	▼		#	3	C	S	c	s	â	ô	û						
4	4	◄		\$	4	D	T	d	t	ã	õ	ñ						
5	5	▲		%	5	E	U	e	u	ä	ö	ñ						
6	6	▲		&	6	F	V	f	v	Á	Ú	ã						
7	7	◄		'	7	G	W	g	w	ç	ù	º						
8	8	◄		(	8	H	X	h	x	ê	ï	¿						
9	9	◄		)	9	I	Y	i	y	ê	ó	ô						
10	A	◄		*	:	J	Z	j	z	è	ù							
11	B	◄		+	:	K	[	k	[	í	ç	½						
12	C	◄		.	<	L	\	l		í	ç	½						
13	D	◄		-	=	M	]	m	]	ì	ú	î						
14	E	◄		.	>	N	^	n	^	Ä	Ö	«						
15	F	◄		/	?	O	_	o	_	Å	Ó	>>						

IBM Character Set 2 (Norway)

Table with columns Dec. (0-240) and Hex. (0-F). Rows 0-15 show character mappings for IBM Character Set 2 (Norway), including NUL, SP, DC1-4, BEL, BS, HT, LF, VT, FF, CR, SO, SI and various Latin characters.

IBM All Character (Norway)

Table with columns Dec. (0-240) and Hex. (0-F). Rows 0-15 show character mappings for IBM All Character (Norway), including NUL, SP, DC1-4, BEL, BS, HT, LF, VT, FF, CR, SO, SI and various Latin characters, with DEL at the end of row 15.

Note:
• Set 1 is the same one which 03H~06H and 15H are switched to NUL, and 80H~9FH is switched to 00H~1FH.

IBM Character Set 2 (Turkey)

Table with columns Dec. (0-240) and Hex. (0-F). Rows 0-15 show character mappings for IBM Character Set 2 (Turkey), including NUL, SP, DC1-4, BEL, BS, HT, LF, VT, FF, CR, SO, SI and various Latin characters.

IBM All Character (Turkey)

Table with columns Dec. (0-240) and Hex. (0-F). Rows 0-15 show character mappings for IBM All Character (Turkey), including NUL, SP, DC1-4, BEL, BS, HT, LF, VT, FF, CR, SO, SI and various Latin characters.

Note:
• Set 1 is the same one which 03H~06H and 15H are switched to NUL, and 80H~9FH is switched to 00H~1FH.

## International Character Set

	n	35o 23H	36o 24H	64o 40H	91o 5BH	92o 5CH	93o 5DH	94o 5EH	96o 60H	123o 7BH	124o 7CH	125o 7DH	126o 7EH	155o 9BH	157o 9DH
USA	0	#	\$	⊕	[ \ ]	'	'	{   }	~	⊕	¥				
FRANCE	1	#	\$	à	°	ç	§	'	'	é	ù	è	'	⊕	¥
GERMANY	2	#	\$	§	Ä	Ö	Ü	'	'	ä	ö	ü	β	⊕	¥
U.K.	3	£	\$	⊕	[ \ ]	'	'	{   }	-	⊕	¥				
DENMARK I	4	#	\$	⊕	Æ	Ø	Å	'	'	æ	ø	å	-	⊕	⊕
SWEDEN	5	#	□	É	Ä	Ö	Å	Û	é	ä	ö	å	ü	⊕	¥
ITALY	6	#	\$	⊕	°	\	é	'	ù	à	ò	è	ì	⊕	¥
SPAIN I	7	Pt	\$	⊕	ì	Ñ	¿	'	'	ñ	}	-	⊕	¥	
JAPAN	8	#	\$	⊕	[ ¥ ]	'	'	{   }	-	⊕	¥				
NORWAY	9	#	□	É	Æ	Ø	Å	Û	é	æ	ø	å	ü	⊕	⊕
DENMARK II	10	#	\$	É	Æ	Ø	Å	Û	é	æ	ø	å	ü	⊕	⊕
SPAIN II	11	#	\$	á	ì	Ñ	¿	é	'	í	ñ	ó	ú	⊕	¥
LATIN AMERICA	12	#	\$	á	ì	Ñ	¿	é	ü	í	ñ	ó	ú	⊕	¥
KOREA	13	#	\$	⊕	[ ₩ ]	'	'	{   }	-	⊕	¥				
LEGAL	64	#	\$	§	°	'	"	¶	'	©	®	†	™	⊕	¥


\*1
\*2

**Note:**

- \*1 These characters can be changed only in the Epson mode. In the IBM mode, International Character Set is set to USA and it cannot be changed.
- \*2 These characters are effective in Graphic Character Set 2 of both the Epson and IBM modes.



- AGM (Alternate Graphics Mode):** **AGM** will allow you to select Epson graphics while in the IBM mode.
- ASCII:** "ASCII" is an acronym for "American Standard Code for Information Interchange". In ASCII, each character has a unique code.
- BASIC:** BASIC is a commonly used microcomputer programming language.
- Baud (baud rate):** Baud is a unit of data transmission speed between computer devices. Can be but not necessarily equal to bits per second.
- Bidirectional printing:** Processing speed is increased by bidirectional printing. That is, the printer prints right-to-left as well as in the normal left-to-right manner.
- Binary:** Binary is a numbering system using the two digits of zero (0) and one (1).
- Bit:** Bit is an abbreviation for "binary digit (0~1)", and is the smallest unit of information used by a printer or computer.
- Bit-image graphics:** Graphics which are created through a series of dots printed in vertical columns.
- Buffer:** Buffer is an area of memory which stores data temporarily.
- Byte:** Byte is the unit of information used by a printer or computer. One byte is equivalent to eight (8) bits.
- Character set:** Character set is the set of characters, numbers, and symbols available for printing.
- Code page:** The computer system stores characters and numbers as a numerical data. The code page is a table which is used to change them into the numerical data.
- Control codes:** Control codes are commands from the computer to the printer that are non-printable characters. They are used to control printer functions.
- cpi:** "cpi" is an abbreviation for "characters per inch", and means the maximum number of characters printed in one horizontal inch.
- cpl:** "cpl" is an abbreviation for "characters per line", and means the maximum number of characters printed on one line.
- cps:** "cps" is an abbreviation for "characters per second", and means the number of characters printed in one second.
- CR (Carriage Return):** "CR" is a control code that returns the printhead to the left margin.

- Decimal (Dec.):** Decimal is a numbering system composed of 10 digits 0, 1, 2, 3, 4, 5, 6, 7, 8 and 9.
- Default:** Default has two meanings: one indicates the previously set conditions or settings executed when the power is turned on, reset or initialized; and the other indicates the original settings when shipped from the factory. (FACTORY settings)
- Dot matrix printer:** An impact printer whereby wires (pins) strike the ribbon and subsequently a dot prints on the paper. The software in the printer supplies the commands which determine which pins are activated to form the appropriate character(s).
- Dot per inch (DPI):** A measure of resolution used for monitors and printers.
- Double strike printing:** Double printing is a print quality enhancing mode which uses a double strike with two passes of the printhead, feeding the paper 1/180" (0.14 mm) between the first and second pass (in Epson ESC/P2 mode only).
- Double high printing:** Double high printing makes the height of a character twice that of a normal one.
- Double wide printing:** Double wide printing makes the width of a character twice that of a normal one.
- Download character:** Download character is a character which the user can design.
- Draft:** Draft is one of three print qualities available on this printer. Draft mode uses a minimum number of dots per character to maximize printing speed.
- Driver:**  P. 109 "Printer drivers"
- Emphasized printing:** Emphasized printing is a print quality enhancing mode done in one pass of the printhead at half speed, allowing horizontally adjacent dots to be printed producing a darker character.
- Emulation:** Emulation means to operate like another printer. KX-P3123 can emulate the Epson LQ-570 or the IBM Proprinter X24E.
- Escape (ESC) sequence:** "ESC" is a control code that begins most printer commands. The characters which follow the "ESC" are interpreted as command, rather than characters to print.
- ESC/P2:** An expanded level of commands for 24 and 48 pin dot matrix printers.

- Fanfold paper:** Fanfold paper has regularly spaced sprocket holes on the left and right sides and pages are separated by a perforation between each sheet. May also be known as computer paper or tractor paper.
- FF (Form Feed):** "FF" is a control code that advances the paper one page.
- Fixed pitch printing:** A type of printing whereby each characters is the same width and prints as equal intervals.
- Font:** All characters of a typeface having the same size, weight, style character table, typeface and rotation. Changing an attribute selects a new font.
- Function:** Function allows you to determine how the printer will operate.
- Graphics:** Groups of dots or characters that are used to create images, as opposed to text and numbers.
- Graphics mode:** A special mode of print in which only raster graphics printing is possible.
- Hexadecimal:** Hexadecimal is a numbering system using the 16 digits, 0, 1, 2, 3, 4, 5, 6, 7, 8, 9, A, B, C, D, E and F.
- Horizontal motion index:** A fixed distance to move horizontally when printing characters.
- Initialization:** Initialization means to reset the printer to the initial start up condition.
- Interface:** Interface is the connection between the two separate systems, such as the computer and the printer. A parallel interface transfers data one character or code at a time, and a serial interface transfers data one bit at a time.
- International character set:** A set of characters defined by each country.
- I/O:** "I/O" is the symbolic notation for "Input/Output".
- Italics:** A font style in which the character slants to the right. Used for emphasis, this is sometimes called oblique.
- Justification:** The alignment of multiple lines of text along the left margin, right margin or both margins. When both margins are fustified, the term is full justification.

**Letter Quality (LQ):** LQ is one of three print qualities available on this printer. LQ mode increases the number of dots per character to improve the print quality but decreases the printing speed.

**LF (Line Feed):** "LF" is a control code that advances the paper one line.

**Line spacing:** The space between lines of type. Also called leading.

**LSB:** "LSB" is an acronym for "Least Significant Bit", and means the rightmost position in a binary number.

**MACRO memory function:** This feature allows the printer to easily save and recall a particular combination of functions, even if the power is turned off.

**Margin:** The area between the edge of the paper and the first or last print position; left, right, top or bottom margin.

**Menu:** Menu is a list of topics from which you can enter to select the desired conditions or settings.

**Micro Line Feed:** Micro Line Feed function allows you to feed the paper by one micro line (1/180"). (P. 37)

**MSB:** "MSB" is an acronym for "Most Significant Bit", and means the leftmost position in a binary number.

**Multipoint mode:** The mode in which the printing of scalable fonts is possible.

**OFF LINE:** OFF LINE is the condition in which the printer cannot communicate with the computer.

**ON LINE:** ON LINE is the condition in which the printer can communicate with the computer.

**Overline printing:** Overline printing produces a continuous line above the characters, using the first pin of the printhead.

**Parallel interface:** An interface that transfers data one byte at a time.

**Parity:** Parity is a method for a computer and printer to check the accuracy of data transfer.

**Perforation:** Perforation indicates the tear position on the fanfold paper. (P. 37)

- Pitch:** Pitch is the number of characters which will print in one inch. Pitch is equivalent to characters per inch (cpi).
- Platen:** Platen is the rubber roller which is a backing for the paper when printing.
- Point size:** A measure of character height used in typesetting. A point=1/72 of an inch.
- Printable area:** The area of a page where the print quality is assured.
- Printer drivers:** Most of today's off the shelf software programs use printer drivers to control printer functions. These drivers contain the software codes your software program uses to access printer features. With the printer driver installed, you will seldom need to know any of the KX-P3123 commands.
- Printing area:** The area of the page within the margins, where printing actually occurs. The printing area is equal to or less than the printable area.
- Proportional spacing (PS):** Proportional spacing is a printing method of adjusting the character space in which a character is printed. A "w" will take up more space than an "i".
- Protocol:** Protocol is the set of rules permitting communication between a computer and printer when a serial interface (RS-232C) is used. It covers polarity, baud rate, parity, data length, start bit and stop bit.
- Pull tractor:** A paper feeding device that "pulls" continuous paper through the printer from the exit side.
- Push tractor:** A paper feeding device that "pushes" continuous paper through the printer from the loading side.
- RAM:** RAM is an acronym for "Random Access Memory". It is the part of the printer's memory in which data is stored, control codes or download characters are to be printed. RAM is cleared when the printer is turned off.
- Raster graphics:** The method used to send graphics in one-dot high lines.
- Reset:** Returning to the printer's original settings.
- ROM:** ROM is an acronym for "Read Only Memory". It is the part of the printer's memory in which predefined characters and operating information for the printer are stored. ROM is not cleared when the printer is turned off.
- Scalable fonts:** The user can alter the point size of a selected font to make the font larger or smaller.
- Self test:** Self test is a method for testing the operation of the printer. (☞ P. 35)

- Serial interface:** Transmitting data one bit at a time from computer to printer.
- Skip perforation:** Skip perforation means nothing is printed in a specified area before and after the page perforation.
- String concatenation:** This is the joining of two or more bytes of data into a single command.
- Style:** A font attribute which changes the appearance by printing the character on a slant. (Italic)
- Super Letter Quality (SLQ):** SLQ is one of three print qualities available on this printer. SLQ mode uses a maximum number of dots per character to improve the print quality more than LQ mode but decreases the printing speed less than LQ mode.
- SUPER QUIET mode:** SUPER QUIET mode is a helpful feature of this printer which reduces printing noise.
- Top of Form:** Top of Form is the first line position on the paper. This printer has the "Top of Form function", a helpful feature which loads the paper automatically to the designated position.
- Typeface:** All characters of a single, unified design at any size and rotation. Example: Roman, Prestige, etc.
- Unidirectional printing:** The printer prints left-to-right only. Printing speed is slow compared with bidirectional printing. This print method permits better vertical alignment.
- User-defined characters:** Also called download characters, these are custom characters defined within RAM.
- Weight:** A font attribute that determines the thickness of the lines creating the character. (Bold)
- Windows:** An operating environment which lies between the operating system (DOS) and an application, that controls the system devices.

## A

Acknowledge ( $\overline{ACK}$ ) ..... 94  
AC power cord ..... 14  
AC socket ..... 14  
Alternate Graphic Mode (A.G.M.) ..... 55  
Auto CR ..... 55  
Auto LF ..... 55  
Auto Load ..... 30  
ASCII ..... 89

## B

Buffer ..... 90  
Bi-directional Printing ..... 90  
Bold PS ..... 90  
Bottom feeding ..... 20, 25

## C

Centronics parallel interface ..... 90  
Characters Alignment ..... 31  
Character sets ..... 90  
Character Set Table ..... 99  
    Epson Mode ..... 99  
    IBM Mode ..... 101  
Clear Buffer ..... 97  
Code page ..... 55, 62  
COLOR ..... 53  
Color Kit ..... 53, 89  
Column indicator ..... 12, 56  
Command reference program ..... 84  
    DOS ..... 84  
    Windows ..... 84  
Connector pin signal ..... 95  
Control Panel ..... 12, 55  
Control Table ..... 12, 43, 54  
cpl ..... 90  
cps ..... 90  
Current Settings ..... 43, 58  
Cut Sheet Feeder ..... 20, 88

## D

Default setting ..... 51  
Detector ..... 91  
    Overheat ..... 91  
    Overload ..... 91  
    Paper out ..... 88, 89, 91  
Dot configuration ..... 90  
Dot pitch ..... 90  
DOS ..... 64, 65, 84  
Draft ..... 90

## E

Elite ..... 90  
Emulation ..... 73, 88, 90  
    Epson ESC/P2 (LQ-570 Mode) .. 73, 90  
    IBM Proprinter X24E Mode ..... 79, 90  
Envelope ..... 20, 29, 39, 92, 93

## F

FACTORY Settings ..... 51, 61, 71  
Fanfold paper ..... 20, 21, 25, 39, 40, 92, 93  
Feeding paper ..... 37  
FF switch ..... 12  
FONT ..... 44, 90  
Form Feed ..... 37  
FORM LENGTH ..... 44  
Frame ground terminal ..... 14  
Frame ground wire ..... 14  
Friction mode ..... 20, 29  
FUNCTION switch ..... 13

## G

Graphic Direction ..... 90

## H

Head gap lever ..... 13, 88  
Help ..... 71  
Hex Dump ..... 98

## I

IBM Proprinter X24E	79, 90
Initialization	97
Initial setup mode	55, 59, 65
Initial setup program	65
Installing	
paper	21
Printer-Driver	33
ribbon cassette	15
Interface cable	88
International Character Set	102

## L

Label	20
LEFT MARGIN	46
LF switch	13
Line Feed	37, 90
LOAD/PARK switch	12
Letter Quality	90

## M

MACRO	43
Defining (MACRO save)	48
Recalling (MACRO recall)	50
Maintenance	87
Matrix	90
Micro line feed	37
Micron	90
Multipart form	20

## O

ON LINE/FUNCTION indicator	13
ON LINE switch	12

## P

Paper	
Feeding	37
Installing	21
Parking	20, 39
Paper Feed	20, 90
Friction Mode	20, 29, 90
Pull Tractor Mode	20, 25, 90
Push Tractor Mode	20, 21, 90

Paper feed selector	13, 88
Paper guide	30
Paper support	22
Parallel Interfacing	94
Parallel Interface cable	14
Pica	90
PITCH	44
Platen	27
Platen knob	11
POWER/PAPER OUT indicator	13
Printer-Driver	32, 33
Printable Area	37
Printing Area	93
Printing direction	90
Pull Tractor Mode	20, 25
Pull up roller	26
Push Tractor Mode	20, 21

## R

Rear feeding	20, 21, 37, 39
Reverse micro line feed	37
Ribbon cassette	15~19, 87, 88
Installing	15
Removing	18
Re-inking	85
RIGHT MARGIN	46
Row indicator	12, 56

## S

Scalable Font	90
Self Test	35, 87
Setup Disk	33, 62, 84
Single sheet	20, 29, 39, 92, 93
Smoked plastic cover	11
Specifications	
Paper	92
Printer	90
Strobe Signal (STB)	94
Super Letter Quality	90
SUPER QUIET	36
SUPER QUIET indicator	13
SUPER QUIET switch	12



**T**

Tear bar .....	38
Tear Off .....	37
TEAR OFF switch .....	12
Timing chart .....	96
Top cover .....	21
Top of Form (TOF) .....	31, 38, 41
Tractor .....	22
Tractor clamping lever .....	22
Troubleshooting .....	86

**U**

Uni-directional character .....	90
Unpacking .....	10
User clear function .....	97

**W**

Windows .....	33, 65, 82
---------------	------------

**Z**

Zero Font .....	55
-----------------	----

# Options and Supplies

- KX-PS13** RS-232C/Current Loop Serial Interface Board (19.2 K Bps)
- KX-PS14** RS-232C/Serial Interface Board (9600 Bps)
- KX-PT10** Auto Cut Sheet Feeder (Single Bin)
- KX-P150** Ribbon Cassette (Black)
- KX-P150C** Ribbon Cassette (4 Colors)
- KX-PCK11** Color Kit (KX-P150C, Gear Unit, Motor Unit)

\* Each of the above options has its own Installation and Instruction Manuals.

**FOR USERS IN CONTINENTAL UNITED STATES ONLY**

**TECHNICAL SUPPORT CALLS**

If you have read this manual and tried the troubleshooting procedures and you are still having difficulty please contact the store from which the unit was purchased.

You may also call the technical support telephone number which is operational during east coast business hours (9:00 AM to 5:00 PM).

The technical support number is: 1-800-222-0584  
(Options and supplies: 1-800-346-4768)

---

**Panasonic Communications & Systems Company,  
Computer Products Division  
Division of Matsushita Electric Corporation of America  
Two Panasonic Way, Secaucus, New Jersey 07094**

**Panasonic Sales Company  
Division of Matsushita Electric of Puerto Rico, Inc.  
San Gabriel Industrial Park, 65th Infantry Avenue KM 9 5  
Carolina, Puerto Rico 00630**

---