

4cyl, 1.6L Turbo, FWD, Automatic Dual Clutch, 25,000 miles Maintenance Menu

Previous Service

18,000 miles

18,000 Mile Factory Required Service

- Inspect Air Conditioning Compressor
- Inspect Air Conditioning Refrigerant
- Inspect Battery Condition
- Inspect Brake Lines, Hoses and Connections
- Inspect Disc Brakes and Pads
- Inspect Driveshafts and Boots
- Inspect Exhaust Pipe and Muffler
- Inspect Intercooler, In/Out Hose, Air Intake Hose
- Inspect Steering Gear Rack, Linkage and Boots
- Inspect Suspension Mounting Bolts
- Inspect Vacuum Hose
- Replace Air Cleaner Filter
- Replace Climate Control Air Filter
- Replace Engine Oil and Filter
- Tire Rotation
- Add Fuel Additive (recommended only if TOP TIER Detergent Gasoline is not available. See owner's manual for details.)

Current Service

24.000 miles

24,000 Mile Factory Required Service

- Inspect Air Cleaner Filter
- Inspect Air Conditioning Compressor
- Inspect Air Conditioning Refrigerant
- Inspect Battery Condition
- Inspect Brake Fluid
- Inspect Brake Lines, Hoses and Connections
- Inspect Disc Brakes and Pads
- Inspect Driveshafts and Boots
- Inspect Dual Clutch transmission fluid
- Inspect Exhaust Pipe and Muffler
- Inspect Fuel Filter
- Inspect Fuel Lines, Fuel Hoses, and Connections
- Inspect Fuel Tank Air Filter
- Inspect Intercooler, In/Out Hose, Air Intake Hose
- Inspect Parking Brake
- Inspect Steering Gear Rack, Linkage and Boots
- Inspect Suspension Mounting Bolts
- Inspect Vacuum Hose
- Inspect Vapor Hose, Fuel Filler Cap and Fuel Tank
- Replace Climate Control Air Filter
- Replace Engine Oil and Filter
- Tire Rotation
- Add Fuel Additive (recommended only if TOP TIER Detergent Gasoline is not available. See owner's manual for details.)

Next Service

30,000 miles

30,000 Mile Factory Required Service

- Inspect Air Cleaner Filter
- Inspect Air Conditioning Compressor
- Inspect Air Conditioning Refrigerant
- Inspect Battery Condition
- Inspect Brake Lines, Hoses and Connections
- Inspect Disc Brakes and Pads
- Inspect Driveshafts and Boots
- Inspect Exhaust Pipe and Muffler
- Inspect Intercooler, In/Out Hose, Air Intake Hose
- Inspect Steering Gear Rack, Linkage and Boots
- Inspect Suspension Mounting Bolts
- Inspect Vacuum Hose
- Replace Climate Control Air Filter
- Replace Engine Oil and Filter
- Tire Rotation
- Add Fuel Additive (recommended only if TOP TIER Detergent Gasoline is not available. See owner's manual for details.)





4cyl, 1.6L Turbo, FWD, Automatic Dual Clutch, 25,000 miles Maintenance Menu

18,000 miles*

18,000 Mile Factory Required Service

- Inspect Air Conditioning Compressor
- Inspect Air Conditioning Refrigerant
- Inspect Battery Condition
- Inspect Brake Lines. Hoses and Connections
- Inspect Disc Brakes and Pads
- Inspect Driveshafts and Boots
- Inspect Exhaust Pipe and Muffler
- Inspect Intercooler, In/Out Hose, Air Intake Hose
- Inspect Steering Gear Rack, Linkage and Boots
- Inspect Suspension Mounting Bolts
- Inspect Vacuum Hose
- Replace Air Cleaner Filter
- Replace Climate Control Air Filter
- Replace Engine Oil and Filter
- Tire Rotation
- Add Fuel Additive (recommended only if TOP TIER Detergent Gasoline is not available. See owner's manual for details.)

24,000 miles*

24,000 Mile Factory Required Service

- Inspect Air Cleaner Filter
- Inspect Air Conditioning Compressor
- Inspect Air Conditioning Refrigerant
- Inspect Battery Condition
- Inspect Brake Fluid
- Inspect Brake Lines. Hoses and Connections
- Inspect Disc Brakes and Pads
- Inspect Driveshafts and Boots
- Inspect Dual Clutch transmission fluid
- Inspect Exhaust Pipe and Muffler
- Inspect Fuel Filter
- Inspect Fuel Lines, Fuel Hoses, and Connections
- Inspect Fuel Tank Air Filter
- Inspect Intercooler, In/Out Hose, Air Intake Hose
- Inspect Parking Brake
- Inspect Steering Gear Rack, Linkage and Boots
- Inspect Suspension Mounting Bolts
- Inspect Vacuum Hose
- Inspect Vapor Hose, Fuel Filler Cap and Fuel Tank
- Replace Climate Control Air Filter
- Replace Engine Oil and Filter
- Tire Rotation
- Add Fuel Additive (recommended only if TOP TIER Detergent Gasoline is not available. See owner's manual for details.)

30,000 miles*

30,000 Mile Factory Required Service

- Inspect Air Cleaner Filter
- Inspect Air Conditioning Compressor
- Inspect Air Conditioning Refrigerant
- Inspect Battery Condition
- Inspect Brake Lines. Hoses and Connections
- Inspect Disc Brakes and Pads
- Inspect Driveshafts and Boots
- Inspect Exhaust Pipe and Muffler
- Inspect Intercooler, In/Out Hose, Air Intake Hose
- Inspect Steering Gear Rack, Linkage and Boots
- Inspect Suspension Mounting Bolts
- Inspect Vacuum Hose
- Replace Climate Control Air Filter
- Replace Engine Oil and Filter
- Tire Rotation
- Add Fuel Additive (recommended only if TOP TIER Detergent Gasoline is not available. See owner's manual for details.)

36.000 miles*

36,000 Mile Factory Required Service

- Inspect Air Conditioning Compressor
- Inspect Air Conditioning Refrigerant
- Inspect Battery Condition
- Inspect Brake Fluid
- Inspect Brake Lines, Hoses and Connections
- Inspect Disc Brakes and Pads
- · Inspect Driveshafts and Boots
- Inspect Exhaust Pipe and Muffler
- Inspect Fuel Filter
- Inspect Fuel Tank Air Filter
- Inspect Intercooler, In/Out Hose, Air Intake Hose
- Inspect Parking Brake
- Inspect Steering Gear Rack, Linkage and Boots
- Inspect Suspension Mounting Bolts
- Inspect Vacuum Hose
- Inspect Vapor Hose, Fuel Filler Cap and Fuel Tank
- Replace Air Cleaner Filter
- Replace Climate Control Air Filter
- Replace Engine Oil and Filter
- Tire Rotation
- Add Fuel Additive (recommended only if TOP TIER Detergent Gasoline is not available. See owner's manual for details.)

42,000 miles*

42,000 Mile Factory Required Service

- Inspect Air Cleaner Filter
- Inspect Air Conditioning Compressor
- Inspect Air Conditioning Refrigerant
- Inspect Battery Condition
- Inspect Brake Lines, Hoses and Connections
- Inspect Disc Brakes and Pads
- Inspect Driveshafts and Boots
- Inspect Exhaust Pipe and Muffler
- Inspect Intercooler, In/Out Hose, Air Intake Hose
- Inspect Steering Gear Rack, Linkage and Boots
- Inspect Suspension Mounting Bolts
- Inspect Vacuum Hose
- Replace Climate Control Air Filter
- Replace Engine Oil and Filter
- Replace Spark Plugs (Iridium Coated)
- Tire Rotation
- Add Fuel Additive (recommended only if TOP TIER Detergent Gasoline is not available. See owner's manual for details.)





4cyl, 1.6L Turbo, FWD, Automatic Dual Clutch, 25,000 miles Maintenance Menu

48,000 miles*

48,000 Mile Factory Required Service

- Inspect Air Cleaner Filter
- Inspect Air Conditioning Compressor
- Inspect Air Conditioning Refrigerant
- Inspect Battery Condition
- Inspect Brake Fluid
- Inspect Brake Lines. Hoses and Connections
- Inspect Disc Brakes and Pads
- Inspect Driveshafts and Boots
- Inspect Dual Clutch transmission fluid
- Inspect Exhaust Pipe and Muffler
- Inspect Fuel Filter
- Inspect Fuel Lines, Fuel Hoses, and Connections
- Inspect Fuel Tank Air Filter
- Inspect Intercooler, In/Out Hose, Air Intake Hose
- Inspect Parking Brake
- Inspect Steering Gear Rack, Linkage and Boots
- Inspect Suspension Mounting Bolts
- Inspect Vacuum Hose
- Inspect Vapor Hose, Fuel Filler Cap and Fuel Tank
- Replace Climate Control Air Filter
- Replace Engine Oil and Filter
- Tire Rotation
- Add Fuel Additive (recommended only if TOP TIER Detergent Gasoline is not available. See owner's manual for details.)

54.000 miles*

54,000 Mile Factory Required Service

- Inspect Air Conditioning Compressor
- Inspect Air Conditioning Refrigerant
- Inspect Battery Condition
- Inspect Brake Lines, Hoses and Connections
- Inspect Disc Brakes and Pads
- Inspect Driveshafts and Boots
- Inspect Exhaust Pipe and Muffler
- Inspect Intercooler, In/Out Hose, Air Intake Hose
- Inspect Steering Gear Rack, Linkage and Boots
- Inspect Suspension Mounting Bolts
- Inspect Vacuum Hose
- Replace Air Cleaner Filter
- Replace Climate Control Air Filter
- Replace Engine Oil and Filter
- Tire Rotation
- Add Fuel Additive (recommended only if TOP TIER Detergent Gasoline is not available. See owner's manual for details.)

60,000 miles*

60,000 Mile Factory Required Service

- Inspect Air Cleaner Filter
- Inspect Air Conditioning Compressor
- Inspect Air Conditioning Refrigerant
- Inspect Battery Condition
- Inspect Brake Fluid
- Inspect Brake Lines. Hoses and Connections
- Inspect Disc Brakes and Pads
- Inspect Drive Belt(s)
- Inspect Driveshafts and Boots
- Inspect Exhaust Pipe and Muffler
- Inspect Fuel Filter
- Inspect Fuel Tank Air Filter
- Inspect Intercooler, In/Out Hose, Air Intake Hose
- Inspect Parking Brake
- Inspect Steering Gear Rack, Linkage and Boots
- Inspect Suspension Mounting Bolts
- Inspect Vacuum Hose
- Inspect Valve Clearance
- Inspect Vapor Hose, Fuel Filler Cap and Fuel Tank
- Replace Climate Control Air Filter
- Replace Engine Oil and Filter
- Tire Rotation
- Add Fuel Additive (recommended only if TOP TIER Detergent Gasoline is not available. See owner's manual for details.)

66,000 miles*

66,000 Mile Factory Required Service

- Inspect Air Cleaner Filter
- Inspect Air Conditioning Compressor
- Inspect Air Conditioning Refrigerant
- Inspect Battery Condition
- Inspect Brake Lines, Hoses and Connections
- Inspect Disc Brakes and Pads
- Inspect Driveshafts and Boots
- Inspect Exhaust Pipe and Muffler
- Inspect Intercooler, In/Out Hose, Air Intake Hose
- Inspect Steering Gear Rack, Linkage and Boots
- Inspect Suspension Mounting Bolts
- Inspect Vacuum Hose
- Replace Climate Control Air Filter
- Replace Engine Oil and Filter
- Tire Rotation
- Add Fuel Additive (recommended only if TOP TIER Detergent Gasoline is not available. See owner's manual for details.)





4cyl, 1.6L Turbo, FWD, Automatic Dual Clutch, 25,000 miles Maintenance Menu

72,000 miles*

72,000 Mile Factory Required Service

- Inspect Air Conditioning Compressor
- Inspect Air Conditioning Refrigerant
- Inspect Battery Condition
- Inspect Brake Fluid
- Inspect Brake Lines. Hoses and Connections
- Inspect Disc Brakes and Pads
- Inspect Drive Belt(s)
- Inspect Driveshafts and Boots
- Inspect Dual Clutch transmission fluid
- Inspect Exhaust Pipe and Muffler
- Inspect Fuel Filter
- Inspect Fuel Lines, Fuel Hoses, and Connections
- Inspect Fuel Tank Air Filter
- Inspect Intercooler, In/Out Hose, Air Intake Hose
- Inspect Parking Brake
- Inspect Steering Gear Rack, Linkage and Boots
- Inspect Suspension Mounting Bolts
- Inspect Vacuum Hose
- Inspect Vapor Hose, Fuel Filler Cap and Fuel Tank
- Replace Air Cleaner Filter
- Replace Climate Control Air Filter
- Replace Engine Oil and Filter
- Tire Rotation
- Add Fuel Additive (recommended only if TOP TIER Detergent Gasoline is not available. See owner's manual for details.)

78,000 miles*

78,000 Mile Factory Required Service

- Inspect Air Cleaner Filter
- Inspect Air Conditioning Compressor
- Inspect Air Conditioning Refrigerant
- Inspect Battery Condition
- Inspect Brake Lines. Hoses and Connections
- Inspect Disc Brakes and Pads
- Inspect Driveshafts and Boots
- Inspect Exhaust Pipe and Muffler
- Inspect Intercooler, In/Out Hose, Air Intake Hose
- Inspect Steering Gear Rack, Linkage and Boots
- Inspect Suspension Mounting Bolts
- Inspect Vacuum Hose
- Replace Climate Control Air Filter
- Replace Engine Oil and Filter
- Tire Rotation
- Add Fuel Additive (recommended only if TOP TIER Detergent

Gasoline is not available. See owner's manual for details.)

84,000 miles*

84,000 Mile Factory Required Service

- Inspect Air Cleaner Filter
- Inspect Air Conditioning Compressor
- Inspect Air Conditioning Refrigerant
- Inspect Battery Condition
- Inspect Brake Fluid
- Inspect Brake Lines, Hoses and Connections
- Inspect Disc Brakes and Pads
- Inspect Drive Belt(s)
- Inspect Driveshafts and Boots
- Inspect Exhaust Pipe and Muffler
- Inspect Fuel Filter
- Inspect Fuel Tank Air Filter
- Inspect Intercooler, In/Out Hose, Air Intake Hose
- Inspect Parking Brake
- Inspect Steering Gear Rack, Linkage and Boots
- Inspect Suspension Mounting Bolts
- Inspect Vacuum Hose
- Inspect Vapor Hose, Fuel Filler Cap and Fuel Tank
- Replace Climate Control Air Filter
- Replace Engine Oil and Filter
- Replace Spark Plugs (Iridium Coated)
- Tire Rotation
- Add Fuel Additive (recommended only if TOP TIER Detergent Gasoline is not available. See owner's manual for details.)

90.000 miles*

90,000 Mile Factory Required Service

- Inspect Air Conditioning Compressor
- Inspect Air Conditioning Refrigerant
- Inspect Battery Condition
- Inspect Brake Lines, Hoses and Connections
- Inspect Disc Brakes and Pads
- Inspect Disc Brakes and Fads
 Inspect Driveshafts and Boots
- Inspect Exhaust Pipe and Muffler
- Inspect Intercooler, In/Out Hose, Air Intake Hose
- Inspect Steering Gear Rack, Linkage and Boots
- Inspect Suspension Mounting Bolts
- Inspect Vacuum Hose
- Replace Air Cleaner Filter
- Replace Climate Control Air Filter
- Replace Engine Oil and Filter
- Tire Rotation
- Add Fuel Additive (recommended only if TOP TIER Detergent Gasoline is not available. See owner's manual for details.)

96.000 miles*

96,000 Mile Factory Required Service

- Inspect Air Cleaner Filter
- Inspect Air Conditioning Compressor
- Inspect Air Conditioning Refrigerant
- Inspect Battery Condition
- Inspect Brake Fluid
- Inspect Brake Lines. Hoses and Connections
- Inspect Disc Brakes and Pads
- Inspect Drive Belt(s)
- Inspect Driveshafts and Boots
- Inspect Dual Clutch transmission fluid
- Inspect Exhaust Pipe and Muffler
- Inspect Fuel Filter
- Inspect Fuel Lines. Fuel Hoses, and Connections
- Inspect Fuel Tank Air Filter
- Inspect Intercooler, In/Out Hose, Air Intake Hose
- Inspect Parking Brake
- Inspect Steering Gear Rack, Linkage and Boots
- Inspect Suspension Mounting Bolts
- Inspect Vacuum Hose
- Inspect Vapor Hose, Fuel Filler Cap and Fuel Tank
- Replace Climate Control Air Filter
- Replace Engine Oil and Filter
- Tire Rotation
- Add Fuel Additive (recommended only if TOP TIER Detergent Gasoline is not available. See owner's manual for details.)





4cyl, 1.6L Turbo, FWD, Automatic Dual Clutch, 25,000 miles Maintenance Menu

102,000 miles*

102,000 Mile Factory Required Service

- Inspect Air Cleaner Filter
- Inspect Air Conditioning Compressor
- Inspect Air Conditioning Refrigerant
- Inspect Battery Condition
- Inspect Brake Lines. Hoses and Connections
- Inspect Disc Brakes and Pads
- Inspect Driveshafts and Boots
- Inspect Exhaust Pipe and Muffler
- Inspect Intercooler, In/Out Hose, Air Intake Hose
- Inspect Steering Gear Rack, Linkage and Boots
- Inspect Suspension Mounting Bolts
- Inspect Vacuum Hose
- Replace Climate Control Air Filter
- Replace Engine Oil and Filter
- Tire Rotation
- Add Fuel Additive (recommended only if TOP TIER Detergent Gasoline is not available. See owner's manual for details.)

108,000 miles*

108,000 Mile Factory Required Service

- Inspect Air Conditioning Compressor
- Inspect Air Conditioning Refrigerant
- Inspect Battery Condition
- Inspect Brake Fluid
- Inspect Brake Lines, Hoses and Connections
- Inspect Disc Brakes and Pads
- Inspect Drive Belt(s)
- Inspect Driveshafts and Boots
- Inspect Exhaust Pipe and Muffler
- Inspect Fuel Filter
- Inspect Fuel Tank Air Filter
- Inspect Intercooler, In/Out Hose, Air Intake Hose
- Inspect Parking Brake
- Inspect Steering Gear Rack, Linkage and Boots
- Inspect Suspension Mounting Bolts
- Inspect Vacuum Hose
- Inspect Vapor Hose, Fuel Filler Cap and Fuel Tank
- Replace Air Cleaner Filter
- Replace Climate Control Air Filter
- Replace Engine Oil and Filter
- Tire Rotation
- Add Fuel Additive (recommended only if TOP TIER Detergent

Gasoline is not available. See owner's manual for details.)

114,000 miles*

114,000 Mile Factory Required Service

- Inspect Air Cleaner Filter
- Inspect Air Conditioning Compressor
- Inspect Air Conditioning Refrigerant
- Inspect Battery Condition
- Inspect Brake Lines. Hoses and Connections
- Inspect Disc Brakes and Pads
- Inspect Driveshafts and Boots
- Inspect Exhaust Pipe and Muffler
- Inspect Intercooler, In/Out Hose, Air Intake Hose
- Inspect Steering Gear Rack, Linkage and Boots
- Inspect Suspension Mounting Bolts
- Inspect Vacuum Hose
- Replace Climate Control Air Filter
- Replace Engine Oil and Filter
- Tire Rotation
- Add Fuel Additive (recommended only if TOP TIER Detergent Gasoline is not available. See owner's manual for details.)

120,000 miles*

120,000 Mile Factory Required Service

- Inspect Air Cleaner Filter
- Inspect Air Conditioning Compressor
- Inspect Air Conditioning Refrigerant
- Inspect Battery Condition
- Inspect Brake Fluid
- Inspect Brake Lines. Hoses and Connections
- Inspect Disc Brakes and Pads
- Inspect Drive Belt(s)
- Inspect Driveshafts and Boots
- Inspect Dual Clutch transmission fluid
- Inspect Exhaust Pipe and Muffler
- Inspect Fuel Filter
- Inspect Fuel Lines. Fuel Hoses, and Connections
- Inspect Fuel Tank Air Filter
- Inspect Intercooler, In/Out Hose, Air Intake Hose
- Inspect Parking Brake
- Inspect Steering Gear Rack, Linkage and Boots
- Inspect Suspension Mounting Bolts
- Inspect Vacuum Hose
- Inspect Valve Clearance
- Inspect Vapor Hose, Fuel Filler Cap and Fuel Tank
- Replace Climate Control Air Filter
- Replace Coolant
- Replace Engine Oil and Filter
- Tire Rotation
- Add Fuel Additive (recommended only if TOP TIER Detergent Gasoline is not available. See owner's manual for details.)





4cyl, 1.6L Turbo, FWD, Automatic Dual Clutch, 25,000 miles Maintenance Menu

126,000 miles*

126,000 Mile Factory Required Service

- Inspect Air Conditioning Compressor
- Inspect Air Conditioning Refrigerant
- Inspect Battery Condition
- Inspect Brake Lines. Hoses and Connections
- Inspect Disc Brakes and Pads
- Inspect Driveshafts and Boots
- Inspect Exhaust Pipe and Muffler
- Inspect Intercooler, In/Out Hose, Air Intake Hose
- Inspect Steering Gear Rack, Linkage and Boots
- Inspect Suspension Mounting Bolts
- Inspect Vacuum Hose
- Replace Air Cleaner Filter
- Replace Climate Control Air Filter
- Replace Engine Oil and Filter
- Replace Spark Plugs (Iridium Coated)
- Tire Rotation
- Add Fuel Additive (recommended only if TOP TIER Detergent Gasoline is not available. See owner's manual for details.)

132,000 miles*

132,000 Mile Factory Required Service

- Inspect Air Cleaner Filter
- Inspect Air Conditioning Compressor
- Inspect Air Conditioning Refrigerant
- Inspect Battery Condition
- Inspect Brake Fluid
- Inspect Brake Lines. Hoses and Connections
- Inspect Disc Brakes and Pads
- Inspect Drive Belt(s)
- Inspect Driveshafts and Boots
- Inspect Exhaust Pipe and Muffler
- Inspect Fuel Filter
- Inspect Fuel Tank Air Filter
- Inspect Intercooler, In/Out Hose, Air Intake Hose
- Inspect Parking Brake
- Inspect Steering Gear Rack, Linkage and Boots
- Inspect Suspension Mounting Bolts
- Inspect Vacuum Hose
- Inspect Vapor Hose, Fuel Filler Cap and Fuel Tank
- Replace Climate Control Air Filter
- Replace Engine Oil and Filter
- Tire Rotation
- Add Fuel Additive (recommended only if TOP TIER Detergent Gasoline is not available. See owner's manual for details.)

138,000 miles*

138,000 Mile Factory Required Service

- Inspect Air Cleaner Filter
- Inspect Air Conditioning Compressor
- Inspect Air Conditioning Refrigerant
- Inspect Battery Condition
- Inspect Brake Lines. Hoses and Connections
- Inspect Disc Brakes and Pads
- Inspect Driveshafts and Boots
- Inspect Exhaust Pipe and Muffler
- Inspect Intercooler, In/Out Hose, Air Intake Hose
- Inspect Steering Gear Rack, Linkage and Boots
- Inspect Suspension Mounting Bolts
- Inspect Vacuum Hose
- Replace Climate Control Air Filter
- Replace Engine Oil and Filter
- Tire Rotation
- Add Fuel Additive (recommended only if TOP TIER Detergent Gasoline is not available. See owner's manual for details.)

144,000 miles*

144,000 Mile Factory Required Service

- Inspect Air Conditioning Compressor
- Inspect Air Conditioning Refrigerant
- Inspect Battery Condition
- Inspect Brake Fluid
- Inspect Brake Lines, Hoses and Connections
- Inspect Disc Brakes and Pads
- Inspect Drive Belt(s)
- Inspect Driveshafts and Boots
- Inspect Dual Clutch transmission fluid
- Inspect Exhaust Pipe and Muffler
- Inspect Fuel Filter
- Inspect Fuel Lines. Fuel Hoses, and Connections
- Inspect Fuel Tank Air Filter
- Inspect Intercooler, In/Out Hose, Air Intake Hose
- Inspect Parking Brake
- Inspect Steering Gear Rack, Linkage and Boots
- Inspect Suspension Mounting Bolts
- Inspect Vacuum Hose
- Inspect Vapor Hose, Fuel Filler Cap and Fuel Tank
- Replace Air Cleaner Filter
- Replace Climate Control Air Filter
- Replace Engine Oil and Filter
- Tire Rotation
- Add Fuel Additive (recommended only if TOP TIER Detergent Gasoline is not available. See owner's manual for details.)





4cyl, 1.6L Turbo, FWD, Automatic Dual Clutch, 25,000 miles Maintenance Menu

150,000 miles*

150,000 Mile Factory Required Service

- Inspect Air Cleaner Filter
- Inspect Air Conditioning Compressor
- Inspect Air Conditioning Refrigerant
- Inspect Battery Condition
- Inspect Brake Lines, Hoses and Connections
- Inspect Disc Brakes and Pads
- Inspect Driveshafts and Boots
- Inspect Exhaust Pipe and Muffler
- Inspect Intercooler, In/Out Hose, Air Intake Hose
- Inspect Steering Gear Rack, Linkage and Boots
- Inspect Suspension Mounting Bolts
- Inspect Vacuum Hose
- Replace Climate Control Air Filter
- Replace Coolant
- Replace Engine Oil and Filter
- Tire Rotation
- Add Fuel Additive (recommended only if TOP TIER Detergent

Gasoline is not available. See owner's manual for details.)

