



Jumper Positions for Drive B (default)

Jumper pins 15-10 for DS1



Jumper Positions for Drive A

Jumper pins 10-5 for DS0



The other two jumpers should be left as is, on the jumper block.

(JLC-05/27/94)