

IBM CONTROL CODES

00	Null
07	Sounds the Buzzer for one second
08	Backspace
09	Horizontal Tab
10	Line Feed
11	Vertical Tab (will be changed to Line Feed.)
12	Form Feed
13	Carriage Return
14	Double Width On
15	Compressed
18	Select 10 CPI
20	Double Width Off
24	Cancel
27,14	Double Width On
27,15	Compressed
27,45,n	Underline Start/End
27,48	1/8" Line Feed
27,49	1/10" Line Feed
27,50	Start Variable Line Feed
27,51,n	Variable Line Feed
27,52	Set Top of Form
27,53,n	Auto LF ON/OFF
27,54	Select Character Set 2
27,55	Select Character Set 1
27,56	Ignore Paper End
27,57	Cancel Ignore Paper End
27,58	Select 12 CPI
27,60	Home Head
27,65,n	Set Variable Line Feed
27,67,n	Set Lines Per Page
27,67,00,m	Set Inches Per Page
27,68,n1,n2,...nk,00	Set Horizontal Tab Stops
27,69	Emphasized
27,70	Emphasized Off
27,71	Double Strike
27,72	Double Strike Off
27,73,n	Font Select
27,74,n	Execute Variable Line Feed
27,75,n1,n2,d1,d2,d3,...	60 DPI Image Graphics Mode
27,76,n1,n2,d1,d2,d3,...	120 DPI Image Graphics Mode
27,78,n	Set Skip Perforation
27,79	Cancel Skip Perforation
27,80,n	Proportional Spacing Off
27,82	Reset All Tabs
27,83,n	Subscript/Superscript
27,84	Subscript/Superscript Off
27,85,n	Unidirectional Printing
27,87,n	Double Width On
27,89,n1,n1,d1,d2,d3,...	120 DPI Image Graphics Mode, Normal Mode
27,90,n1,n2,d1,d2,d3,...	240 DPI Image Graphics Mode
27,93	Reverse Line Feed 1/6"
27,94,n	Print Characters Below 32
27,61,C1,C2,C3,C4,C5,C6	Load User's Font

NOTES: The following control codes are available when character set 1 is selected.

135	BEL	(Same as 07)
136	BS	(Same as 08)
137	HT	(Same as 09)
138	LF	(Same as 10)
139	VT	(Same as 11)
140	FF	(Same as 12)
141	CR	(Same as 13)
142	SO	(Same as 14)
143	SI	(Same as 15)
146	DC2	(Same as 18)
148	DC4	(Same as 20)
152	CAN	(Same as 24)
155	ESC	(Same as 27)

The control code preceded by an ESCape code is handled in the same way as a control code not preceded by an ESCape code.

(css 07/26/93)