



#### Vertical and Horizontal Position:

If necessary, turn Horizontal Position control clockwise to move the display to the left or counterclockwise to move it to the right.

Turn Vertical Position control clockwise to move the display up or counterclockwise to move it down.

#### Contrast and Brightness:

Adjust the contrast and brightness controls to suit the room's lighting and your viewing preferences.

**CAUTION:** If the same characters or graphics are shown for a long period of time with the contrast and brightness controls set to their maximum positions, part of the screen might be damaged. Use these controls with care.

#### Power ON/OFF:

To turn on the VGM-225, press POWER. The POWER indicator lights. Press POWER again to turn off the monitor.