

**BIOS LISTING
for
CP/M 2.2.04**

595-3055

СЪВЕЩАНИЕ
ЮЛ
БИОГРАДИНО

```
1 0000          ORG    000H
2 0001 =        H17T   EQU    1
3 0000 =        H37T   EQU    0
4 0000 =        H47T   EQU    0
5 0000 =        H67T   EQU    0
```

```
6
7      ;+*****
```

```
8      ;+
9      ;+  * * * N O T E * * *
```

```
10     ;+
```

```
11     ;+ THE ABOVE 5 LINES OF CODE ARE THE PREAMBLE TO THE BIOS.
```

```
12     ;+ THESE LINES ARE USED BY "MAKEBIOS" IN GENERATING THE BIOS.
```

```
13     ;+ THESE LINES SHOULD NOT BE ALTERED FOR ANY REASON UNLESS THE
```

```
14     ;+ PROGRAM "MAKEBIOS" IS ALSO ALTERED. THESE LINES MUST APPEAR
```

```
15     ;+ AS THE FIRST 5 LINES IN THIS SOURCE.
```

```
16     ;+
```

```
17     ;+*****
```

```
18
19     PAGE
```

```
20
21
22 0004 = VERS EQU 04
23 0020 = LEVEL EQU >>
24 0009 = MONTH EQU 09
25 000F = DAY EQU 15
26 0052 = YEAR EQU 82
27
28 ;*****
29 ;+
30 ;+ BIOS2, A BIOS MODULE FOR CP/M 2.2
31 ;+ FOR USE WITH HEATH/ZENITH H/Z89 AND H-8 COMPUTERS
32 ;+ AND H17/H77/H87 5 1/4 INCH DISKS
33 ;+ AND H47/Z47 8 INCH DISKS
34 ;+ AND H37 5 1/4 INCH DISKS
35 ;+ AND H67 HARD DISK WITH 8 INCH FLOPPY
36 ;+ AND H8-4,H89-3 SERIAL I/O CARD
37 ;+ AND H89-11 H89 SERIAL/PARALLEL CARD
38 ;+
39 ;+ COPYRIGHT 1980,1981 HEATH COMPANY, BENTON HARBOR, MICHIGAN
40 ;+
41 ;*
42 ;+ HEATH/ZENITH SOFTWARE GROUP
43 ;+ HILLTOP ROAD
44 ;+ SAINT JOSEPH, MICHIGAN
45 ;
46 ; BECAUSE THIS CODE MUST BE ASSEMBLEABLE UNDER BOTH 'ASM' AND 'MAC',
47 ; THE CONDITIONALS MAY SEEM A LITTLE STRANGE. 'ASM' DOESN'T HAVE
48 ; THE FOLLOWING
49 ; 1) IF/THEN/ELSE STRUCTURE
50 ; 2) NESTED IF CAPABILITY
51 ; 3) RELATIONAL OPERATORS
52 ;+
53 ;*****
54
55 0000 = FALSE EQU 0
56 0001 = TRUE EQU 1
57 IF TRUE=1
58 %: TRUE NE 1
59 ENDIF
60
61 IF (H17+H37+H47+H67-1) SHR 15
62 %: NO DISK DRIVE TYPES SPECIFIED
63 ENDIF
64 IF (2-(H17+H37+H47+H67)) SHR 15
65 %: TOO MANY DISK DRIVE TYPES SPECIFIED
66 ENDIF
67
68
69 0000 = PARTITN EQU TRUE AND H67T ;FALSE = NO HARD DISK PARTITION SUPPORT
70 ;TRUE = SUPPORT HARD DISK PARTITIONING
71
72 0000 = H67PART2 EQU TRUE AND PARTITN ;FALSE = ONLY 1 PARTITION AT A TIME
73 ;TRUE = ALLOW 2 DRIVES (PARTITIONS)
74
75 0000 = EXPER EQU FALSE ;EXPERIMENTAL
```

```

76 0000 = TOD EQU FALSE ;TIME OF DAY HANDLER
77 0000 = EVENT EQU FALSE ;EVENT DOWN COUNTER
78 0001 = INTINP EQU TRUE ;ASSEMBLE WITH INTERRUPT CRT DRIVER
79 0000 = BRKKEY EQU FALSE AND INTINP ;TRUE = WARM START ON BREAK KEY
80 ;FALSE = NO SPECIAL PROCESSING
81 0000 = H37ED EQU TRUE AND H37T ;TRUE = BIOS SUPPORTS H37 EXTENDED
82 ; DOUBLE DENSITY
83 0000 = H47ED EQU TRUE AND H47T ;TRUE = BIOS SUPPORTS H47 EXTENDED
84 ; DOUBLE DENSITY
85
86 0003 = H17ND EQU 3*H17T ;NUMBER OF H17 DRIVES SUPPORTED
87 0000 = H37ND EQU 3*H37T ;NUMBER OF H37 DRIVES SUPPORTED
88 0000 = H47ND EQU 2*H47T ;NUMBER OF H47 DRIVES SUPPORTED
89 0000 = H67ND EQU 2*H67T+H67PART2 ;NUMBER OF H&7 DRIVES SUPPORTED
90
91 0000 = BIOS EQU $
92
93 F200 = BDOS EQU BIOS-0E00H
94 EA00 = CCP EQU BDOS-0800H
95 EA03 = CCPCLR EQU CCP+3
96 0000 = BOOT EQU 0000H ;BASE OF USABLE RAM
97 0003 = I0BYTE EQU BOOT+3 ;I/O DEVICE ASSIGNMENT BYTE
98 0004 = LOGDSK EQU BOOT+4 ;WHERE CPM STORES DEFAULT DRIVE
99 0040 = BDMAP EQU 0040H ;LOGICAL TO PHYSICAL DRIVE MAP
100 ; (UP TO 8 BYTES [DRIVES] 0040H-0047H)
101 0048 = BBDF EQU 0048H ;BOOT DEVICE FLAGS
102 0049 = BBDA EQU 0049H ;BOOT DEVICE ADDRESS (BASE PORT #)
103 004A = BBP EQU 004AH ;BOOT BEGINNING OF PARTITION
104 ; (3 BYTE VALUE)
105 004D = B0PB EQU 004DH ;BOOT LAST SECTOR OF PARTITION + 1
106 ; (3 BYTE VALUE)
107 004E = BB10S EQU 004EH ;CONTAINS ADDRESS OF START OF BIOS
108 ; AFTER COLD BOOT IS COMPLETED
109 005C = FCB EQU BOOT+5CH ;DEFAULT FILE CONTROL BLOCK
110 0080 = BUFF EQU BOOT+80H ;DEFAULT DISK BUFFER
111 0100 = TPA EQU BOOT+100H ;BASE OF TRANSIENT PGM AREA
112
113 PAGE

```

```

114
115 ;
116 ; H17 DISK RELATED EQUATES
117 ;
118
119 007C = UPDP EQU 07CH ;DISK DATA PORT
120 007D = UPFC EQU 07DH ;FILL CHARACTER
121 007E = UPST EQU 07EH ;STATUS FLAGS
122 007F = UPSC EQU 07FH ;SYNC CHARACTER (OUTPUT)
123 007G = UPSR EQU 07GH ;SYNC RESET (INPUT)
124 007H = DPDC EQU 07HH ;DISK CONTROL PORT
125
126 0002 = U0 EQU 02H ;H17 UNIT 0
127 0004 = U1 EQU 04H ; UNIT 1
128 0008 = U2 EQU 08H ; UNIT 2
129 0010 = DFMO EQU 10H ;MOTOR ON (ALL DRIVES)
130 0020 = DFDI EQU 20H ;DIRECTION (0 = OUT)
131 0040 = DFST EQU 40H ;STEP COMMAND (ACTIVE HIGH)
132
133 0001 = DFHD EQU 01H ;HOLE DETECT
134 0002 = DFTO EQU 02H ;TRACK 0 DETECT
135 0004 = DFWP EQU 04H ;WRITE PROTECT
136 0008 = DFSD EQU 08H ;SYNC DETECT
137
138 00FD = DSYN EQU 0FDH ;PREFIX SYNC CHARACTER
139
140 0014 = LPSA EQU 20 ;NUMBER OF TRIES FOR CORRECT SECTOR
141 0005 = STSA EQU 8/2+1 ;MS/2 TO WAIT FOR INDEX HOLE
142 0007 = STSB EQU 12/2+1 ;MS/2 TO WAIT PAST INDEX HOLE
143 0014 = WHDA EQU 20 ;UDLY COUNT FOR HOLE DEBOUNCE
144 0014 = WHNA EQU 20 ;UDLY COUNT FOR HOLE DEBOUNCE
145 0050 = WSCA EQU 64*25/20 ;LOOP COUNT FOR 25 CHARACTERS
146 0014 = WRITA EQU 20 ;GUARDBAND COUNT FOR WRITE
147 000A = WRITB EQU 10 ;NUMBER OF ZERO CHARACTERS AFTER HOLE EDGE
148 0010 = WRITC EQU 128/8 ;TWO CHARACTER DELAY BEFORE WRITING
149 0030 = READA EQU 48 ;DELAY BEFORE HUNT MODE
150 00FA = SPD EQU 250 ;250 * 4MS = 1 S
151 0014 = HLTG EQU 20 ; 20 * 4MS = 80 MS
152 0006 = HST EQU 24/4 ;HEAD SETTLE TIME 24 MS
153 000F = STEPR EQU 30/2 ;STEP RATE MS/2
154 000F = DELAYS EQU 6*256+15 ;HEAD LOAD AND MOTOR ON TIMER VALUES
155 000A = RETRIES EQU 10 ;NUMBER OF RETRIES
156
157 0001 = D$E$TRK EQU 001H ;BAD TRACK ERROR
158 0002 = D$E$HSY EQU 002H ;HEADER SYNC ERROR
159 0004 = D$E$HCK EQU 004H ;HEADER CHECKSUM
160 0008 = D$E$CHK EQU 008H ;CHECKSUM ERROR
161 0010 = D$E$RNF EQU 010H ;RECORD NOT FOUND
162 0020 = D$E$MDS EQU 020H ;MISSING DATA SYNC
163 0040 = D$E$WRP EQU 040H ;WRITE PROTECT ERROR
164 0080 = D$E$UNR EQU 080H ;UNIT NOT READY
165
166 PAGE

```

```
167
168
169 ;
170 ; H47 DISK EQUATES.
171 ;
172
173 0000 = H47CTL EQU 0 ;STATUS/CONTROL PORT DISPLACEMENT
174 0001 = H47DAT EQU 1 ;DATA PORT DISPLACEMENT
175
176 ; STATUS PORT BITS
177 0080 = DSTR EQU 10000000B ;TR
178 0040 = DSIE EQU 01000000B ;INT ENABLE
179 0020 = DSDONE EQU 00100000B ;DONE (I.E. NOT BUSY)
180 0001 = DSERR EQU 00000001B ;ERROR
181
182 ; CONTROL PORT BITS
183 0040 = DCIE EQU 01000000B ;INT ENABLE
184 0002 = DCRES EQU 00000010B ;RESET
185
186 ; COMMANDS
187 0001 = DRS EQU 01H ;READ STATUS
188 0002 = DRAS EQU 02H ;READ AUXILIARY STATUS
189 0003 = DSNS EQU 03H ;SET NUMBER OF SECTORS
190 0007 = DRD EQU 07H ;READ (BUFFERED)
191 0008 = DWR EQU 08H ;WRITE (BUFFERED)
192 000B = DCOPY EQU 0BH ;COPY
193 000D = DFMT EQU 0DH ;SINGLE DENSITY FORMAT
194 000E = DFMTD EQU 0EH ;FORMAT DOUBLE DENSITY (TRK 0 SINGLE)
195 000F = DFMTD2 EQU 0FH ;FORMAT DOUBLE DENSITY (TRK 0-76)
196
197 PAGE
```

```
198
199 ;
200 ; H37 EQUATES
201 ;
202
203 ; PORT ASSIGNMENTS
204 0078 = FD#BASE EQU 078H ;BASE PORT ADDRESS
205 0078 = FD#CON EQU FD#BASE ;DISK CONTROL PORT
206 0079 = FD#INT EQU FD#BASE+1 ;INTERFACE MUX PORT
207 007A = FD#CMD EQU FD#BASE+2 ;1797 COMMAND REGISTER
208 007A = FD#STA EQU FD#BASE+2 ; STATUS REGISTER
209 007B = FD#DAT EQU FD#BASE+3 ; DATA REGISTER
210 007A = FD#SEC EQU FD#BASE+2 ; SECTOR REGISTER
211 007B = FD#TRK EQU FD#BASE+3 ; TRACK REGISTER
212
213 ; INTERFACE MUX PORT FLAGS
214 0000 = FD#CD EQU 0 ;ACCESS C/D REGISTERS
215 0001 = FD#TS EQU 1 ;ACCESS T/S REGISTERS
216
217 ; COMMANDS
218 0000 = FDCRST EQU 000H ;RESTORE
219 0010 = FDCSEK EQU 010H ;SEEK
220 0020 = FDCSTP EQU 020H ;STEP
221 0040 = FDCSTI EQU 040H ;STEP IN
222 0060 = FDCSTO EQU 060H ;STEP OUT
223 0080 = FDCRDS EQU 080H ;READ SECTOR
224 00A0 = FDCWRS EQU 0A0H ;WRITE SECTOR
225 00C0 = FDCRDA EQU 0C0H ;READ ADDRESS
226 00E0 = FDCRDT EQU 0E0H ;READ TRACK
227 00F0 = FDCWRT EQU 0F0H ;WRITE TRACK
228 00D0 = FDCFI EQU 0D0H ;FORCE INTERRUPT
229
230 ; TYPE 1 COMMAND FLAGS
231 0010 = FDFUTR EQU 00010000B ;UPDATE TRACK REGISTER
232 0008 = FDFHLB EQU 00001000B ;HEAD LOAD AT BEGINNING
233 0004 = FDFVRF EQU 00000100B ;VERIFY FLAGS
234
235 ; TYPE 1 COMMAND STEP RATE FLAGS
236 0000 = FDFS6 EQU 00000000B ;STEP RATE 6 MS
237 0001 = FDFS12 EQU 00000001B ; 12
238 0002 = FDFS20 EQU 00000010B ; 20
239 0003 = FDFS30 EQU 00000011B ; 30
240
241 ; TYPE 2&3 COMMAND FLAGS
242 0010 = FDFMRF EQU 00010000B ;MULTIPLE RECORD FLAG
243 0008 = FDFSLE EQU 00001000B ;SECTOR LENGTH FLAG
244 0004 = FDFDLF EQU 00000100B ;30 MS DELAY
245 0002 = FDFSS1 EQU 00000010B ;SELECT SIDE 1
246 0001 = FDFDDM EQU 00000001B ;DELETED DATA MARK
247
248 ; TYPE 4 COMMAND FLAGS
249 0000 = FDFINI EQU 00000000B ;TERMINATE WITH NO INTERRUPT
250 0001 = FDFIIO EQU 00000001B ;NOT READY TO READY TRANSITION
251 0002 = FDFI11 EQU 00000010B ;READY TO NOT READY TRANSITION
252 0004 = FDFI12 EQU 00000100B ;INDEX PULSE
253 0008 = FDFI13 EQU 00001000B ;IMMEDIATE INTERRUPT
```



```

254
255 ; STATUS FLAGS
256 0080 = FDSNRD EQU 10000000B ;NOT READY
257 0040 = FDSWPV EQU 01000000B ;WRITE PROTECT VIOLATION
258 0020 = FDSHLD EQU 00100000B ;HEAD IS LOADED
259 0020 = FDSRTE EQU 00100000B ;RECORD TYPE
260 0020 = FDSWTF EQU 00100000B ;WRITE FAULT
261 0010 = FDSSEK EQU 00010000B ;SEEK ERROR
262 0010 = FDSRNF EQU 00010000B ;RECORD NOT FOUND
263 0008 = FDSCRC EQU 00001000B ;CRC ERROR
264 0004 = FDSTK0 EQU 00000100B ;FOUND TRACK 0
265 0004 = FDSLDT EQU 00000100B ;LOST DATA
266 0002 = FDSIND EQU 00000010B ;INDEX HOLE
267 0001 = FDSBSY EQU 00000001B ;BUSY
268
269 ; INFO RETURNED BY A READ ADDRESS COMMAND
270 0000 = FDRATRK EQU 0 ;TRACK
271 0001 = FDRASID EQU 1 ;SIDE
272 0002 = FDRASEC EQU 2 ;SECTOR
273 0003 = FDRASL EQU 3 ;SECTOR LENGTH
274 0004 = FDRACRC EQU 4 ;2 BYTE CRC
275 0006 = FDRAL EQU 6 ;LENGTH OF READ ADDRESS INFO
276
277 ; DISK HEADER SECTOR LENGTH VALUES
278 0000 = FDSL128 EQU 0 ;SECTOR LENGTH 128
279 0001 = FDSL256 EQU 1 ;SECTOR LENGTH 256
280 0002 = FDSL512 EQU 2 ;SECTOR LENGTH 512
281 0003 = FDSL1K EQU 3 ;SECTOR LENGTH 1024
282
283 ; CONTROL REGISTER FLAGS
284 0001 = CONIRQ EQU 00000001B ;ENABLE INT REQ
285 0002 = CONDR0 EQU 00000010B ;ENABLE DR0 INT / DISABLE SYSTEM INT
286 0004 = CONMFM EQU 00000100B ;ENABLE MFM
287 0008 = CONMO EQU 00001000B ;MOTOR(S) ON
288 0010 = CONDS0 EQU 00010000B ;DRIVE 0
289 0020 = CONDS1 EQU 00100000B ; 1
290 0040 = CONDS2 EQU 01000000B ; 2
291 0080 = CONDS3 EQU 10000000B ; 3
292
293 ; MISCELLANEOUS VALUES
294 0028 = NTRK37 EQU 40 ;NUMBER OF TRACKS SINGLE DENSITY (48 TPI)
295 0050 = NTRK037 EQU 80 ;NUMBER OF TRACKS DOUBLE DENSITY (96 TPI)
296 ;NSPTS37 EQU 10 ;NUMBER OF SECTORS PER TRACK
297 ; SINGLE DENSITY
298 ;NSPTD37 EQU 16 ;NUMBER OF SECTORS PER TRACK
299 ; DOUBLE DENSITY
300 ;NSPTE37 EQU 5 ;NUMBER OF SECTORS PER TRACK
301 ; EXTENDED DOUBLE DENSITY
302 ;ILFS37 EQU 3 ;INTERLEAVE FACTOR SINGLE DENSITY
303 ;ILFD37 EQU 3 ;INTERLEAVE FACTOR DOUBLE DENSITY
304 ;ILFE37 EQU 3 ;INTERLEAVE FACTOR EXTENDED DOUBLE DENSITY
305 003C = NSBT37 EQU 60 ;NUMBER OF CP/M RECORDS TO BE LOADED AT BOOT
306 0014 = FDHDD EQU 20 ;HOLE DEBOUNCE DELAY LOOP COUNTER VALUE
307 060F = DELAY37 EQU 6*256+15 ;DESELECT AND MOTOR TURN OFF DELAY
308
309 0020 = H37VEC EQU 3*4 ;LEVEL 4 INTERRUPT

```

```
310 0023 = DLYM037 EQU H37VEC+3 ;MOTOR TURN OFF DELAY COUNTER
311 0024 = DLYH37 EQU H37VEC+4 ;DESELECT DELAY COUNTER
312 0025 = H37CTL EQU H37VEC+5 ;H37 CONTROL REGISTER IMAGE
313 0026 = H37IREY EQU H37VEC+6 ;WHERE TO GO AFTER INTERRUPT ADDRESS
314
315 PAGE
```

```

316
317
318 ;
319 ; H&7 EQUATES.
320 ;
321
322 0001 = H67BLKIO EQU TRUE ;TRUE = USE Z80 BLOCK I/O
323 ;FALSE = 'USE' HANDSHAKE I/O'
324
325 0000 = SHUGART EQU FALSE ;TRUE = 'HARD DISK IS SHUGART'
326 ;FALSE = HARD DISK IS MEMOREX
327
328 ; PORT DISPLACEMENTS.
329 0000 = HD$DAT EQU 0 ;DATA PORT
330 0001 = HD$CON EQU 1 ;CONTROL PORT
331 0001 = HD$STA EQU 1 ;STATUS PORT
332 0002 = HD$SWI EQU 2 ;SWITCH PORT
333
334 ; CONTROL PORT FLAGS.
335 0080 = HDFACKH EQU 10000000B ;ACKNOWLEDGE HOLD
336 0040 = HDFSEL EQU 01000000B ;SELECT
337 0020 = HDFEI EQU 00100000B ;ENABLE INTERRUPTS
338 0010 = HDFRES EQU 00010000B ;RESET
339 0002 = HDFDE EQU 00000010B ;DATA ENABLE
340
341 ; BUS STATUS FLAGS.
342 0080 = HDBREQ EQU 10000000B ;REQUEST
343 0040 = HDBIO EQU 01000000B ;I/O (0=IN 1=OUT)
344 0020 = HDBMSG EQU 00100000B ;MSG
345 0010 = HDBCMD EQU 00010000B ;CMD/DATA (0=DATA 1=COMMAND)
346 0008 = HDBBSY EQU 00001000B ;BUSY
347 0004 = HDBPE EQU 00000100B ;PARITY ERROR
348 0002 = HDBIRQ EQU 00000010B ;INTERRUPT REQUEST
349 0001 = HDBACK EQU 00000001B ;HDS IS HOLDING ACKNOWLEDGE LYNE
350
351 ; COMMANDS.
352 0000 = HDCTDR EQU 000H ;TEST DRIVE READY
353 0001 = HDCRCL EQU 001H ;RECALIBRATE
354 0002 = HDCRSY EQU 002H ;REQUEST SYNDROME
355 0003 = HDCRS EQU 003H ;REQUEST SENSE
356 0004 = HDCFD EQU 004H ;FORMAT DRIVE
357 0006 = HDCFT EQU 006H ;FORMAT TRACK
358 0007 = HDCFBS EQU 007H ;FORMAT BAD SECTOR
359 0008 = HDCRD EQU 008H ;READ
360 0009 = HDCWPS EQU 009H ;WRITE PROTECT SECTOR
361 000A = HDCWR EQU 00AH ;WRITE
362 000B = HDCSEK EQU 00BH ;SEEK
363 0020 = HDCCPY EQU 020H ;COPY
364 00C0 = HDCFDD EQU 0C0H ;FLOPPY DISK DESCRIPTION
365
366 ; CLASS 0 COMMAND BLOCK STRUCTURE.
367 0000 = HD0OP EQU 0 ;OPCODE
368 0001 = HD0LULA EQU 1 ;LOGICAL UNIT #/LOGICAL ADDR
369 00E0 = HD0LUN EQU 11100000B ;BITS 7-5 = LOGICAL UNIT #
370 001F = HD0LA2 EQU 00011111B ;BITS 4-0 = LOGICAL ADDR (HIGH ORDER)
371 0002 = HD0LA1 EQU 2 ;LOGICAL ADDRESS (MIDDLE ORDER)

```

```

372 0003 = HDOLA0 EQU 3 ; LOGICAL ADDRESS (LOW ORDER)
373 0004 = HDONB EQU 4 ; NUMBER OF BLOCKS / INTERLEAVE FACTOR
374 0005 = HDOCON EQU 5 ; CONTROL
375
376 ; CLASS 1 COMMAND BLOCK STRUCTURE.
377 0000 = HDIOP EQU 0 ; OPCODE
378 0001 = HDILUAS EQU 1 ; SOURCE LOGICAL UNIT #/ADDR
379 00E0 = HDILUNS EQU 11100000B ; BITS 7-5 = LOGICAL UNIT #
380 001F = HDILA2S EQU 00011111B ; BITS 4-0 = LOGICAL ADDR (HIGH ORDER)
381 0002 = HDILA1S EQU 2 ; SOURCE LOGICAL ADDRESS (MIDDLE ORDER)
382 0003 = HDILA0S EQU 3 ; SOURCE LOGICAL ADDRESS (LOW ORDER)
383 0004 = HD1NB EQU 4 ; NUMBER OF BLOCKS
384 0005 = HDILUAD EQU 5 ; DESTINATION LOGICAL UNIT #/ADDR
385 00E0 = HD1LUND EQU 11100000B ; BITS 7-5 = LOGICAL UNIT #
386 001F = HD1LA2D EQU 00011111B ; BITS 4-0 = LOGICAL ADDR (HIGH ORDER)
387 0006 = HD1LA1D EQU 6 ; DESTINATION LOGICAL ADDR (MIDDLE ORDER)
388 0007 = HD1LA0D EQU 7 ; DESTINATION LOGICAL ADDR (LOW ORDER)
389 0008 = HD1SPAR EQU 8 ; SPARE
390 0009 = HD1CON EQU 9 ; CONTROL
391
392 ; CLASS 6 COMMAND BLOCK STRUCTURE.
393 0000 = HD6OP EQU 0 ; OPCODE
394 0001 = HD6LUN EQU 1 ; LOGICAL UNIT # (BITS 7-5)
395 0005 = HD6TFC EQU 5 ; TRACK FORMAT CODE
396
397 ; COMMAND BLOCK CONTROL BYTE FLAGS.
398 0080 = HDFDR EQU 10000000B ; DISABLE RETRIES
399 0040 = HDFDDEC EQU 01000000B ; DISABLE DATE ERROR CORRECTION
400
401 ; TRACK FORMAT CODE FLAGS.
402 0002 = HDFDEN EQU 00000010B ; DENSITY (0=SINGLE 1=DOUBLE)
403 0001 = HDFSID EQU 00000001B ; SIDES (0=SINGLE 1=DOUBLE)
404
405 ; COMPLETION STATUS BYTE FLAGS.
406 00E0 = HDFLUN EQU 11100000B ; LOGICAL UNIT # MASK
407 0002 = HDFERR EQU 00000010B ; ERROR DURING COMMAND EXECUTION
408 0001 = HDFPE EQU 00000001B ; PARITY ERROR
409
410 ; REQUEST SYNDROME BLOCK.
411 0000 = HDSMBO EQU 0 ; M.S. BIT OFFSET
412 0001 = HDLSLBS EQU 1 ; L.S. BIT OFFSET / SYNDROME
413 00E0 = HDFLBO EQU 11100000B ; BITS 7-5 = L.S. BIT OFFSET
414 000F = HDFSYN EQU 00001111B ; BITS 3-0 = SYNDROME
415
416 ; REQUEST SENSE BLOCK.
417 0000 = HDSSB EQU 0 ; SENSE BYTE
418 0080 = HDSBAV EQU 10000000B ; BLOCK ADDRESS VALID
419 0030 = HDSET EQU 00110000B ; ERROR TYPE MASK
420 000F = HDSEC EQU 00001111B ; ERROR CODE MASK
421 0001 = HDLULA EQU 1 ; LOGICAL UNIT #/LOGICAL ADDR
422 00E0 = HDLUN EQU 11100000B ; BITS 7-5 = LOGICAL UNIT #
423 001F = HDLSLA2 EQU 00011111B ; BITS 4-0 = LOGICAL ADDR (HIGH ORDER)
424 0002 = HDLSLA1 EQU 2 ; LOGICAL ADDRESS (MIDDLE ORDER)
425 0003 = HDSLAO EQU 3 ; LOGICAL ADDRESS (LOW ORDER)
426
427 ; ERROR CODE TABLE.

```

```

428 00F0 = HDECLS EQU 11110000B ;CLASS MASK
429 0000 = HDECLS0 EQU 000H ;CLASS 0
430 0010 = HDECLS1 EQU 010H ;CLASS 1
431 0020 = HDECLS2 EQU 020H ;CLASS 2
432 0080 = HDECLSZ EQU 080H ;ZDS EXTENSION CLASS
433 ; TYPE 0 (DRIVE) ERROR CODES
434 0000 = HDENS EQU 000H ;NO STATUS
435 0001 = HDENIS EQU 001H ;NO INDEX SIGNAL
436 0002 = HDENSC EQU 002H ;NO SEEK COMPLETE
437 0003 = HDENWF EQU 003H ;WRITE FAULT
438 0004 = HDENR EQU 004H ;DRIVE NOT READY
439 0005 = HDENSN EQU 005H ;DRIVE NOT SELECTED
440 0006 = HDENTO EQU 006H ;NO TRACK 00
441 0007 = HDENMS EQU 007H ;MULTI-DRIVE SELECTED
442 ; TYPE 1 (CONTROLLER) ERROR CODES
443 0010 = HDEIR EQU 010H ;ID READ
444 0011 = HDEUD EQU 011H ;UNCORRECTABLE DATA
445 0012 = HDEIAM EQU 012H ;ID ADDRESS MARK NOT FOUND
446 0013 = HDEDAM EQU 013H ;DATA ADDRESS MARK NOT FOUND
447 0014 = HDERNF EQU 014H ;RECORD NOT FOUND
448 0015 = HDESE EQU 015H ;SEEK ERROR
449 0017 = HDEWP EQU 017H ;WRITE PROTECTED
450 0018 = HDECDF EQU 018H ;CORRECTABLE DATA FIELD ERROR
451 0019 = HDEBBF EQU 019H ;BAD BLOCK FOUND
452 001A = HDEFE EQU 01AH ;FORMAT ERROR
453 ; TYPE 2 (COMMAND) ERROR CODES
454 0020 = HDEIC EQU 020H ;INVALID COMMAND
455 0021 = HDEIDA EQU 021H ;INVALID DISK ADDRESS
456 0022 = HDEIF EQU 022H ;ILLEGAL FUNCTION FOR THE DRIVE
457 ; ZDS ERROR CODES
458 0080 = HDENZM EQU 080H ;NON-ZERO MESSAGE BYTE
459 0081 = HDEBP EQU 081H ;BUS PARITY ERROR
460 0082 = HDEPAR EQU 082H ;PARITY ERROR
461 0083 = HDEOB EQU 083H ;SECTOR # OUT OF PARTITION BOUNDS
462 0084 = HDETO EQU 084H ;TIME OUT
463
464 ; MISCELLANEOUS EQUATES
465
466 0122 = H67MIN EQU 290 ;MINIMUM # OF SECTORS FOR A PARTITION
467 801A = H67MAX EQU 32794 ;MAXIMUM # OF USEABLE SECTORS
468 ; FOR A PARTITION
469
470 NSEC67 EQU SHUGART ;TOTAL NUMBER OF SECTORS FOR SHUGART
471 ELSE
472 9880 = NSEC67 EQU 39040 ;TOTAL NUMBER OF SECTORS FOR MEMOREX
473 ENDIF
474 001A = NSPT67 EQU 26 ;NUMBER OF SECTORS PER TRACK
475 0001 = NSYS67H EQU 1 ;NUMBER OF BOOT TRACKS FOR HARD DISK
476
477 PAGE

```

```
478
479 ;
480 ;MISC EQUATES
481 ;
482
483 00C3 = MI$JMP EQU 0C3H ;8080 JUMP INSTRUCTION
484
485 00F0 = H8CTL EQU 0F0H ;H8 CONTROL PORT
486 00D0 = H8TR EQU 0D0H ;H8 CLOCK TICK RESET
487
488 00F2 = H88CTL EQU 0F2H ;H88 CONTROL PORT
489 0020 = M1H EQU 020H ;KEEP RAM AT 0
490 0040 = I00 EQU 040H ;H17 SIDE SELECT
491 0002 = CLKE EQU 002H ;TURN ON 2MS CLOCK
492
493 0008 = CLKVEC EQU 0008H ;CLOCK INTERRUPT VECTOR
494 000B = TICCNT EQU 000BH ;TWO BYTE TICK COUNTER
495 000D = CTLPRT EQU 000DH ;CURRENT CONTENTS OF '89 CONTROL LATCH
496 000E = H8FLAG EQU 000EH ;CONTENTS = 0 FOR H/Z89, = H8TR FOR H8
497 000F = DEVCTL EQU 000FH ;CURRENT CONTENTS OF H17 CONTROL LATCH
498 0018 = SERVEC EQU 0008H*3 ;SERIAL INTERRUPT VECTOR (LEVEL 3)
499
500 PAGE
```

```
501
502 ;
503 ;MISC CPM EQUATES
504 ;
505
506 0003 = NDISKS EQU H17ND+H37ND+H47ND+H67ND ;MAXIMUM NUMBER OF DISKS
507 ; IN THIS SYSTEM
508 IF TRUE=1
509 %: TRUE NE 1
510 ENDIF
511 IF (8-NDISKS) SHR 15
512 %: NDISK GT 8 --- DRIVE MAP ONLY HAS 8 ENTRY SLOTS
513 ENDIF
514
515 002C = NSECTS EQU 44 ;NUM SECTS TO READ ON WM BOOT
516 ;
517 ; MAX HOST (PHYSICAL) SECTOR SIZE
518 IF (H47T AND H47ED) OR (H37T AND H37ED)
519 HSTSIZ EQU 1024 ;MAX HOST (PHYSICAL) SECTOR SIZE
520 ELSE
521 0100 = HSTSIZ EQU 256 ;MAX HOST (PHYSICAL) SECTOR SIZE
522 ENDIF
523
524 00FF = BT#WM EQU OFFH ;WARM BOOT FLAG
525 0000 = BT#CD EQU 000H ;COLD BOOT FLAG
526 ;
527 ;DEFAULT PORT ASSIGNMENTS
528 ;
529 00FA = H85CRT EQU 3720
530 00E8 = H84CRT EQU 0E8H
531 ; H89-11 PORTS
532 00D8 = H11TTY EQU 0D8H
533 00D0 = H11LPT EQU 0D0H
534 ; H89-3, H8-4 PORTS
535 00D0 = H84TTY EQU 0D0H
536 00E0 = H84LPT EQU 0E0H
537 00D8 = H84RDP EQU 0D8H
538 ;
539 ;BAUD RATE DIVISORS FOR 8250'S
540 ;
541 0600 = B75 EQU 1536
542 0417 = B110 EQU 1047
543 0359 = B134 EQU 857
544 0180 = B300 EQU 384
545 00C0 = B600 EQU 192
546 0060 = B1200 EQU 96
547 0030 = B2400 EQU 48
548 0018 = B4800 EQU 24
549 000C = B9600 EQU 12
550 0006 = B19200 EQU 6
551 ;
552 ;ASCII VALUES
553 ;
554 0000 = NULL EQU 00H
555 0003 = CTLC EQU 03H
556 0007 = BELL EQU 07H
```

557 000D = CR EQU ODH
558 000A = LF EQU OAH
559 000D = PADCH EQU CR
560
561 PAGE

;CHAR THAT GETS NULL PADDING, MUST NOT BE NULL


```
562
563      ;DEFAULT I/O BYTE
564      ;      CON: = CRT:
565      ;      RDR: = UR1:
566      ;      PUN: = UP1:
567      ;      LST: = LPT:
568      ;
569
570 0000 =      TTY      EQU      0
571
572 0001 =      CRT      EQU      1
573 0001 =      PTR      EQU      1
574 0001 =      PTP      EQU      1
575
576 0002 =      BAT      EQU      2
577 0002 =      UR1      EQU      2
578 0002 =      UP1      EQU      2
579 0002 =      LPT      EQU      2
580
581 0003 =      UC1      EQU      3
582 0003 =      UR2      EQU      3
583 0003 =      UP2      EQU      3
584 0003 =      UL1      EQU      3
585
586 00A9 =      DIOB     EQU      (CRT) OR (UR1 SHL 2) OR (UP1 SHL 4) OR (LPT SHL 6)
587
588      PAGE
```

```

589
590 ;
591 ; DEVICE DRIVER ENTRY JUMP VECTOR OFFSETS.
592 ;
593
594 0000 = DDSEL EQU 0 ;SELECT DISK
595 0003 = DDRD EQU 3 ;READ
596 0006 = DDWR EQU 6 ;WRITE
597 0009 = DDRES EQU 9 ;RESET
598 000C = DDMNT EQU 12 ;MOUNT
599
600 ;
601 ; DISK PARAMETER ENTRY DESCRIPTION.
602 ;
603
604 0000 = DPEXLT EQU 0 ;SECTOR TRANSLATE TABLE ADDRESS
605 000A = DPEDPB EQU 10 ;DISK PARAMETER BLOCK ADDRESS
606 0010 = DPEH7H EQU 16 ;HEATH EXTENSIONS
607 0018 = DPEL EQU 24 ;LENGTH OF DISK PARAMETER ENTRY
608
609 ; HEATH EXTENSIONS.
610 0010 = DPEFLAG EQU DPEH7H+0 ;FLAGS
611 00E0 = DPETYPE EQU 11100000B ;BIT 7-5 = DEVICE TYPE
612 0000 = DPENE EQU 00000000B ;NON-EXISTENT
613 0040 = DPEH17 EQU 01000000B ;H17
614 0060 = DPEH37 EQU 01100000B ;H37
615 0080 = DPEH47 EQU 10000000B ;H47
616 00C0 = DPEH67H EQU 11000000B ;H67 HARD DISK
617 00C8 = DPEH67F EQU 11001000B ;H67 FLOPPY DISK
618 00E8 = DPETYPF EQU DPETYPE OR DPEH67F ;H67 TYPE MASK
619 0010 = DPEP7C EQU 00010000B ;BIT 4 -- 0=BASE PORT 78H 1=PORT 7CH
620 0010 = DPE48RD EQU 00010000B ;BIT 4 -- FOR H37
621 ; 48 TPI MEDIA IN 96 TPI DRIVE (R/O)
622 0008 = DPE96T EQU 00001000B ;BIT 3 -- 0=48 TPI DRIVE 1=96 TPI DRIVE
623 0004 = DPEASGN EQU 00000100B ;BIT 2 -- FOR H67 HARD DISK
624 ;
625 ; 0=UNASSIGNED A PARTITION
626 ; 1=ASSIGNED A PARTITION
626 0004 = DPEED EQU 00000100B ;BIT 2 -- 1=EXTENDED DOUBLE DENSITY
627 0002 = DPEDD EQU 00000010B ;BIT 1 -- 0=SINGLE DENSITY 1=DOUBLE
628 0001 = DPE2S EQU 00000001B ;BIT 0 -- 0=SINGLE SIDED 1=DOUBLE
629
630 0011 = DPEUNIT EQU DPEH7H+1 ;UNIT SELECT VALUE
631 0012 = DPERPS EQU DPEH7H+2 ;CP/M RECORDS PER PHYSICAL SECTOR
632 0013 = DPERFAB EQU DPEH7H+3 ;CP/M RECORDS PER ALLOCATION BLOCK
633 0014 = DPETRK EQU DPEH7H+4 ;TRACK COUNTER
634 0080 = DPEUNK EQU 10000000B ;TRACK POSITION UNKNOWN
635 0015 = DPESEK EQU DPEH7H+5 ;MOTOR SPEED AND SEEK SPEED
636 ;BIT 6-0 = SEEK SPEED VALUE
637 0080 = DPEMD EQU 10000000B ;BIT 7 = MOTOR UP TO SPEED FLAG
638 ; 0=1 SEC 1=250 MSEC
639 0016 = DPEUPB EQU DPEH7H+6 ;H67 PARTITION UPPER BOUND + 1
640 0016 = DPEFLG2 EQU DPEH7H+6 ;2ND FLAG BYTE
641 0002 = DPEIMG EQU 00000010B ;BIT 1 IMAGINARY DRIVE
642 0001 = DPE96TM EQU 00000001B ;BIT 0 0=48 TPI MEDIA 1=96 TPI MEDIA
643 0017 = DPELUN EQU DPEH7H+7 ;LAST LOGICAL UNIT MOUNTED
644

```

```
645 0008 = DPEHL EQU 8 ;LENGTH OF HEATH EXTENSION
646
647 ;
648 ; DISK PARAMETER BLOCK.
649 ;
650
651 0000 = DPBSPT EQU 0 ;SECTORS PER TRACK
652 0002 = DPBBSH EQU DPBSPT+2 ;BLOCK SHIFT FACTOR
653 0003 = DPBBLM EQU DPBSPT+3 ;BLOCK MASK
654 0004 = DPBEXM EQU DPBSPT+4 ;EXTENT MASK
655 0005 = DPBDSM EQU DPBSPT+5 ;TOTAL # OF BLOCKS - 1
656 0007 = DPBDRM EQU DPBSPT+7 ;# OF DIRECTORY ENTRIES - 1
657 0009 = DPBALO EQU DPBSPT+9 ;INITIAL ALO VALUE
658 000A = DPBAL1 EQU DPBSPT+10 ;INITIAL AL1 VALUE
659 000B = DPBCKS EQU DPBSPT+11 ;SIZE OF DIRECTORY CHECK VECTOR
660 000D = DPBOFF EQU DPBSPT+13 ;NUMBER OF SYSTEM TRACKS
661 000F = DPBL EQU 15 ;LENGTH OF DISK PARAMETER BLOCK
662
663 ;*****
664 ;
665 ; DISK LABEL DEFINITIONS
666 ;
667 ; DISK LABELS ARE USED ON ALL SYSGEN'ED DISKS.
668 ; ALSO THE H37 AND H67 HARD DATA DISKS USE THE LABEL.
669 ; TO MAINTAIN COMPATIBILITY WITH OLDER RELEASES OF CP/M
670 ; THE H17, H47, AND H67 FLOPPY DATA DISKS DO NOT USE LABELS.
671 ;
672 ; THE LABEL RESIDES ON THE 1ST SECTOR OF TRACK 0.
673 ;
674 ; AT THE END OF THE LABEL IS A CHECKSUM. THE CHECKSUM IS CALCULATED
675 ; BY ADDING UP THE VALUES IN THE LABEL PRIOR TO THE CHECKSUM SLOT
676 ; A BYTE AT A TIME, THEN TAKING THE ONE'S COMPLEMENT OF THE SUM.
677 ;
678 ;*****
679
680 0000 = LABVER EQU 0 ;CURRENT FORM # FOR LABEL
681
682 0000 = LABBUF EQU 0 ;SLOT FOR JUMP INSTRUCTION AROUND LABEL
683 0003 = BDTYPE EQU LABBUF+3 ;SLOT FOR DRIVE TYPE
684
685 0004 = LABEL EQU LABBUF+4
686 0004 = LABTYP EQU LABEL+0 ;SLOT FOR LABEL TYPE
687 0005 = LABHTH EQU LABTYP+1 ;SLOT FOR HEATH EXTENSIONS TO DPE
688 000D = LABDPB EQU LABHTH+DPEHL ;SLOT FOR DISK PARAMETER BLOCK
689 001C = LABCS EQU LABDPB+DPBL ;CHECKSUM
690
691 0019 = LABLEN EQU LABCS-LABEL+1 ;LABEL LENGTH
692
693 PAGE
```

694

695

696

; SOFTWARE BOOT CODE DEFINITIONS

697

698

0000 =

SBC#SBC EQU

0

;SECTOR # OF SBC

699

700

0000 =

SBC#JMP EQU

0000H

;JUMP TO SOFTWARE BOOT CODE

701

0003 =

SBC#VER EQU

0003H

;SOFTWARE BOOT CODE VERSION NUMBER

702

0004 =

SBC#REV EQU

0004H

;SOFTWARE BOOT CODE REVISION NUMBER

703

0005 =

SBC#DBS EQU

0005H

;DEFAULT BOOT STRING

704

0018 =

SBC#BSA EQU

0018H

;SECTOR ADDR OF BAD SECTOR TABLE A

705

001B =

SBC#BSB EQU

001BH

;SECTOR ADDR OF BAD SECTOR TABLE B

706

001E =

SBC#SBA EQU

001EH

;SECTOR ADDR OF SUPER BLOCK A

707

0021 =

SBC#SBB EQU

0021H

;SECTOR ADDR OF SUPER BLOCK B

708

0024 =

SBC#SSZ EQU

0024H

;SECTOR SIZE

709

0026 =

SBC#SPT EQU

0026H

;SECTORS PER TRACK

710

0028 =

SBC#TPC EQU

0028H

;TRACKS PER CYLINDER

711

002A =

SBC#CPV EQU

002AH

;CYLINDERS PER VOLUME

712

002C =

SBC#SPS EQU

002CH

;SECTORS PER SLAB

713

002E =

SBC#VSZ EQU

002EH

;VOLUME SIZE (SECTORS PER VOLUME)

714

0031 =

SBC#NSL EQU

0031H

;NUMBER OF SLABS - 1

715

0032 =

SBC#CSA EQU

0032H

;CHECKSUM: SUPER BLOCK A

716

0034 =

SBC#CSB EQU

0034H

;CHECKSUM: SUPER BLOCK B

717

0036 =

SBC#CBA EQU

0036H

;CHECKSUM: BAD SECTOR TABLE A

718

0038 =

SBC#CBB EQU

0038H

;CHECKSUM: BAD SECTOR TABLE B

719

720

0080 =

SBC#LEN EQU

0080H

;SBC LENGTH

721

722

; SUPER BLOCK DEFINITIONS

723

724

0000 =

SPB#OSD EQU

0

;OPERATING SYSTEM DEFINITIONS

725

0001 =

SPB#PAT EQU

1

;PARTITION TABLE

726

727

; OPERATING SYSTEM NAME TABLE DEFINITIONS

728

729

0010 =

SPB#OSL EQU

16

;LENGTH OF EACH ENTRY

730

0010 =

SPB#OSN EQU

16

;NUMBER OF ENTRIES

731

732

; PARTITION TABLE ENTRIES

733

734

0000 =

SPB#OSI EQU

0

;OPERATING SYSTEM ID

735

001F =

SPB#OSM EQU

00011111B

;OPERATING SYSTEM ID MASK

736

001E =

SPB#UAR EQU

00011110B

;UNALLOCATED REGION

737

001F =

SPB#EOL EQU

SPB#OSM

;END OF LIST

738

739

0001 =

SPB#FSN EQU

1

;FIRST SECTOR # OF PARTITION

740

; (LOW,MID,HIGH)

741

742

0004 =

SPB#PEL EQU

4

;LENGTH OF ENTRY

743

744

; BAD SECTOR TABLE

745

746

0003 =

SBC#BEL EQU

3

;LENGTH OF ENTRY

747

748

749

PAGE

```

750
751 ;**
752 ;
753 ; EP3DEF = EQUATES FOR ENHANCED PROGRAMMABLE COMMUNICATION
754 ; INTERFACE CHIP 2661-3.
755 ;
756 ;
757 ; PORT DISPLACEMENTS
758 ;
759 0000 = EPDATA EQU 0 ;DATA
760 0001 = EPSTAT EQU 1 ;STATUS
761 0001 = EPSYN EQU 1 ;SYN1/SYN2/DLE
762 0002 = EPMODE EQU 2 ;MODE
763 0003 = EPCMD EQU 3 ;COMMAND
764 ;
765 ; STATUS REGISTER
766 ;
767 0001 = EPTXR EQU 00000001B ;TRANSMITTER READY
768 0002 = EPRXR EQU 00000010B ;RECEIVER READY
769 0004 = EPTXE EQU 00000100B ;TRANSMITTER EMPTY
770 0004 = EPDSC EQU 00000100B ;DATA SET CHANGE
771 0008 = EPPE EQU 00001000B ;PARITY ERROR
772 0010 = EPOE EQU 00010000B ;OVERRUN ERROR
773 0020 = EPFE EQU 00100000B ;FRAME ERROR
774 0020 = EPSD EQU 00100000B ;SYNC DETECTED
775 0040 = EPDCD EQU 01000000B ;DATA CARRIER DETECT
776 0080 = EPDSR EQU 10000000B ;DATA SET READY
777 ;
778 ; MODE REGISTER 1
779 ;
780 0003 = EPMBRF EQU 00000011B ;MODE AND BAUDRATE FACTOR
781 0000 = EPS1X EQU 000H ; SYNCHRONOUS 1X RATE
782 0001 = EPA1X EQU 001H ; ASYNCHRONOUS 1X RATE
783 0002 = EPA16X EQU 002H ; ASYNCHRONOUS 16X RATE
784 0003 = EPA64X EQU 003H ; ASYNCHRONOUS 64X RATE
785 ;
786 000C = EPCL EQU 00001100B ;CHARACTER LENGTH
787 0000 = EPCL5 EQU 000H ; LENGTH 5
788 0004 = EPCL6 EQU 004H ; LENGTH 6
789 0008 = EPCL7 EQU 008H ; LENGTH 7
790 000C = EPCL8 EQU 00CH ; LENGTH 8
791 ;
792 0010 = EPPC EQU 00010000B ;PARITY CONTROL (0=DISABLED , 1=ENABLED)
793 0020 = EPPT EQU 00100000B ;PARITY TYPE (0=ODD , 1=EVEN)
794 ;
795 00C0 = EPASBL EQU 11000000B ;ASYNCHRONOUS STOP BIT LENGTH
796 0040 = EPSB1 EQU 040H ; LENGTH 1
797 0080 = EPSB15 EQU 080H ; LENGTH 1.5
798 00C0 = EPSB2 EQU 0C0H ; LENGTH 2
799 ;
800 0040 = EPSTC EQU 01000000B ;SYNCHRONOUS TRANSPARENCY CONTROL
801 ; (0=NORMAL , 1=TRANSPARENT)
802 0080 = EPNSC EQU 10000000B ;NUMBER OF SYNC CHARACTERS
803 ; (0=DOUBLE , 1=SINGLE)
804 ;
805 ; MODE REGISTER 2

```

```
806
807 000F = EPBR5 EQU 00001111B ;BAUD RATE SELECTION
808 00F0 = EPBR2U EQU 11110000B ;SEE TEXT
809
810 ; COMMAND REGISTER
811
812 0001 = EPTXEN EQU 00000001B ;TRANSMITTER ENABLE
813 0002 = EPDTR EQU 00000010B ;DATA TERMINAL READY
814 0004 = EPRXEN EQU 00000100B ;RECEIVER ENABLE
815 0008 = EPSBRK EQU 00001000B ;SEND BREAK (ASYNC)
816 0008 = EPSDLE EQU 00001000B ;SEND DLE (SYNC)
817 0010 = EPRESE EQU 00010000B ;RESET STATUS ERRORS
818 0020 = EPRTS EQU 00100000B ;REQUEST TO SEND
819
820 00C0 = EPOM EQU 11000000B ;OPERATING MODE
821 0000 = EPNDRM EQU 000H ; NORMAL
822 0040 = EPOM1 EQU 040H ; MODE 1
823 0080 = EPOMLL EQU 080H ; LOCAL LOOP BACK
824 00C0 = EPOMRL EQU 0C0H ; REMOTE LOOP BACK
825
826 ; BAUDRATE SELECTION VALUES
827
828 0000 = EPB050 EQU 0 ;50
829 0001 = EPB075 EQU 1 ;75
830 0002 = EPB110 EQU 2 ;110
831 0003 = EPB134 EQU 3 ;134.5
832 0004 = EPB150 EQU 4 ;150
833 0005 = EPB300 EQU 5 ;300
834 0006 = EPB600 EQU 6 ;600
835 0007 = EPB120 EQU 7 ;1200
836 0008 = EPB180 EQU 8 ;1800
837 0009 = EPB200 EQU 9 ;2000
838 000A = EPB240 EQU 10 ;2400
839 000B = EPB360 EQU 11 ;3600
840 000C = EPB480 EQU 12 ;4800
841 000D = EPB720 EQU 13 ;7200
842 000E = EPB960 EQU 14 ;9600
843 000F = EPB192 EQU 15 ;19200
844
845 ;**
846 ;
847 ; PPDEF - EQUATES FOR PARALLEL PORT USING 8255.
848 ;
849 ;
850 ; PORT DISPLACEMENTS
851
852 0000 = PPDATA EQU 0 ;DATA PORT A
853 0001 = PPDATA EQU 1 ;DATA PORT B
854 0002 = PPDATA EQU 2 ;DATA PORT C
855 0003 = PPCTL EQU 3 ;CONTROL
856
857 ; CONTROL WORD
858
859 0080 = PPM5F EQU 10000000B ;MODE SET FLAG (0=BIT SET/RESET ,
860 ; 1=MODE SET)
861
```

```
.....
862 0060 = PPGAMS EQU 0110000B ;GROUP A MODE SELECT
863 0000 = PPGAM0 EQU 000H ; MODE 0
864 0020 = PPGAM1 EQU 020H ; MODE 1
865 0040 = PPGAM2 EQU 040H ; MODE 2
866
867 0010 = PPGAPA EQU 00010000B ;PORT A (0=OUTPUT , 1=INPUT)
868 0008 = PPGAPC EQU 00001000B ;PORT C UPPER (0=OUTPUT , 1=INPUT)
869
870 0004 = PPGBMS EQU 00000100B ;GROUP B MODE SELECT
871 0000 = PPGBM0 EQU 000H ; MODE 0
872 0004 = PPGBM1 EQU 004H ; MODE 1
873
874 0002 = PPGBPB EQU 00000010B ;PORT B (0=OUTPUT, 1=INPUT)
875 0001 = PPGBPC EQU 00000001B ;PORT C LOWER (0=OUTPUT , 1=INPUT)
876
877 000E = PPBSEL EQU 00001110B ;BIT SELECT
878 0000 = PPBS0 EQU 000H ; BIT 0
879 0002 = PPBS1 EQU 002H ; BIT 1
880 0004 = PPBS2 EQU 004H ; BIT 2
881 0006 = PPBS3 EQU 006H ; BIT 3
882 0008 = PPBS4 EQU 008H ; BIT 4
883 000A = PPBS5 EQU 00AH ; BIT 5
884 000C = PPBS6 EQU 00CH ; BIT 6
885 000E = PPBS7 EQU 00EH ; BIT 7
886
887 0001 = PPBSR EQU 000000001B ;BIT SET/RESET (0=RESET, 1=SET)
888
889 ;**
890 ;
891 ; H8911DEF - EQUATES FOR H89-11
892 ;
893 ;
894 ; 2661-3 SERIAL PORT
895 ;
896 0004 = EPINT EQU 4 ;INTERRUPT ENABLE REGISTER
897 0001 = EPIE EQU 00000001B ;0=DISABLE , 1=ENABLE
898
899 ; PARALLEL PORT PRINTER
900
901 0001 = PPDS EQU 00000001B ;DATA STROBE
902 0080 = PPRDY EQU 10000000B ;PRINTER READY
903
904 PAGE
```

```
905
906      ;
907      ; ENTRY POINT TABLE
908      ;
909      0000 C3320D      JMP      CBOOT      ;FROM COLD START LOADER
910      0003 C39A00      WBOOT:  JMP      WBOOT      ;TO INITIATE A WARM BOOT
911      0006 C3E108      JMP      CONST      ;CHECK CONSOLE STATUS
912      0009 C30609      JMP      CONIN      ;READ CONSOLE CHAR
913      000C C31409      JMP      CONOUT     ;WRITE CONSOLE CHAR
914      000F C33209      JMP      LIST       ;WRITE LIST DEVICE CHAR
915      0012 C34209      JMP      PUNCH      ;WRITE PUNCH DEVICE CHAR
916      0015 C35309      JMP      READER     ;READ CHAR FROM READER
917      0018 C37B01      JMP      HOME       ;SET DISK TO TRACK ZERO
918      001B C38E01      JMP      SETDSK     ;SELECT DISK DRIVE
919      001E C38801      JMP      SETTRK     ;SEEK TO TRACK
920      0021 C31602      JMP      SETSEC     ;SET SECTOR NUMBER
921      0024 C31C02      JMP      SETDMA     ;SET STARTING ADDRESS FOR DISK I/O
922      0027 C32F02      JMP      READ       ;READ SELECTED SECTOR
923      002A C34302      JMP      WRITE      ;WRITE SELECTED SECTOR
924      002D C32209      JMP      LISTST     ;CHECK LIST DEVICE STATUS
925      0030 C32202      JMP      SECTRAN    ;SECTOR TRANSLATE ROUTINE
926
927      PAGE
```



```

928
929 ;*****
930 ;
931 ; BIOS HEADER SECTION.
932 ;
933 ; *** NOTE ***
934 ;
935 ; IF THIS SECTION IS ALTERED, THEN THE FILE 'BIOSDEF.LIB'
936 ; MUST ALSO BE UPDATED.
937 ;
938 ;*****
939 ;
940 0033 04      BIOSVER DB      VERS          ;BIOS VERSION
941 0034 A9      DEFIOB  DB      DIOB          ;DEFAULT IOBYTE
942 0035 10      PRTRDY  DB      010H         ;SERIAL PRINTER (LPT) READY MASK
943 ;           ; (CTS = 010H WHICH IS DEFAULT
944 ;           ; DSR = 020H)
945 ;
946 0036 00      MODE    DB      PARTITN*MODEB3
947 0001 =       MODEB0  EQU      00000001B   ;BIT 0  1=CRT ON HS-5 CARD
948 0002 =       MODEB1  EQU      00000010B   ;BIT 1  1=EXTENDED DISK ERROR MSG'S
949 0004 =       MODEB2  EQU      00000100B   ;BIT 2  0 = SERIAL LPT READY IS LOW
950 ;           ; 1 = SERIAL LPT READY IS HIGH
951 0008 =       MODEB3  EQU      00001000B   ;BIT 3  1=PARTITIONING USED
952 0040 =       MODEB6  EQU      01000000B   ;BIT 6  1=RUN 'AUTO' ON WARM BOOT
953 0080 =       MODEB7  EQU      10000000B   ;BIT 7  1=RUN 'AUTO' ON COLD BOOT
954 ;
955 0037 06      MODE2   DB      MODE2B2+MODE2B1
956 0001 =       MODE2B0 EQU      00000001B   ;BIT 0  0=H89-3 OR H8-4
957 ;           ; 1=H89-11
958 0002 =       MODE2B1 EQU      00000010B   ;BIT 1  0=H89-11 LPT IS SERIAL
959 ;           ; 1=H89-11 LPT IS PARALLEL
960 0004 =       MODE2B2 EQU      00000100B   ;BIT 2  0=PARALLEL LPT READY IS LOW
961 ;           ; 1=PARALLEL LPT READY IS HIGH
962 ;
963 ; SERIAL DEVICE STRUCTURES
964 ;     DB      PORT$NUMBER
965 ;     DW      CONTROL$WORD
966 ;           WHERE THE CONTROL$WORD CONTAINS
967 ;           B15      MAP LOWER TO UPPER CASE
968 ;           B14-B12 NUMBER OF NULLS AFTER A CR
969 ;           B11-B00 BAUD RATE DIVISOR
970 ;
971 0038 E8      H84PT1: DB      H84CRT
972 0039 0C00    CRTBAUD DW      B9600
973 003B D0      H84PT2: DB      H84TTY
974 003C 8001    TTYBAUD:DW      B300
975 003E E0      H84PT3: DB      H84LPT
976 003F 1800    LPTBAUD:DW      B4800
977 0041 D8      H84PT4: DB      H84RDP
978 0042 8001    RDPBAUD:DW      B300
979 0044 D8      H11PT2: DB      H11TTY
980 0045 0500    TTY11B  DW      EPB300
981 0047 D0      H11PT3: DB      H11LPTF
982 0048 0000    DW      0
983 ;

```

```
984 004A 12      BSIZE  DB      (BIOSEND-BIOS+255)/256 ;BIOS SIZE IN PAGES
985 004B 1211    BEND   DW      BIOSEND ;ENDING ADDRESS OF BIOS + 1
986 004D 0000    SECNT17 DW      0 ;H17 SOFT ERROR COUNT (SINCE COLD BOOT)
987 004F 0000    SECNT37 DW      0 ;H37 SOFT ERROR COUNT (SINCE COLD BOOT)
988 0051 03      BNDISKS DB      NDISKS ;NUMBER OF DISKS POSSIBLE IN THIS BIOS
989
990 0052          DPBASE DS      0 ;START OF DISK PARAMETER ENTRY TABLES
991
992             PAGE
```

```

993
994          IF          H17T
995 0052 1B0D0000 DPE0   DW      XLT17,0000H      ;TRANSLATE TABLE
996 0056 00000000      DW      0000H,0000H      ;SCRATCH
997 005A 320E0C0D      DW      DIRBUF,DPB17S    ;DIR BUFF, PARM BLK
998 005E BE0EB20E      DW      CSV0;ALV0      ;CHECK;ALLOC VEC
999 0062 40           DB      DPEH17          ;DISK TYPE
1000 0063 02          DB      U0            ;SELECT CODE
1001 0064 02          DB      2            ;NUMBER OF 128 BYTE RECORDS/PHYSICAL SECTOR
1002 0065 08          DB      8            ;NUMBER OF RECORDS/ALLOCATION BLOCK
1003 0066 FF          DB      OFFH         ;TRACK LOCATION
1004 0067 0F          DB      STEPR        ;STEP RATE
1005 0068 00          DB      0            ;FLAG BYTE 2
1006 0069 00          DB      0            ;'REAL' - LAST DISK MOUNTED
1007                                     ;'IMAGINARY' - CORRESPONDING REAL
1008                                     ;'DRIVE'S LOGICAL UNIT #'
1009 006A 1B0D0000 DPE1   DW      XLT17,0000H
1010 006E 00000000      DW      0000H,0000H
1011 0072 320E0C0D      DW      DIRBUF,DPB17S
1012 0076 DA0ECE0E      DW      CSV1;ALV1
1013 007A 40           DB      DPEH17
1014 007B 04          DB      U1
1015 007C 02          DB      2
1016 007D 08          DB      8
1017 007E FF          DB      OFFH
1018 007F 0F          DB      STEPR
1019 0080 00          DB      0
1020 0081 00          DB      0
1021 0082 1B0D0000 DPE2   DW      XLT17,0000H
1022 0086 00000000      DW      0000H,0000H
1023 008A 320E0C0D      DW      DIRBUF,DPB17S
1024 008E F60EEA0E      DW      CSV2;ALV2
1025 0092 40           DB      DPEH17
1026 0093 08          DB      U2
1027 0094 02          DB      2
1028 0095 08          DB      8
1029 0096 FF          DB      OFFH
1030 0097 0F          DB      STEPR
1031 0098 00          DB      0
1032 0099 00          DB      0
1033                                     ENDIF
1034
1035          IF          H37T
1036          DPE37#0     DW      0000H,0000H      ;TRANSLATE TABLE
1037          DW      0000H,0000H      ;SCRATCH
1038          DW      DIRBUF,DPB37#0    ;DIR BUFF, PARM BLK
1039          DW      CSV37#0,ALV37#0
1040          DB      DPEH37+DPEDD     ;ASSUME DOUBLE DENSITY AT COLD BOOT
1041          DB      CONDS0
1042          DB      2
1043          DB      8
1044          DB      DPEUNK
1045          DB      FDFS30
1046          DB      0
1047          DB      0
1048          DPE37#1     DW      0000H,0000H

```

```
.....
1049          DW      0000H,0000H
1050          DW      DIRBUF,DPB37#1
1051          DW      CSV37#1,ALV37#1
1052          DB      DPEH37+DPEDD
1053          DB      CONDS1
1054          DB      2
1055          DB      8
1056          DB      DPEUNK
1057          DB      FDFS30
1058          DB      0
1059          DB      0
1060          DPE37#2 DW      0000H,0000H
1061          DW      0000H,0000H
1062          DW      DIRBUF,DPB37#2
1063          DW      CSV37#2,ALV37#2
1064          DB      DPEH37+DPEDD
1065          DB      CONDS2
1066          DB      2
1067          DB      8
1068          DB      DPEUNK
1069          DB      FDFS30
1070          DB      0
1071          DB      0
1072          ENDIF
1073
1074          IF      H47T
1075          DPE47#0 DW      XLT0S,0000H      ;TRANSLATE TABLE
1076          DW      0000H,0000H      ;SCRATCH
1077          DW      DIRBUF,DPBOSS      ;DIR BUFF, PARM BLK
1078          DW      CSV47#0,ALV47#0      ;CHECK, ALLOC VEC
1079          DB      DPEH47
1080          DB      000H
1081          DB      1
1082          DB      8
1083          DB      0,0,0,0
1084          DPE47#1 DW      XLT0S,0000H
1085          DW      0000H,0000H
1086          DW      DIRBUF,DPBOSS
1087          DW      CSV47#1,ALV47#1
1088          DB      DPEH47
1089          DB      020H
1090          DB      1
1091          DB      8
1092          DB      0,0,0,0
1093          ENDIF
1094
1095          IF      H67T
1096          DPE67#0 DW      0000H,0000H
1097          DW      0000H,0000H
1098          DW      DIRBUF,DPB67#0
1099          DW      0000H,ALV67#0
1100          DB      DPEH67H      ;H67 HARD DISK
1101          DB      0      ;SELECT
1102          DB      2      ;LOGICAL IN EACH PHYSICAL
1103          DB      32      ;ALLOCATED AT ONCE
1104          DW      0      ;TRACK 0 OFFSET
.....
```



```

1130
1131 ;
1132 ; WARM BOOT -- READ IN BDOS AND CCP
1133 ; INITIALIZE
1134 ; JUMP TO CCP
1135 ;
1136
1137 009A 311211 WBOOT: LXI SP,STACK ;SET STACK POINTER
1138 009D FB EI ;INSURE INTERRUPTS ARE ENABLED
1139
1140 009E AF XRA A
1141 009F 4F MOV C,A ;BOOT FROM DRIVE 0
1142 00A0 5F MOV E,A ;ACT LIKE THIS IS THE FIRST LOGIN
1143 00A1 CD8E01 CALL SETDSK
1144 00A4 7C MOV A,H
1145 00A5 B5 ORA L
1146 00A6 CA6301 JZ WBTE ; BR IF SELECT ERROR
1147 00A9 E5 PUSH H ;GET POINTER TO XLATE AND SPT VALUE FOR
1148 ; TRACKS 1 TO N
1149 00AA CDC608 CALL HLIHL ;GET THE POINTER TO THE TRANSLATE TABLE
1150 00AD 229610 SHLD XLTW1 ; AND SAVE IT
1151 00B0 229310 SHLD XLTW
1152 00B3 E1 POP H
1153 00B4 E5 PUSH H
1154 00B5 110A00 LXI D,DPEDPB ;GET THE POINTER TO THE DISK PARAM BLOCK
1155 00B8 19 DAD D
1156 00B9 CDC608 CALL HLIHL
1157 00BC 7E MOV A,M ;THE FIRST ENTRY OF WHICH IS THE NUMBER
1158 00BD 329510 STA SPT1 ; OF SECTORS PER TRACK
1159 00C0 329210 STA SPT
1160 00C3 E1 POP H
1161
1162 IF H47T OR H67T
1163 PUSH H
1164 LXI D,DPEH47
1165 DAD D ;GET POINTER TO HEATH DISK TABLE
1166 MOV A,M ;GET TYPE BYTE
1167 MOV C,A
1168 ANI DPETYPE
1169 CPI DPEH47 ;CHECK FOR TYPE H47
1170 JZ WBTOX ;IS H47
1171 MOV A,C
1172 ANI DPETYFF
1173 CPI DPEH67F ;CHECK FOR TYPE H67 FLOPPY
1174 JNZ WBTO ;IF NOT H47 OR H67, THEN USE THESE VALUES
1175 WBOOT: MVI A,26 ; ELSE USE SINGLE DENSITY VALUES
1176 LXI H,XLT0S ; FOR TRACK 0
1177 STA SPT
1178 SHLD XLTW
1179 WBOOT: POP H
1180 ENDIF
1181
1182 00C4 111000 LXI D,DPEH47
1183 00C7 19 DAD D ;GET POINTER TO HEATH DISK TABLE
1184 00C8 1180E9 LXI D,CCP-128 ;ASSUME STARTING ADDRESS OF BOOT TRACK
1185 00CB 01002C LXI B,NSECTS*256 ;B = # OF SECTORS; C = STARTING SECTOR

```

```

1186
1187             IF      H37T OR H67T
1188             MOV     A,M           ;GET TYPE BYTE
1189             ANI     DPEH37
1190             CPI     DPEH37       ;CHECK FOR H37
1191             JZ      WBT0Y        ;BR IF H37
1192             CPI     DPEH67H      ;CHECK FOR H67
1193             JNZ     WBT0Z        ;BR IF NOT H67
1194             WBT0Y: LXI     D,CCP-256 ;RESET STARTING ADDRESS OF BOOT TRACK
1195             ENDIF
1196
1197             00CE 210000   WBT0Z: LXI     H,0           ;STARTING TRACK = 0
1198
1199             00D1 22A210   WBT1:  SHLD    SEKTRK
1200             00D4 EB           XCHG
1201             00D5 229010   SHLD    DMAB           ;STARTING DMA ADR FOR THIS TRACK
1202
1203             00D8 C5           WBT2:  PUSH   B
1204             00D9 0600        MVI     B,0           ;TRANSLATE SECTOR IN BC
1205             00DB 2A9310     LHLD    XLTW
1206             00DE EB           XCHG
1207             00DF CD2202     CALL   SECTRAN
1208             00E2 4D           MOV     C,L           ;TRANSLATED SECTOR IN HL
1209             00E3 7D           MOV     A,L
1210             00E4 F5           PUSH   PSW
1211             00E5 CD1602     CALL   SETSEC        ;SET THIS AS THE SECTOR TO READ
1212             00E8 F1           POP    PSW
1213             00E9 3D           DCR    A              ;CHANGE SECTOR NUMBER TO 0 THRU SPT-1
1214             00EA CD6F01     CALL   CDA           ;CORRECT DMA ADDRESS FOR THIS SECTOR
1215             00ED 22B210     SHLD   DMAADR
1216             00F0 7C           MOV     A,H
1217             00F1 FE0A        CPI     CCP/256       ;0. IS THIS SECTOR PART OF BOOT CODE
1218             00F3 DA0801     JC     WBT3          ;YES, SO DON'T REALLY READ IT
1219             00F6 FE00        CPI     BIOS/256     ;IS THIS SECTOR PART OF THE BIOS
1220             00F8 D20801     JNC    WBT3          ;YES, SO DON'T REALLY READ IT
1221
1222             00FB CD2F02     CALL   READ          ;READ THIS SECTOR
1223
1224             00FE B7           ORA    A              ;CHECK FOR ERRORS
1225             00FF C26301     JNZ    WBTE
1226
1227             0102 C1           POP    B
1228             0103 05           DCR    B              ;COUNT THIS SECTOR AS READ
1229             0104 CA2C01     JZ     WBT4          ;IF THAT IS THE LAST ONE, SET POINTERS & LEAVE
1230
1231             0107 C5           WBT3: PUSH   B
1232             0108 C1           POP    B
1233             0109 0C           INR    C              ;NEXT SECTOR
1234             010A 3A9210     LDA    SPT           ;NUMBER OF SECTORS PER TRACK
1235             010D B9           CMP    C              ;HAVE WE OVERFLOWED TO NEXT TRACK?
1236             010E C2D800     JNZ    WBT2          ;NO
1237             0111 0E00        MVI    C,0
1238             0113 CD6F01     CALL   CDA           ;UPDATE TRACK STARTING ADDRESS
1239
1240             0116 E5           PUSH   H
1241             0117 3A9510     LDA    SPT1          ;BEYOND TRACK 0,

```

```

1242 011A 329210 STA SPT ; SO UPDATE SPT AND XLTW TO BE THE VALUES
1243 011D 2A9610 LHL XLTW1 ; FOR TRACKS 1 AND BEYOND
1244 0120 229310 SHLD XLTW
1245 0123 E1 POP H
1246
1247 0124 EB XCHG
1248 0125 2AA210 LHL SEKTRK
1249 0128 23 INX H
1250 0129 C3D100 JMP WBT1
1251
1252 012C 3EFF WBT4: MVI A,BT#WM ;FLAG THIS AS A WARM BOOT
1253
1254 012E F5 GOW: PUSH PSW ;SAVE THE BOOT TYPE
1255
1256 012F 3EC3 MVI A,MI#JMP ;INITIALIZE BIOS AND BDOS VECTORS
1257 0131 210300 LXI H,WBOOT
1258 0134 320000 STA BOOT
1259 0137 220100 SHLD BOOT+1
1260 013A 2106F2 LXI H,BDOS+6
1261 013D 320500 STA BOOT+5
1262 0140 220600 SHLD BOOT+6
1263
1264 0143 018000 LXI B,BUFF ;SET DEFAULT DMA ADDRESS
1265 0146 CD1C02 CALL SETDMA
1266
1267 0149 CD1204 CALL FLUSH1 ;RE-INIT HOST DEBLOCKING
1268
1269 014C F1 POP PSW ;GET THE BOOT TYPE
1270 014D 0F RRC ; CARRY SET IF WARM BOOT
1271 014E 3A3600 LDA MODE
1272 0151 D25501 JNC GOW1 ; IF WARM BOOT
1273 0154 17 RAL ; THEN SHIFT LEFT TWICE
1274 0155 17 GOW1: RAL ;CARRY SET IF TO RUN AUTO
1275 0158 3A0400 LDA LOGDSK ;GET DISK NUMBER TO
1276 0159 32A110 STA SEKDSK ; SAVE AS DESIRED DISK
1277 015C 4F MOV C,A ; PASS TO CCP IN C
1278 015D DA00EA JC CCP ;EXECUTE AUTO
1279 0160 C303EA JMP CCPCLR ;EXECUTE CCP
1280
1281
1282 0163 21C00C WBTE: LXI H,BTMSG ;PRINT BOOT ERROR MESSAGE
1283 0166 CD9B0C CALL PMSG
1284 0169 CD0609 CALL CONIN ;WAIT FOR KEYBOARD
1285 016C C39A00 JMP WBOOT ;TRY AGAIN
1286
1287 PAGE

```



```
.....
1288
1289 ;CDA - CORRECT DMA ADDRESS
1290 ; ENTRY A = RECORDS TO ADJUST
1291 ; DMAB = STARTING ADDRESS OF TRACK
1292 ; EXIT HL = CORRECTED ADDRESS
1293 ;
1294
1295 016F 2A9010 CDA: LHLD DMAB ;GET STARTING ADDRESS OF TRACK
1296 0172 B7 ORA A ;CLEAR CARRY
1297 0173 1F RAR ;DIVIDE BY 2
1298 0174 57 MOV D,A ; D = A/2
1299 0175 3E00 MVI A,0
1300 0177 1F RAR
1301 0178 5F MOV E,A ; E = 00H OR 80H
1302 0179 19 DAD D
1303 017A C9 RET
1304
1305 PAGE
.....
```

```
1306
1307 ;
1308 ; HOME - SEEK HEAD TO TRACK 0 (DEFERRED)
1309 ;
1310
1311 017B 3A300D HOME: LDA HSTWRT ;CHECK FOR PENDING WRITE
1312 017E B7 ORA A
1313 017F C28501 JNZ HOMED
1314 0182 322F0D STA HSTACT ;CLEAR HOST ACTIVE FLAG
1315 0185 010000 HOMED: LXI B,0 ;SET TO TRACK 0
1316
1317 ;
1318 ; SETTRK - SET DISK TRACK NUMBER
1319 ; ENTRY: BC DESIRED TRACK ( 0 TO N-1 )
1320 ;
1321
1322 0188 60 SETTRK: MOV H,B
1323 0189 69 MOV L,C
1324 018A 22A210 SHLD SEKTRK
1325 018D C9 RET
1326
1327 PAGE
```

```

1328
1329
1330
1331          SETDSK - SELECT A DISK DRIVE
1332          ENTRY: C      DESIRED DISK
1333          E      LSB = 0 IF FIRST LOGIN
1334
1335 018E 7B      SETDSK: MOV    A,E
1336 018F 32F001 STA    SETDSKB      ;SAVE 1ST FLAG
1337 0192 79      MOV    A,C      ;GET THE DRIVE # FROM C
1338 0193 32EF01 STA    SETSKA      ;SAVE LOGICAL UNIT NAME
1339 0196 FE03    CPI    NDISKS    ;CHECK IF LEGAL
1340 0198 D2DF01 JNC    SETDE      ; BR IF NOT
1341
1342 019B 214000 LXI    H,BDMAP    ;GET MAPPED DRIVE #
1343 019E CDA808 CALL   DADA      ;(HL)=POINTER TO LOGICAL/MAPPED DRIVE #
1344 01A1 7E      MOV    A,M      ;GET LOGICAL/MAPPED DRIVE #
1345 01A2 32A110 STA    SEKDSK     ;SAVE IT
1346 01A5 CDAD08 CALL   GETDPE     ;GET ADDR OF DPE
1347 01A8 22F101 SHLD   SETDSKC    ;SAVE ADDR OF DPE
1348 01AB 111000 LXI    D,DPEHTH   ;GET ADDR OF DPE'S HEATH EXTENSIONS
1349 01AE 19      DAD    D
1350 01AF 228C10 SHLD   DPBX      ;SAVE IT
1351
1352          IF    PARTITN
1353          MOV    A,M      ;GET HEATH EXTENSION FLAG BYTE
1354          ANI    DPETYFF
1355          CPI    DPEH67H
1356          JNZ   SETDSK1   ;BR IF NOT H67 HARD DISK
1357          MOV    A,M
1358          ANI    DPEASGN   ;CHECK IF PARTITION IS ASSIGNED
1359          JZ    SETDE     ;BR IF NOT
1360          ENDIF
1361
1362          SETDSK1:
1363 01B2 3AF001 LDA    SETDSKB    ;RESTORE FIRST LOGIN FLAG
1364 01B5 1F      RAR
1365 01B6 DADB01 JC     SETDSK2   ; BR IF NOT
1366
1367 01B9 CD0404 CALL   FLUSH      ;FLUSH HOST BUFFER (I MAY NEED IT
1368                                     ; AND ITS ASSOCIATED VARIABLES)
1369
1370 01BC 213600 LXI    H,MODE     ;SAVE MODE
1371 01BF 7E      MOV    A,M
1372 01C0 32F301 STA    SETDSKD    ;TURN OFF EXTENDED ERROR MSG'S
1373 01C3 E&FD    ANI    OFFH-MODEB1
1374 01C5 77      MOV    M,A
1375
1376 01C6 3AA110 LDA    SEKDSK     ;SET HOST DPE'S HEATH EXTENSION
1377 01C9 CD5104 CALL   SHD      ; ADDR AND SWAP DISK IF NEEDED
1378
1379 01CC 110000 LXI    D,DBSEL    ;CALL DEVICE DRIVER FOR SELECT
1380 01CF CDF401 CALL   DSKDIS
1381
1382 01D2 3AF301 LDA    SETDSKD    ;RESTORE BIOS MODE BYTE
1383 01D5 323600 STA    MODE

```

```
1384
1385 01D8 DADF01          JC      SETDE          ; BR IF ERROR RETURNED BY DEVICE DRIVER
1386
1387                      SETDSK2:
1388 01DB 2AF101          LHL D  SETDSKC          ;RET WITH ADDR OF DPE
1389 01DE C9              RET
1390
1391 01DF 3AEF01          SETDE: LDA      SETDSKA          ;GET DRIVE # FROM ENTRY
1392 01E2 210400          LXI      H,LOGDSK          ;CHECK TO SEE IF ERROR IS
1393 01E5 BE              CMP      M                  ; ON DEFAULT DISK
1394 01E6 C2EB01          JNZ     SETDE1           ; BR IF NOT
1395 01E9 3600            MVI     M,0              ;SET DEFAULT AS DRIVE A
1396 01EB 210000          SETDE1: LXI     H,0000H          ;SET ERROR RETURN VALUE
1397 01EE C9              RET
1398
1399 01EF                      SETDSKA DS      1          ;LOGICAL UNIT # FOR SELECTION
1400 01F0                      SETDSKB DS      1          ;1ST TIME FLAG
1401 01F1                      SETDSKC DS      2          ;ADDR RETURNED BY GETDPE
1402 01F3                      SETDSKD DS      1          ;SAVED BIOS MODE BYTE
1403
1404                      PAGE
```

```
1405
1406 01F4 7E      DSKDIS: MOV    A,M          ;GET DISK DRIVE TYPE
1407 01F5 07      RLC
1408 01F6 07      RLC
1409 01F7 07      RLC
1410 01F8 E607    ANI    DPETYPE/32
1411              IF    DPETYPE-11100000B
1412 %:           DPETYPE NE 11100000B
1413              ENDIF
1414 01FA 87      ADD    A          ;*2
1415 01FB 210602  LXI    H,DTT
1416 01FE CDA808  CALL  DADA
1417 0201 CDC608  CALL  HLIHL
1418 0204 19      DAD    D          ;ADD JUMP VECTOR OFFSET
1419 0205 E9      PCHL
1420
1421              DTT:
1422 0206 0D08    DW    NULDVD      ;000 - NON-EXISTANT
1423 0208 0D08    DW    NULDVD      ;001 - RESERVED
1424
1425              IF    H17T
1426 020A FC04    DW    H17DVD      ;010 - H17
1427              ELSE
1428              DW    NULDVD
1429              ENDIF
1430
1431              IF    H37T
1432              DW    H37DVD      ;011 - H37
1433              ELSE
1434 020C 0D08    DW    NULDVD
1435              ENDIF
1436
1437              IF    H47T
1438              DW    H47DVD      ;100 - H47
1439              ELSE
1440 020E 0D08    DW    NULDVD
1441              ENDIF
1442
1443 0210 0D08    DW    NULDVD      ;101 - RESERVED
1444
1445              IF    H67T
1446              DW    H67DVD      ;110 - H67
1447              ELSE
1448 0212 0D08    DW    NULDVD
1449              ENDIF
1450
1451 0214 0D08    DW    NULDVD      ;111 - RESERVED
1452
1453              PAGE
```

```
1454
1455 ; SETSEC - SET SECTOR NUMBER
1456 ; ENTRY C DESIRED SECTOR (NUMBERED 1 TO SPT )
1457 ;
1458
1459 SETSEC: MOV A,C ;GET SECTOR NUMBER
1460 0216 79 DCR A ;SAVE 0 TO SPT-1
1461 0217 3D STA SEKSEC
1462 0218 32A410 RET
1463 021B C9
1464 ;
1465 ; SETDMA - SET DISK I/O ADDRESS
1466 ;
1467 ;
1468 SETDMA: MOV H,B ;MOVE ARGUMENT FROM BC TO HL
1469 021C 60 MOV L,C
1470 021D 69 SHLD DMAADR
1471 021E 22B210 RET
1472 0221 C9
1473 ;
1474 ; SECTAN - TRANSLATE SECTOR INDEX USING TABLE AT DE
1475 ; INTO SECTOR NUMBER FOR SKEW
1476 ;
1477 ; ENTRY C = SECTOR INDEX (0 TO SPT-1)
1478 ; DE = ADDR OF TRANSLATE TABLE
1479 ; EXIT HL = SECTOR NUMBER (1 TO SPT)
1480 ;
1481 ;
1482 SECTAN: XCHG ;HL POINTS TO TABLE
1483 0222 EB MOV A,H ;CHECK FOR NULL XLATE TABLE
1484 0223 7C ORA L
1485 0224 B5 DAB B
1486 0225 09 JZ SECTAN1 ;NULL XLATE TABLE
1487 0226 CA2D02 MOV L,M ;L CONTAINS THE TRANSLATE SECTOR
1488 0229 6E MVI H,0
1489 022A 2600 RET
1490 022C C9
1491 SECTAN1:
1492 022D 23 INX H ;PUT IN RANGE 1 TO SPT
1493 022E C9 RET
1494
1495 PAGE
```

```
1496
1497      ;
1498      ; READ - READ THE (LOGICAL) RECORD SET BY SETDSK, SETTRK, SETSEC
1499      ; INTO MEMORY AT DMAADR, DEBLOCKING AS NECESSARY
1500      ;
1501
1502 0000 = WRALL EQU 0 ;WRITE TO ALLOCATED
1503 0001 = WRDIR EQU 1 ;WRITE TO DIRECTORY
1504 0002 = WRUAL EQU 2 ;WRITE TO UNALLOCATED
1505      ;
1506      ;
1507      ; READ THE SELECTED CP/M SECTOR
1508 022F AF READ: XRA A
1509 0230 32310D STA UNACNT
1510 0233 3E01 MVI A,1
1511 0235 32B010 STA READOP ;READ OPERATION
1512 0238 32AF10 STA RSFLAG ;MUST READ DATA
1513 023B 3E02 MVI A,WRUAL
1514 023D 32B110 STA WRTYPE ;TREAT AS UNALLOC
1515 0240 C30D03 JMP RWOPER ;TO PERFORM THE READ
1516
1517 PAGE
```

```

1518
1519 ; WRITE - WRITE THE (LOGICAL) RECORD SET BY SETDSK, SETTRK, SETSEC
1520 ; FROM MEMORY AT DMAADR, BLOCKING AS NECESSARY
1521 ;
1522
1523 0243 AF WRITE: XRA A ;0 TO ACCUMULATOR
1524 0244 32B010 STA READOP ;NOT A READ OPERATION
1525 0247 79 MOV A,C ;WRITE TYPE IN C
1526 0248 32B110 STA WRTYPE
1527 024B FE02 CPI WRUAL ;WRITE UNALLOCATED?
1528 024D C29102 JNZ CHKUNA ;CHECK FOR UNALLOC
1529 ;
1530 ; WRITE TO UNALLOCATED, SET PARAMETERS
1531 0250 2A8C10 LHLD DPBX ;SET NUMBER OF RECORDS PER ALLOCATION
1532 0253 23 INX H
1533 0254 23 INX H
1534 0255 23 INX H
1535 0256 7E MOV A,M
1536 0257 32310D STA UNACNT
1537 025A 3AA110 LDA SEKDSK ;DISK TO SEEK
1538 025D 32AA10 STA UNADSK ;UNADSK = SEKDSK
1539 0260 2AA210 LHLD SEKTRK
1540 0263 22AB10 SHLD UNATRK ;UNATRK = SEKTRK
1541
1542 0266 2A8C10 LHLD DPBX
1543 0269 11F0FF LXI D,-DPBETH
1544 026C 19 DAD D ;HL POINTS TO POINTER TO XLATE TABLE
1545 026D C0C608 CALL HLIHL ;HL POINTS TO XLATE TABLE
1546
1547 0270 7C MOV A,H
1548 0271 B5 ORA L
1549 0272 C27E02 JNZ WRITE0 ;XLATE TABLE PRESENT
1550 0275 3AA410 LDA SEKSEC ;NO XLATE TABLE
1551 0278 32AD10 STA UNASI ;USE SECTOR #
1552 027B C39102 JMP CHKUNA
1553
1554 027E 3AA410 WRITE0: LDA SEKSEC ;GET DESIRED SECTOR
1555 0281 3C INR A ;CORRECT TO 1 TO SPT
1556 0282 0E00 MVI C,0 ;INITIALIZE INDEX
1557
1558 0284 BE WRITE1: CMP M ;FIND SECTOR'S INDEX
1559 0285 CA8D02 JZ WRITE2 ; (WHICH IS THE UNTRANSLATED SECTOR-1)
1560
1561 0288 0C INR C ;NOT THIS ONE, TRY THE NEXT
1562 0289 23 INX H
1563 028A C38402 JMP WRITE1
1564
1565 028D 79 WRITE2: MOV A,C ;GET THE INDEX
1566 028E 32AD10 STA UNASI ;SAVE IT
1567
1568 ;
1569 ; CHECK FOR WRITE TO UNALLOCATED SECTOR
1570 0291 3A310D CHKUNA: LDA UNACNT ;ANY UNALLOC REMAIN?
1571 0294 B7 ORA A
1572 0295 CA0503 JZ ALLOC ;SKIP IF NOT
1573 ;

```



```

1574 ; MORE UNALLOCATED RECORDS REMAIN
1575 0298 3D DCR A ;UNACNT = UNACNT-1
1576 0299 32310D STA UNACNT
1577 029C 3AA110 LDA SEKDSK ;SAME DISK?
1578 029F 21AA10 LXI H,UNADSK
1579 02A2 BE CMP M ;SEKDSK = UNADSK?
1580 02A3 C20503 JNZ ALLOC ;SKIP IF NOT
1581 ;
1582 ; DISKS ARE THE SAME
1583 02A6 3AA210 LDA SEKTRK
1584 02A9 21AB10 LXI H,UNATRK
1585 02AC BE CMP M ;SEKTRK LSB = UNATRK LSB?
1586 02AD C20503 JNZ ALLOC ;SKIP IF NOT
1587 02B0 3AA310 LDA SEKTRK+1
1588 02B3 23 INX H
1589 02B4 BE CMP M ;SEKTRK MSB = UNATRK MSB?
1590 02B5 C20503 JNZ ALLOC ;SKIP IF NOT
1591 ;
1592 ; TRACKS ARE THE SAME
1593 02B8 2A8C10 LHLD DPBX
1594 02BB 11FOFF LXI D,-DPEPTH
1595 02BE 19 DAD D
1596 02BF CDC608 CALL HLIHL
1597 02C2 7C MOV A,H
1598 02C3 B5 ORA L
1599 02C4 C2D002 JNZ CHKUNAS ;XLATE TABLE PRESENT
1600 02C7 3AAD10 LDA UNASI
1601 02CA 21A410 LXI H,SEKSEC
1602 02CD C3DA02 JMP CHKUNA6
1603 02D0 3AAD10 CHKUNAS: LDA UNASI
1604 02D3 CDA808 CALL DADA
1605 02D6 3AA410 LDA SEKSEC
1606 02D9 3C INR A
1607 02DA BE CHKUNA6: CMP M ;SEKSEC = UNASI?
1608 02DB 21AD10 LXI H,UNASI
1609 02DE C20503 JNZ ALLOC ;SKIP IF NOT
1610 ;
1611 ; MATCH, MOVE TO NEXT SECTOR FOR FUTURE REF
1612 02E1 34 INR M ;UNASI = UNASI+1
1613 02E2 7E MOV A,M ;END OF TRACK?
1614 02E3 E5 PUSH H
1615 02E4 F5 PUSH PSW
1616 02E5 2A8C10 LHLD DPBX ;GET NUMBER OF SECTORS/TRACK FROM DPB
1617 02E8 11FAFF LXI D,-DPEPTH+DPEDPB
1618 02EB 19 DAD D
1619 02EC CDC608 CALL HLIHL ;GET DBPX
1620 02EF F1 POP PSW
1621 02F0 BE CMP M ;FIRST ENTRY OF WHICH IS SEC/TRACK
1622 02F1 E1 POP H
1623 02F2 DAFE02 JC NOVVF ;SKIP IF NO OVERFLOW
1624 ;
1625 ; OVERFLOW TO NEXT TRACK
1626 02F5 3600 MVI M,0 ;UNASI = 0
1627 02F7 2AAB10 LHLD UNATRK
1628 02FA 23 INX H
1629 02FB 22AB10 SHLD UNATRK ;UNATRK = UNATRK+1

```

```
1630 ;
1631 ;
1632 02FE AF NOOVF: XRA A ;0 TO ACCUMULATOR
1633 02FF 32AF10 STA RSFLAG ;RSFLAG = 0
1634 0302 C30D03 JMP RWOPER ;TO PERFORM THE WRITE
1635 ;
1636 ;
1637 0305 AF ALLOC: XRA A ;0 TO ACCUM
1638 0306 32310D STA UNACNT ;UNACNT = 0
1639 0309 3C INR A ;1 TO ACCUM
1640 030A 32AF10 STA RSFLAG ;RSFLAG = 1
1641
1642 PAGE
```

```

1643
1644 ; ENTER HERE TO PERFORM THE LOGICAL READ/WRITE
1645 030D AF RWOPEP: XRA A ;ZERO TO ACCUM
1646 030E 32AE10 STA ERFLAG ;NO ERRORS (YET)
1647 0311 2A8C10 LHL D DPBX ;FIND LOGICAL SECTORS PER PHYSICAL
1648 0314 4E MOV C,M ;GET DISK TYPE
1649 0315 23 INX H
1650 0316 23 INX H
1651 0317 46 MOV B,M ;GET LOGICAL SECTORS PER PHYSICAL
1652
1653 IF H47T OR H67T
1654 MOV A,C
1655 ANI DPETYPE
1656 CPI DPEH47 ;CHECK FOR H47 FLOPPY
1657 JZ RWOX ;IS H47
1658 MOV A,C
1659 ANI DPETYPF
1660 CPI DPEH67F ;CHECK FOR H67 FLOPPY
1661 JNZ RWO ;BR IF NOT
1662 RWOX: LHL D SEKTRK ;WHAT TRACK ARE WE AFTER?
1663 MOV A,H
1664 ORA L ;IF NOT TRACK 0
1665 JNZ RWO ; THEN USE THE VALUE OF LSP IN DPBX
1666 MVI B,I ; ELSE ON TRACK 0 IT IS I!
1667 ENDIF
1668
1669 0318 78 RWO: MOV A,B
1670 0319 329C10 STA LSP
1671
1672 031C 3AA410 LDA SEKSEC ;COMPUTE HOST SECTOR
1673 031F F5 RW1: PUSH PSW ;SAVE THE PHYSICAL SECTOR (TO DATE)
1674 0320 78 MOV A,B ;GET SHIFT FACTOR (SHIFT LOG2 SEC PER REC)
1675 0321 1F RAR
1676 0322 47 MOV B,A
1677 0323 DA2C03 JC RW2
1678 0324 F1 POP PSW
1679 0327 B7 ORA A
1680 0328 1F RAR
1681 0329 C31F03 JMP RW1
1682 032C F1 RW2: POP PSW
1683 032D 32A910 STA SEKHST ;HOST SECTOR TO SEEK
1684 ;
1685 ; ACTIVE HOST SECTOR?
1686 0330 212F0D LXI H,HSTACT ;HOST ACTIVE FLAG
1687 0333 7E MOV A,M
1688 0334 3601 MVI M,I ;ALWAYS BECOMES 1
1689 0336 B7 ORA A ;WAS IT ALREADY?
1690 0337 CA6703 JZ FILHST ;FILL HOST IF NOT
1691 ;
1692 ; HOST BUFFER ACTIVE, SAME AS SEEK BUFFER?
1693 033A 3AA110 LDA SEKDSK
1694 033D 21A510 LXI H,HSTDSK ;SAME DISK?
1695 0340 BE CMP M ;SEKDSK = HSTDSK?
1696 0341 C26003 JNZ NOMATCH
1697 ;
1698 ; SAME DISK, SAME TRACK?

```

```

1699 0344 3AA210 LDA SEKTRK
1700 0347 21A610 LXI H,HSTTRK
1701 034A BE CMP M ;SEKTRK LSB = HSTTRK LSB?
1702 034B C26003 JNZ NOMATCH
1703 034E 3AA310 LDA SEKTRK+1
1704 0351 23 INX H
1705 0352 BE CMP M ;SEKTRK MSB = HSTTRK MSB?
1706 0353 C26003 JNZ NOMATCH
1707 ;
1708 ; SAME DISK, SAME TRACK, SAME BUFFER?
1709 0356 3AA210 LDA SEKHST
1710 0359 21A810 LXI H,HSTSEC ;SEKHST = HSTSEC?
1711 035C BE CMP M
1712 035D CA9203 JZ MATCH ;SKIP IF MATCH
1713 ;
1714 ; PROPER DISK, BUT NOT CORRECT SECTOR
1715 0360 3A300D NOMATCH: LDA HSTWRT ;HOST WRITTEN?
1716 0363 B7 ORA A
1717 0364 C4F303 CNZ WRITEHST ;CLEAR HOST BUFF
1718 ;
1719 ; MAY HAVE TO FILL THE HOST BUFFER
1720 0367 3AA110 FILHST: LDA SEKDSK
1721 036A 32A510 STA HSTDISK
1722 036D 2AA210 LHLD SEKTRK
1723 0370 22A610 SHLD HSTTRK
1724 0373 3AA910 LDA SEKHST
1725 0376 32A810 STA HSTSEC
1726 0379 3AB010 LDA READOP
1727 037C B7 ORA A
1728 037D C28703 JNZ FIL1 ;YES IT WAS A READ
1729 0380 3A9C10 LDA LSP
1730 0383 3D DCR A
1731 0384 CA8E03 JZ FIL2 ;DON'T NEED TO PREREAD IF PHYSICAL=LOGICAL
1732 ;
1733 0387 3AAF10 FIL1: LDA RSFLAG ;NEED TO READ?
1734 038A B7 ORA A
1735 038B C4E303 CNZ READHST ;YES, IF 1
1736 038E AF FIL2: XRA A ;0 TO ACCUM
1737 038F 32300D STA HSTWRT ;NO PENDING WRITE
1738 ;
1739 ; COPY DATA TO OR FROM BUFFER
1740 0392 3A9C10 MATCH: LDA LSP
1741 0395 3D DCR A
1742 0396 21A410 LXI H,SEKSEC
1743 0399 A6 ANA M
1744 039A 210000 LXI H,0
1745 039D CA8803 JZ M2
1746 03A0 118000 LXI D,128
1747 03A3 19 M1: DAD D
1748 03A4 3D DCR A
1749 03A5 C2A303 JNZ M1
1750 ; HL HAS RELATIVE HOST BUFFER ADDRESS
1751 03A8 11320D M2: LXI D,HSTBUF
1752 03AB 19 DAD D ;HL = HOST ADDRESS
1753 03AC EB XCHG ;NOW IN DE
1754 03AD 2AB210 LHLD DMAADR ;GET/PUT CP/M DATA

```

```
.....
1755 03B0 0E80          MVI    C,128          ;LENGTH OF MOVE
1756 03B2 3AB010      LDA    READOP        ;WHICH WAY?
1757 03B5 B7          ORA    A
1758 03B6 C2BF03      JNZ    RWMOVE        ;SKIP IF READ
1759                   ;
1760                   ;
1761 03B9 3E01          MVI    A,1
1762 03BB 32300D      STA    HSTWRT        ;HSTWRT = 1
1763 03BE EB          XCHG           ;SOURCE/DEST SWAP
1764                   ;
1765                   ; C INITIALLY 128, DE IS SOURCE, HL IS DEST
1766 03BF CDCB08      RWMOVE: CALL  MOVEITX ;MOVE DATA
1767                   ;
1768                   ; DATA HAS BEEN MOVED TO/FROM HOST BUFFER
1769 03C2 3AB110      LDA    WRTYPE        ;WRITE TYPE
1770 03C5 FE01          CPI    WRDIR        ;TO DIRECTORY?
1771 03C7 3AAE10      LDA    ERFLAG        ;IN CASE OF ERRORS
1772 03CA C2DB03      JNZ    RW9          ;BR IF NOT DIRECTORY WRITE
1773                   ;
1774                   ; CLEAR HOST BUFFER FOR DIRECTORY WRITE
1775 03CD B7          ORA    A            ;ERRORS?
1776 03CE C2DD03      JNZ    RW9A        ;BR IF ERROR
1777 03D1 AF          XRA    A            ;0 TO ACCUM
1778 03D2 32300D      STA    HSTWRT        ;BUFFER WRITTEN
1779 03D5 CDF303      CALL  WRITEHST
1780 03D8 3AAE10      LDA    ERFLAG
1781                   ;
1782 03DB A7          RW9: ANA    A            ;CHECK FOR ERROR
1783 03DC C8          RZ                ;RET IF NONE
1784                   ;
1785 03DD F5          RW9A: PUSH   PSW          ;SAVE ERROR
1786 03DE CD1204      CALL  FLUSH1        ;RE-INIT HOST BUFFER FLAGS
1787 03E1 F1          POP    PSW         ;RESTORE ERROR
1788 03E2 C9          RET
1789                   ;
1790                   PAGE
.....
```

```

1791
1792 ;
1793 ; WRITEHST PERFORMS THE PHYSICAL WRITE TO
1794 ; THE HOST DISK, READHST READS THE PHYSICAL
1795 ; DISK.
1796 ;
1797 ; READHST - PERFORM PHYSICAL SECTOR READ
1798 ; HSTDSK = HOST DISK #, HSTTRK = HOST TRACK #,
1799 ; HSTSEC = HOST SECT #. READ "HSTSIZ" BYTES
1800 ; INTO HSTBUF AND RETURN ERROR FLAG IN ERFLAG.
1801 ;
1802 READHST:
1803 03E3 AF XRA A ;INDICATE READ OPERATION
1804 03E4 329B10 STA RWOP
1805
1806 03E7 3AA510 LDA HSTDSK ;GET HOST DISK
1807 03EA CD5104 CALL SHD ;SET HOST DEVICE POINTER
1808 ; AND PERFORM LOGICAL TO PHYSICAL MAPPING
1809
1810 03ED 110300 LXI D,DDRD
1811 03FO C3F401 JMP DSKDIS
1812
1813 ;
1814 ; WRITEHST - WRITE PHYSICAL SECTOR
1815 ; HSTDSK = HOST DISK #, HSTTRK = HOST TRACK #,
1816 ; HSTSEC = HOST SECT #. WRITE "HSTSIZ" BYTES
1817 ; FROM HSTBUF AND RETURN ERROR FLAG IN ERFLAG.
1818 ; RETURN ERFLAG NON-ZERO IF ERROR
1819 ;
1820
1821 WRITEHST:
1822 03F3 3E01 MVI A,1 ;INDICATE WRITE OPERATION
1823 03F5 329B10 STA RWOP
1824
1825 03F8 3AA510 LDA HSTDSK
1826 03FB CD5104 CALL SHD ;GET HSTDPB, ALSO DO PHYSICAL -> LOGICAL MAP
1827
1828 03FE 110600 LXI D,DDWR
1829 0401 C3F401 JMP DSKDIS
1830
1831 ;
1832 ; FLUSH - FLUSHES HOST BUFFER.
1833 ; FLUSH1 - REINITIALIZES HOST FLAGS
1834 ;
1835
1836 0404 3A2F0D FLUSH: LDA HSTACT ;IS HOST BUFFERING ACTIVE
1837 0407 A7 ANA A
1838 0408 CA1204 JZ FLUSH1 ;BR IF NOT
1839
1840 040B 3A300D LDA HSTWRT ;IS HOST BUFFER WAITING TO BE WRITTEN
1841 040E A7 ANA A
1842 040F C4F303 CNZ WRITEHST ;YES - WRITE IT
1843
1844 0412 AF FLUSH1: XRA A
1845 0413 322F0D STA HSTACT ;DEACTIVATE HOST BUFFER
1846 0416 32300D STA HSTWRT ;NO PENDING WRITE

```

```
.....
1847 0419 32310D STA UNACNT ;NO UNALLOCATED SECTORS IN BLOCK
1848
1849 041C C9 RET
1850
1851 ; EXTENDED ERROR MESSAGE HANDLER.
1852 ;
1853 ; ENTRY: (ERRTYP) = ERROR CODE
1854 ; (HL) = ADDR OF DEVICE TYPE MSG
1855 ; EXIT: NONE
1856 ; USES: ALL
1857
1858 041D 3A3600 PRERR: LDA MODE ;CHECK IF EXTENDED ERROR MESSAGES
1859 0420 E602 ANI MODEB1 ; REQUESTED
1860 0422 C8 RZ ; RET IF NOT
1861
1862 0423 E5 PUSH H ;SAVE DEVICE TYPE MSG
1863 0424 21F0C LXI H,CRLF
1864 0427 CD9B0C CALL PMSG
1865 042A E1 POP H ;RESTORE DEVICE TYPE MSG
1866 042B CD9B0C CALL PMSG
1867
1868 042E 3A9B10 LDA RWOP ;PRINT I/O TYPE MSG
1869 0431 21E90C LXI H,RDMSG ;ASSUME READ
1870 0434 A7 ANA A
1871 0435 CA3B04 JZ PRERR1
1872 0438 21EF0C LXI H,WRMSG ;WAS WRITE
1873 PRERR1:
1874 043B CD9B0C CALL PMSG
1875
1876 043E 21F60C LXI H,ERRMSG
1877 0441 CD9B0C CALL PMSG
1878
1879 0444 3A9E10 LDA ERRTYP ;PRINT ERROR TYPE
1880 0447 CDA80C CALL HOUT
1881
1882 044A 21FE0C LXI H,CRLF
1883 044D CD9B0C CALL PMSG
1884
1885 0450 C9 RET
1886
1887 PAGE
.....
```

```

1888
1889 ; SHD - SET HOST DPB POINTER
1890 ; ENTRY A HOST DISK
1891 ; EXIT HSTDPB POINTS TO HOST DISK PARAMETERS
1892 ; (HL) = (HSTDPB)
1893 ;
1894
1895 SHD:
1896 IF H17T OR H37T
1897 0451 32D004 STA SHDA
1898 0454 32D104 STA SHDB
1899 ENDF
1900 0457 CDBE08 CALL GETDPEX ;GET ADDR OF DPE'S HEATH EXTENSIONS
1901 045A 228E10 SHLD HSTDPB ; SAVE IT
1902
1903 IF H17T OR H37T
1904
1905 045D 7E MOV A,M ;CHECK DRIVE TYPE
1906 045E E6E0 ANI DPETYPE
1907 0460 FE40 CPI DPEH17
1908 0462 CA6A04 JZ SHD1
1909 0465 FE60 CPI DPEH37
1910 0467 C2C804 JNZ SHD6
1911
1912 046A EB SHD1: XCHG ;(DE) = ADDR OF HEATH EXTENSIONS
1913 046B 210600 LXI H,DPEFLG2-DPEHTH
1914 046E 19 DAD D
1915 046F 7E MOV A,M
1916 0470 E602 ANI DPEIMG ;CHECK IF IMAGINARY DRIVE
1917 0472 CA8104 JZ SHD2 ; BR IF NOT
1918
1919 0475 210700 LXI H,DPELUN-DPEHTH ;GET REAL DRIVE LOGICAL UNIT #
1920 0478 19 DAD D
1921 0479 7E MOV A,M
1922 047A 32D104 STA SHDB ;SAVE IT
1923 047D CDBE08 CALL GETDPEX ;GET ADDR OF DPE'S HEATH EXTENSIONS
1924 0480 EB XCHG ;(DE) = ADDR OF HEATH EXTENSIONS
1925
1926 0481 210700 SHD2: LXI H,DPELUN-DPEHTH
1927 0484 19 DAD D
1928 0485 3AD004 LDA SHDA
1929 0488 BE CMP M ;REQ UNIT = CURRENTLY MOUNTED UNIT
1930 0489 CAC504 JZ SHD5 ; BR IF YES
1931
1932 048C 77 MOV M,A ;UPDATE MOUNTED UNIT SLOT
1933
1934 048D CDC904 CALL SHD9 ;GET LOGICAL DISK NAME
1935 0490 C641 ADI 'A'
1936 0492 32DD04 STA MNMSG4
1937
1938 0495 3AD104 LDA SHDB ;GET PHYSICAL DISK NAME
1939 0498 CDC904 CALL SHD9
1940 049B C641 ADI 'A'
1941 049D 32E804 STA MNMSGB
1942
1943 04A0 110C00 LXI D,DDMNT ;MOUNT DISK DRIVE

```



```

1944 04A3 2A8E10      LHL D  HSTDPB
1945 04A6 CDF401      CALL  DSKDIS
1946
1947 04A9 21D204      LXI   H,MNMSG      ;PROMPT USER TO CHANGE DISK
1948 04AC CD9B0C      CALL  PMSG
1949
1950 04AF CD0609      SHD3: CALL  CONIN      ;GET A CHARACTER FROM THE CONSOLE
1951
1952 04B2 FE0D          CPI   CR           ;IF CHAR == CR
1953 04B4 CABF04      JZ    SHD4        ;THEN GO AHEAD
1954
1955 04B7 0E07          MVI   C,BELL      ;ELSE RING BELL
1956 04B9 CD1409      CALL  CONOUT
1957 04BC C3AF04      JMP   SHD3        ;AND WAIT FOR ANOTHER CHARACTER
1958
1959 04BF 21FE0C      SHD4: LXI   H,CRLF
1960 04C2 CD9B0C      CALL  PMSG
1961
1962 04C5 2A8E10      SHD5: LHL D  HSTDPB
1963
1964                ENDIF
1965
1966 04C8 C9           SHD6: RET
1967
1968                IF      H17T OR H37T
1969
1970                ; GET LOGICAL UNIT #
1971                ;
1972                ; ENTRY: (A) = LOGICAL AND MAPPED UNIT #'S
1973                ;          BIT 7-4 = LOGICAL UNIT #
1974                ;          BIT 3-0 = MAPPED UNIT #
1975                ; EXIT: (A) = LOGICAL UNIT #
1976                ; USES: A,F
1977
1978 04C9 1F           SHD9: RAR
1979 04CA 1F           RAR
1980 04CB 1F           RAR
1981 04CC 1F           RAR
1982 04CD E60F        ANI   0FH
1983 04CF C9           RET
1984
1985 04D0              SHDA  DS    1      ;LOGICAL/MAPPED DRIVE # OF REQ
1986 04D1              SHDB  DS    1      ;LOGICAL/MAPPED DRIVE # OF REAL
1987
1988 04D2 0D0A505554MNMSG DB    CR,LF, 'PUT DISK '
1989 04DD 2E20494E20MNMSG6A DB    ' IN DRIVE '
1990 04E8 2E3A20414EMNMSGB DB    ' .: AND PRESS RETURN',0
1991                ENDIF
1992
1993                PAGE

```

```
1994
1995                IF      H17T
1996
1997                ;      H17 DEVICE DRIVE          11 MAR 1982
1998
1999                H17DVD:
2000    04FC C33A06    JMP      RDYH17          ;SELECT ENTRY POINT
2001    04FF C30B05    JMP      RD17M          ;READ
2002    0502 C32405    JMP      WR17M          ;WRITE
2003    0505 C32D06    JMP      RESH17         ;RESET
2004    0508 C32406    JMP      MNTH17         ;MOUNT
2005
2006                PAGE
```

```
.....  
2007  
2008 050B 3AA810 RD17M: LDA HSTSEC  
2009 050E 329910 STA SECTOR  
2010  
2011 0511 3AA610 LDA HSTTRK ;GET TRACK (# IS ALWAYS < 256)  
2012 0514 329810 STA TRACK  
2013  
2014 0517 CD4905 CALL RD17  
2015 051A 3E00 MVI A,00H  
2016 051C D22005 JNC RDH1 ;CARRY SET INDICATES ERROR  
2017 051F 3D DCR A ; IF ERROR, MAKE ERFLAG = OFFH  
2018 0520 32AE10 RDH1: STA ERFLAG  
2019 0523 C9 RET  
2020  
2021 0524 3AA810 WR17M: LDA HSTSEC ;GET SECTOR NUMBER  
2022 0527 329910 STA SECTOR  
2023  
2024 052A 3AA610 LDA HSTTRK ;GET TRACK (# IS ALWAYS < 256)  
2025 052D 329810 STA TRACK  
2026  
2027 0530 CD7E05 CALL WR17  
2028 0533 3E00 MVI A,00H  
2029 0535 D23905 JNC WRH1 ;CARRY SET ON ERROR  
2030 0538 3D DCR A ; MAKE ERFLAG = OFFH ON ERROR  
2031 0539 32AE10 WRH1: STA ERFLAG  
2032 053C C9 RET  
2033  
2034 PAGE
```

```
2035
2036      ;
2037      ; XOK - EXIT FROM DISK OPERATION WITHOUT ERROR
2038      ; XIT - EXIT FLAGGING ERROR IN CARRY
2039      ;
2040
2041 053D AF      XOK:  XRA    A          ;CLEAR CARRY
2042 053E F5      XIT:  PUSH   PSW
2043 053F F3      DI
2044 0540 210F06  LXI    H,DELAYS      ;SET DISK MOTOR AND SELECT TIMERS
2045 0543 222B08  SHLD   DLYMO
2046 0546 F1      POP    PSW
2047 0547 FB      EI
2048 0548 C9      RET
2049      ;
2050      ; RD17 - READ A SELECTED SECTOR
2051      ;
2052
2053 0549 CDB906  RD17:  CALL   SDP          ;SET PARAMETERS FOR THIS OPERATION
2054
2055 054C CDD506  RD171: CALL   SDT          ;SEEK THE DESIRED TRACK
2056
2057 054F CD3F07      CALL   LPS          ;FIND THE PROPER SECTOR
2058 0552 DA7505      JC     RD17E      ;COULDN'T FIND IT
2059 0555 0600      MVI    B,0          ;READ 256 BYTES
2060 0557 21320D      LXI    H,HSTBUF      ;POINTER TO BUFFER
2061 055A CDC907      CALL   WSC          ;WAIT FOR SYNC
2062 055D 3E20      MVI    A,D#E#MDS      ;MISSING DATA SYNC ERROR
2063 055F DA7505      JC     RD17E      ;MISSING SYNC BYTE
2064
2065 0562 CDBB07  RD172: CALL   RDB          ;READ A BYTE FROM THE DISK
2066 0565 77      MOV    M,A          ;PUT IT IN MEMORY
2067 0566 23      INX    H          ;INCREMENT POINTER
2068
2069 0567 05      DCR    B          ;COUNT BYTE AS READ
2070 0568 C26205  JNZ   RD172      ;MORE TO READ
2071
2072 056B 42      MOV    B,D          ;CHECK CHECKSUM
2073 056C CDBB07  CALL   RDB
2074 056F B8      CMP    B
2075 0570 CA3D05  JZ     XOK          ;EVERYTHING IS OKAY
2076 0573 3E08      MVI    A,D#E#CHK      ;SIGNAL CHECKSUM ERROR
2077
2078 0575 CDCC05  RD17E: CALL   H17E      ;H17 ERROR HANDLER
2079 0578 D24C05  JNC   RD171      ;TRY AGAIN
2080 057B C33E05  JMP   XIT        ;RETURN, FLAGGING ERROR IN CARRY
2081
2082      PAGE
```

```
.....
2083
2084 ;
2085 ; WR17 - WRITE A SECTOR
2086 ;
2087
2088 057E CDB906 WR17: CALL SDP ;SET DISK PARAMETERS
2089
2090 0581 DB7F WR17: IN DPDC ;SEE IF WRITE PROTECTED
2091 0583 E604 ANI DFWP
2092 0585 3E40 MVI A,D#E#WRP ;POSSIBLE WRITE PROTECT ERROR
2093 0587 C2C305 JNZ WR17E ;YES, IT IS A WRITE PROTECT ERROR
2094
2095 058A CDD506 CALL SDT ;GET CORRECT TRACK
2096
2097 058D CD3F07 CALL LPS ;FIND THE PROPER SECTOR
2098 0590 DAC305 JC WR17E ;COULDN'T FIND IT
2099
2100 0593 0600 MVI B,0 ;256 BYTES/SECTOR
2101 0595 21320D LXI H,HSTBUF ;POINTER TO SOURCE OF DATA
2102
2103 0598 3E14 MVI A,WRITA
2104 059A 3D WR17: DCR A
2105 059B C29A05 JNZ WR172
2106
2107 059E 0E0A MVI C,WRITB
2108 05A0 3E10 MVI A,WRITC
2109 05A2 CDEA07 CALL WSP ;WRITE THE SYNC PATTERN
2110
2111 05A5 7E WR173: MOV A,M
2112 05A6 CDFF07 CALL WNB ;WRITE THIS DATA BYTE
2113 05A9 23 INX H
2114 05AA 05 DCR B
2115 05AB C2A505 JNZ WR173 ;LOOP TO WRITE ALL 256 BYTES
2116
2117 05AE 7A MOV A,D ;WRITE CHECKSUM
2118 05AF CDFF07 CALL WNB
2119
2120 05B2 CDFF07 CALL WNB ;CONTINUE TUNNEL ERASE
2121 05B5 CDFF07 CALL WNB ;FOR 3 CHARACTER TIMES
2122 05B8 CDFF07 CALL WNB
2123
2124 05BB 3A0F00 LDA DEVCTL ;OFF WRITE GATE
2125 05BE D37F OUT DPDC
2126 05C0 C33D05 JMP XOK
2127
2128 05C3 CDCC05 WR17E: CALL H17E ;CALL THE H17 ERROR HANDLER
2129 05C6 D28105 JNC WR171 ;TRY AGAIN
2130 05C9 C33E05 JMP XIT ;RETURN FLAGGING ERROR IN CARRY
2131
2132 PAGE
.....
```

```

2133
2134      ; H17E - H17 ERROR HANDLER
2135      ; ENTRY   A - ERROR TYPE
2136      ; EXIT    C - SET IF RETRIES EXHAUSTED
2137
2138 05CC FB      H17E: EI
2139 05CD 329E10 STA   ERRTYP      ;SAVE THE ERROR TYPE
2140
2141 05D0 E6C0    ANI   D#E#UNR+D#E#WRP ;IS IT UNIT NOT READ OR
2142      ; WRITE 'PROTECT VIOLATION'
2143 05D2 C21806 JNZ   H17E4      ;IF SO, THEN AUTOMATIC HARD ERROR
2144
2145 05D5 2A4D00 LHL  SECNT17      ;BUMP THE SOFT ERROR COUNT
2146 05D8 23     INX   H
2147 05D9 224D00 SHLD  SECNT17
2148
2149 05DC 219D10 LXI   H,ERRCNT      ;GET A POINTER TO THE RETRY COUNTER
2150 05DF 35     DCR   M          ; DECREMENT THE RETRY COUNTER
2151 05E0 CA1806 JZ    H17E4      ;RETRIES EXHAUSTED, FLAG HARD ERROR
2152
2153      ; BASED ON ERROR TYPE AND RETRY NUMBER
2154      ; SELECT FROM THE FOLLOWING RETRY ACTIONS
2155      ; SEEK TRACK 0 IF BAD TRACK ERROR OR RETRY 5
2156      ; JUST TRY AGAIN IF RETRY ODD
2157      ; MOVE IN THEN OUT IF RETRY & 2 = 0
2158      ; MOVE OUT THEN IN IF RETRY & 2 = 1
2159
2160 05E3 3A9E10 LDA   ERRTYP
2161 05E6 FE01 CPI   D#E#TRK      ;WAS IT A BAD TRACK ERROR
2162 05E8 CA1306 JZ    H17E2      ;YES, GO DO A SEEK TRACK ZERO
2163
2164 05EB 7E     MOV   A,M          ;FETCH RETRY COUNT
2165 05EC FE05 CPI   5            ;IF == 5
2166 05EE CA1306 JZ    H17E2      ; THEN SEEK TRACK ZERO
2167
2168 05F1 1F     RAR           ;IF ODD, THEN TRY AGAIN IN PLACE
2169 05F2 3F     CMC           ;COMPLEMENT CARRY
2170 05F3 D0     RNC           ;RETURN WITH CARRY CLEAR
2171
2172 05F4 2A9F10 LHL  TRKPT      ;GET POINTER TO CURRENT TRACK
2173
2174 05F7 1F     RAR           ;IS B1 OF ERRCNT = 1?
2175 05F8 7E     MOV   A,M          ;GET CURRENT TRACK
2176 05F9 DA0806 JC    H17E1      ;YES, SO MOVE OUT THEN IN
2177
2178 05FC FE27 CPI   39           ;IF IT IS ALREADY AT THE MAXIMUM TRACK
2179 05FE CA1606 JZ    H17E3      ; THEN DON'T DO ANYTHING
2180
2181 0601 34     INR   M          ;INCREMENT CURRENT TRACK
2182 0602 CD1007 CALL  MAI          ; MOVE ARM IN ONE TRACK
2183 0605 C31606 JMP   H17E3
2184
2185 0608 B7     H17E1: ORA   A          ;IF IT IS ALREADY AT MINIMUM TRACK
2186 0609 CA1606 JZ    H17E3      ; THEN DON'T DO ANYTHING
2187
2188 060C 35     DCR   M          ;DECREMENT CURRENT TRACK

```

```
.....
2189 060D CD1507          CALL   MAD           ; MOVE ARM OUT ONE TRACK
2190 0610 C31606          JMP    H17E3
2191
2192 0613 CDF506          H17E2: CALL   STZ
2193
2194 0616 AF              H17E3: XRA    A           ; CLEAR CARRY
2195 0617 C9              RET
2196
2197                      ;     HARD ERROR HAS OCCURRED
2198                      ;     (OPTIONALLY) PRINT ERROR MESSAGE
2199                      ;     RETURN WITH CARRY SET
2200
2201 0618 212006          H17E4: LXI   H,H17MSG
2202 061B CD1D04          CALL   PRERR         ; PRINT EXTENDED ERROR MESSAGE
2203
2204 061E 37              STC                    ; RETURN FLAGGING HARD ERROR IN CARRY
2205 061F C9              RET
2206
2207 0620 48313700        H17MSG DB    'H17',0
2208
2209                      PAGE
.....
```

```
2210
2211 ;
2212 ; MNTH17 -- MOUNT
2213 ;
2214
2215 0624 2A8E10 MNTH17: LHLD HSTDPB ;SET TRACK POINTER TO UNKNOWN
2216 0627 110400 LXI D,DPETRK-DPEHTH
2217 062A 19 DAD D
2218 062B 3680 MVI M,DPEUNK
2219
2220 ;+ JMP RESH17 ;RESET DRIVE
2221
2222
2223
2224
2225 ;
2226 ; RESH17 -- ABORT OPERATION/RESET H17
2227 ;
2228
2229 062D AF RESH17: XRA A
2230 062E D37F OUT DPDC
2231 0630 320F00 STA DEVCTL
2232 0633 210000 LXI H,0
2233 0636 222B08 SHLD DLYM0
2234 0639 C9 RET
2235
2236
2237
2238
2239 ;
2240 ; RDYH17 -- CHECK IF UNIT READY
2241 ; 1. DRIVE IS AVAILABLE
2242 ; 2. CORRECT TYPE OF MEDIA HAS BEEN INSERTED
2243 ;
2244 ; ENTRY: NONE
2245 ; EXIT: PSW/C = 0 IF READY
2246 ; = 1 IF NOT READY
2247 ; USES: ALL
2248 ;
2249 ; THE NUMBER OF HOLE TRANSITIONS IS COUNTED IN THE TIME IT TAKES
2250 ; FOR 1 REVOLUTION (200MS). IF THE DISK INSERTED IS HARD SECTORED,
2251 ; THEN 11 HOLES PLUS/MINUS 1 (22+-2 TRANSITIONS) SHOULD BE COUNTED,
2252 ; 10 SECTOR HOLES AND 1 INDEX HOLE.
2253 ;
2254
2255 RDYH17:
2256 063A CD7806 CALL ONH17 ;TURN ON MOTOR AND SELECT DRIVE
2257
2258 063D 212D08 LXI H,DLYW ;WAIT UNTIL DRIVE IS UP TO SPEED
2259 RDYH17A:
2260 0640 7E MOV A,M
2261 0641 A7 ANA A
2262 0642 C24006 JNZ RDYH17A
2263
2264 0645 210B00 LXI H,TICCNT ;GET TIME VALUE
2265 0648 3E64 MVI A,100
```



```
.....
2266 064A 86          ADD     M
2267 064B 47          MOV     B,A          ;(B) = TIME VALUE
2268
2269 064C 0E00        MVI     C,0          ;(C) = HOLE COUNTER
2270 064E 51          MOV     D,C          ;(D) = INIT HOLE STATUS TO NO HOLE
2271
2272                RDYH17B:
2273 064F DB7F        IN      DPDC          ;GET HOLE STATUS
2274 0651 E601        ANI     DFHD
2275 0653 BA          CMP     D              ;HAS IT CHANGED
2276 0654 CA5F06      JZ      RDYH17C       ; BR IF NOT
2277
2278 0657 57          MOV     D,A          ;SAVE NEW STATUS
2279 0658 0C          INR     C              ;COUNT TRANSITION
2280
2281 0659 3E14        MVI     A,WHDA        ;DEBOUNCE DELAY
2282                RDYH17B1:
2283 065B 3D          DCR     A
2284 065C C25B06      JNZ     RDYH17B1
2285
2286                RDYH17C:
2287 065F 78          MOV     A,B          ;CHECK IF TIME UP
2288 0660 BE          CMP     M
2289 0661 C24F06      JNZ     RDYH17B       ; BR IF NOT
2290 0664 79          MOV     A,C          ;TIME UP -- CHECK # OF HOLES
2291 0665 FE14        CPI     10*2
2292 0667 DA7006      JC      RDYH17D       ; IF < 10 THEN ERROR
2293 066A FE19        CPI     12*2+1
2294 066C 3F          CMC
2295 066D D27506      JNC     RDYH17E       ; IF <= 12 THEN OK
2296
2297                RDYH17D:
2298 0670 3E80        MVI     A,D*E$UNR     ; OTHERWISE SAY UNIT NOT READY
2299 0672 CDCC05      CALL    H17E          ;REPORT ERROR
2300
2301                RDYH17E:
2302 0675 C33E05      JMP     XIT           ;RETURN VIA 'XIT'
2303
2304                PAGE
```

```

2305
2306 ;
2307 ; ONH17 -- TURNS ON MOTOR, SELECT DRIVE, AND SET SETTLE DELAY COUNTERS.
2308 ;
2309
2310 0678 FB      ONH17: EI                      ;MAKE CERTAIN INTERRUPTS ARE ENABLED
2311
2312 0679 210000  LXI      H,0
2313 067C 222B08  SHLD    DLYMO
2314
2315 067F 2A8E10  LHL    HSTDPB      ;GET DEVICE SELECT CODE
2316 0682 23      INX      H
2317 0683 7E      MOV     A,M
2318 0684 F610    DRY     DFMO      ;TURN ON THE MOTOR
2319 0686 D37F    OUT     DPDC
2320
2321 0688 47      MOV     B,A
2322 0689 210F00  LXI     H,DEVCTL      ;WHAT WAS ITS STATE?
2323 068C 7E      MOV     A,M
2324 068D E610    ANI     DFMO      ;WAS THE MOTOR ON?
2325 068F C2A906  JNZ     ONH17A      ;YES, DON'T HAVE TO WAIT FOR IT
2326
2327 0692 E5      PUSH   H
2328 0693 2A8E10  LHL    HSTDPB      ;FIND OUT HOW FAST IT COMES UP
2329 0696 110500  LXI     D,DPESEK-DPEHTH
2330 0699 19      DAD     D
2331 069A 7E      MOV     A,M
2332 069B E1      POP     H
2333 069C 17      RAL
2334
2335           %:      IF     DPEMO-10000000B
2336           ENDIF
2337 069D 3EFA    MVI     A,SPD      ;UP TO SPEED IN SPD * 4 MS
2338 069F D2B406  JNC     ONH17B
2339 06A2 1F      RAR
2340 06A3 1F      RAR      ;NEW DRIVES UP IN 1/4 TIME
2341 06A4 E63F    ANI     03FH
2342 06A6 C3B406  JMP     ONH17B
2343
2344 06A9 7E      ONH17A: MOV    A,M
2345 06AA E60E    ANI     U0+U1+U2   ;CHECK THE AVAILABLE UNITS
2346 06AC A0      ANA     B           ;WAS THIS UNIT SELECTED?
2347 06AD 3E00    MVI     A,0
2348 06AF C2B406  JNZ     ONH17B
2349 06B2 3E14    MVI     A,HLTG     ;THIS HEAD WAS ALREADY LOADED
2350 06B4 322D08  ONH17B: STA    DLYW      ;MUST WAIT FOR HEAD LOAD TIMING
2351
2352 06B7 70      MOV     M,B
2353           ;MOV   A,B
2354           ;STA   DEVCTL
2355
2356 06B8 C9      RET
2357
2358           PAGE

```

```
2359  
2360 ;  
2361 ; SDP - SET DEVICE PARAMETERS  
2362 ; SET 'RETRY' COUNT; 'MAKE SURE MOTOR IS ON AND DRIVE SELECTED'  
2363 ;  
2364 ;  
2365 SDP:  
2366 06B9 CD7806 CALL ONH17 ;TURN ON MOTOR AND SELECT DRIVE  
2367  
2368 06BC 3E0A MVI A;RETRIES ;SET TRY COUNTER  
2369 06BE 329D10 STA ERRCNT  
2370  
2371 06C1 2A8E10 LHLD HSTDPB ;GET THE CURRENT TRACK FOR THIS DISK  
2372 06C4 110400 LXI D;DPETRK-DPEHTH ;OFFSET TO TRACK IN DISK TABLES  
2373 06C7 19 DAD D ;GET ADDRESS OF TRACK FOR THIS DRIVE  
2374 06C8 229F10 SHLD TRKPT  
2375 06CB 7E MOV A,M  
2376 06CC 17 RAL ;IF MSB IS 0  
2377 06CD D0 RNC ; THEN TRACK IS POINTED TO BY TRKPT  
2378 ;CALL STZ ; ELSE HEAD POSITION IS UNKNOWN AND  
2379 ;RET ; IS ZEROED  
2380 06CE C3F506 JMP STZ  
2381  
2382 PAGE
```

```
2383
2384 ; SDT - SEEK DESIRED TRACK
2385 ; SEEK TO TRACK UPDATING *TRKPT
2386 ;
2387 06D1 34 SDT0: INR M
2388 06D2 CD1007 CALL MAI
2389
2390 06D5 2A9F10 SDT: LHL D TRKPT
2391 06D8 3A9810 LDA TRACK
2392 06DB BE CMP M
2393 06DC CAE906 JZ SDT1 ;AT DESIRED TRACK
2394 06DF F2D106 JP SDT0 ; MUST MOVE ARM IN
2395 ; ELSE MUST MOVE ARM OUT
2396 06E2 35 DCR M
2397 06E3 CD1507 CALL MAO
2398
2399 06E6 C3D506 JMP SDT
2400
2401
2402 06E9 3A2D08 SDT1: LDA DLYW ;MAKE CERTAIN TO DELAY FOR HEAD SETTLE TIME
2403 06EC FE06 CPI HST ;IS WAIT ALREADY > HEAD SETTLE
2404 06EE D0 RNC ;IF SO, RETURN
2405 06EF 3E06 MVI A,HST ; ELSE BE SURE TO DELAY FOR HEAD SETTLE
2406 06F1 322D08 STA DLYW
2407 06F4 C9 RET
2408
2409 ;
2410 ; STZ - SEEK TRACK 0 BY STEPPING THE HEAD OUT UNTIL THE TRACK ZERO INDICATOR
2411 ; IS ACTIVE OR 255 STEPS HAVE BEEN DONE.
2412 ; CALLED DURING ERROR RECOVERY AND TO INITIALLY POSITION HEADS.
2413
2414 STZ:
2415 06F5 2E00 MVI L,0 ;SET LOOP COUNTER
2416
2417 06F7 DB7F STZ0: IN DPDC ;CHECK THE TRACK ZERO SENSOR
2418 06F9 E202 ANI DFT0
2419 06FB C20807 JNZ STZ1 ;IF SET, THEN WE ARE AT TRACK 0
2420 06FE 2D DCR L ;DCR LOOP COUNTER
2421 06FF CA0807 JZ STZ1 ; IF COUNTER EXHAUSTED, THEN ASSUME TRACK 0
2422 0702 CD1507 CALL MAO ;MOVE OUT ANOTHER TRACK
2423 0705 C3F706 JMP STZ0
2424 STZ1:
2425 0708 2A9F10 LHL TRKPT ;ZERO TRACK INDICATOR FOR THIS DRIVE
2426 070B 3600 MVI M,0
2427 070D C3E906 JMP SDT1 ;HEAD SETTLE DELAY IN CASE GOING TO 0
2428
2429
2430 PAGE
```

```
2431
2432 ; MAI - MOVE ARM IN
2433 ; MAO - MOVE ARM OUT
2434 ;
2435
2436 0710 3E20 MAI: MVI A,DFDI ;SET DIRECTION
2437 0712 C31&07 JMP MAD1
2438 0715 AF MAO: XRA A ;SET DIRECTION
2439 0716 E5 MAD1: PUSH H
2440 0717 67 MOV H,A
2441 0718 3A0F00 LDA DEVCTL ;GET CURRENT VALUE OF DISK PORT
2442 071B B4 ORA H ;OR IN DIRECTION
2443 071C D37F OUT DPDC ; SEND IT TO DISK
2444 071E F640 ORI DFST ;OR IN STEP
2445 0720 D37F OUT DPDC ; SEND IT TO DISK
2446 0722 EE40 XRI DFST ;CLEAR STEP
2447 0724 D37F OUT DPDC ; SEND IT TO DISK
2448 0726 2A8E10 LHLD HSTDPB ;GET STEP RATE
2449 0729 110500 LXI D,5
2450 072C 19 DAD D
2451 072D 7E MOV A,M
2452 072E E&7F ANI 07FH
2453 0730 E1 POP H
2454 ; CALL DLY ;IMPLICIT CALL DLY AND RET
2455 ; RET
2456 ;
2457 ;
2458 ; DLY - DELAY A * 2 MS
2459 ;
2460
2461 0731 E5 DLY: PUSH H
2462 0732 210B00 LXI H,TICCNT ;POINTER TO TICK COUNTER; INCREMENTED EVERY 2MS
2463 0735 86 ADD M ;VALUE OF TICCNT WHEN DELAY COMPLETED
2464 0736 BE DLY1: CMP M ;WAIT FOR TICCNT TO CATCH UP
2465 0737 C23607 JNZ DLY1
2466 073A E1 POP H
2467 073B C9 RET
2468
2469
2470 PAGE
```

```
2471
2472 ; LPS - LOCATE PROPER SECTOR
2473 ;
2474
2475 073C CD7D07 LPS0: CALL STS ;SKIP THIS SECTOR
2476
2477 073F 3A2D08 LPS: LDA DLYW ;READY TO READ YET?
2478 0742 B7 ORA A
2479 0743 C23C07 JNZ LPS0 ;IF NOT, WAIT A SECTOR TIME
2480
2481 0746 0614 MVI B,LPSA
2482
2483 0748 F3 LPS1: DI
2484 0749 CDC907 CALL WSC ;WAIT FOR A SYNC CHARACTER
2485 074C 3E02 MVI A,D#E#HSY ;FLAG HEADER SYNC ERROR
2486 074E DA7207 JC LPS2 ;COULDN'T FIND ONE
2487
2488 0751 CDBB07 CALL RDB ;READ THE VOLUME NUMBER
2489 0754 CDBB07 CALL RDB ;READ THE TRACK NUMBER
2490 0757 219810 LXI H,TRK
2491 075A BE CMP M
2492 075B 3E01 MVI A,D#E#TRK ;BAD TRACK ERROR
2493 075D C27207 JNZ LPS2 ;WRONG TRACK
2494
2495 0760 CDBB07 CALL RDB ;READ THE SECTOR NUMBER
2496 0763 23 INX H ;POINT TO SECTOR
2497 0764 BE CMP M
2498 0765 3E10 MVI A,D#E#RNF ;RECORD NOT FOUND ERROR
2499 0767 C27207 JNZ LPS2 ;WRONG SECTOR
2500
2501 076A 62 MOV H,D
2502 076B CDBB07 CALL RDB ;DO CHECKSUM ON HEADER
2503 076E BC CMP H
2504 076F C8 RZ ;OKAY
2505 0770 3E04 MVI A,D#E#HCK ;HEADER CHECKSUM IS WRONG
2506
2507 0772 F5 LPS2: PUSH PSW
2508 0773 CD7D07 CALL STS ;SKIP THIS SECTOR
2509 0776 F1 POP PSW
2510 0777 05 DCR B ;ANOTHER TIME PASSES QUICKLY PAST
2511 0778 C24807 JNZ LPS1
2512
2513 077B 37 STC ;ENOUGH ALREADY
2514 077C C9 RET
2515
2516
2517 PAGE
```

```
2518
2519 ; STS = SKIP THIS SECTOR
2520 ; EXIT AT BEGINNING OF NEXT SECTOR
2521 ; 1. IF HEAD IS NOT OVER A HOLE, WAIT 8 MS WHILE HOLE CHECKING.
2522 ; IF NO HOLE IN THIS TIME, THEN WE ARE IN A REGULAR GAP.
2523 ; WAIT FOR THE NEXT HOLE AND EXIT.
2524 ; 2. IF THE HEAD IS OVER A HOLE, OR BECOMES SO DURING THE 8 MS
2525 ; WAIT, THEN WAIT FOR THE HOLE TO PASS, WAIT 12 MS IN CASE OF
2526 ; THE INDEX HOLE, THEN WAIT FOR THE NEXT HOLE AND EXIT.
2527 ;
2528
2529 077D FB STS: EI
2530 077E C5 PUSH B
2531 077F DB7F IN DPDC ;CHECK THE DISK PORT
2532 0781 1F RAR ;FOR SECTOR HOLES
2533 0782 DA9907 JC STS2 ;CURRENTLY OVER A HOLE
2534
2535 ; NO HOLE YET, WAIT 8 MS MIN (10 MS MAX) FOR HOLE TO APPEAR
2536
2537 0785 210B00 LXI H,TICNT
2538 0788 46 MOV B,M
2539 0789 DB7F STS1: IN DPDC
2540 078B 1F RAR
2541 078C DA9907 JC STS2 ;FOUND A HOLE
2542
2543 078F 3E05 MVI A,STSA
2544 0791 80 ADD B
2545 0792 BE CMP M
2546 0793 C28907 JNZ STS1 ;8 MS STILL NOT UP
2547 0796 C3A107 JMP STS3 ;FOUND A SECTOR GAP
2548
2549 ; HAVE HOLE. SKIP IT AND WAIT 12 MS
2550
2551 0799 CDAE07 STS2: CALL WNH ;WAIT FOR NO HOLE
2552 079C 3E07 MVI A,STSB
2553 079E CD3107 CALL DLY
2554 07A1 C1 STS3: POP B
2555 07A2 F3 DI
2556
2557
2558 PAGE
```

```
2559
2560 ; WHD - WAIT HOLE DETECT
2561 ;
2562
2563 07A3 DB7F WHD: IN DPDC ;WATCH THE DISK CONTROL PORT
2564 07A5 1F RAR ;UNTIL A HOLE IS FOUND
2565 07A6 D2A307 JNC WHD ; STILL NO HOLE
2566 07A9 3E14 MVI A,WHDA ;SET UP LOOP DELAY COUNT
2567 07AB C3B607 JMP UDLY
2568
2569 ;
2570 ; WNH - WAIT FOR NO HOLE
2571 ;
2572
2573 07AE DB7F WNH: IN DPDC ;WATCH THE DISK CONTROL PORT
2574 07B0 1F RAR ;UNTIL THE CURRENT HOLE IS PAST
2575 07B1 DAAE07 JC WNH
2576 07B4 3E14 MVI A,WHNA ;SET UP LOOP DELAY COUNT
2577
2578 ;
2579 ; UDLY - MICROSECOND DELAY
2580 ; CALLED WITH INTERRUPTS DISABLED TO WAIT
2581 ; A * ( 15 / 2.048 ) MICROSECONDS ON 8080
2582 ; A * ( 14 / 2.048 ) MICROSECONDS ON Z80
2583
2584 07B6 3D UDLY: DCR A
2585 07B7 C2B607 JNZ UDLY
2586 07BA C9 RET
2587
2588 ;
2589 ; RDB - READ BYTE FROM DISK
2590 ;
2591
2592 07BB DB7D RDB: IN UPST ; IS A BYTE READY?
2593 07BD 1F RAR
2594 07BE D2BB07 JNC RDB ; WAIT UNTIL READY
2595
2596 07C1 DB7C IN UPDP ;GET THE BYTE
2597 07C3 5F MOV E,A ;SAVE IT IN E
2598 07C4 AA XRA D ;UPDATE CRC
2599 07C5 07 RLC
2600 07C6 57 MOV D,A
2601 07C7 7B MOV A,E ;RESTORE BYTE READ TO A
2602 07C8 C9 RET
2603
2604
2605 PAGE
```



```
2606
2607 ; WSC - WAIT SYNC CHARACTER
2608 ; WSC WAITS FOR THE APPEARANCE OF A SYNC CHARACTER. THE DISK
2609 ; SHOULD BE SELECTED, MOVING, AND THE HEAD SHOULD BE OVER THE
2610 ; PRE-SYNC ZERO BAND
2611 ;
2612 ; IF SYNC IS NOT FOUND IN 25 CHARACTER TIMES, ERROR
2613 ;
2614 07C9 3E30 WSC: MVI A,READA ;DELAY PAST GARBAGE BYTE
2615 07CB 3D WSC0: DCR A
2616 07CC C2CB07 JNZ WSC0
2617 07CF 3EFD MVI A,DSYN ;SET UP SYNC CHARACTER
2618 07D1 D37E OUT UPSC
2619 07D3 DB7E IN UPSR ;RESET SYNC SEARCH
2620 07D5 3E50 MVI A,WSCA ;NUMBER OF LOOPS IN 25 CHARACTERS
2621 07D7 57 MOV D,A
2622 07D8 DB7F WSC1: IN DPDC
2623 07DA E608 ANI DFSD ;CHECK FOR SYNC
2624 07DC C2E507 JNZ WSC2 ;GOT IT
2625 07DF 15 DCR D
2626 07E0 C2D807 JNZ WSC1 ;TRY UNTIL TIME-OUT
2627
2628 07E3 37 STC ;COULDN'T FIND SYNC
2629 07E4 C9 RET
2630
2631 ; FOUND SYNC CHARACTER
2632
2633 07E5 DB7C WSC2: IN UPDP ;GOBBLE THE SYNC CHARACTER
2634 07E7 1600 MVI D,0 ;CLEAR CHECKSUM
2635 07E9 C9 RET
2636
2637
2638 PAGE
```

```
2639
2640 ; WSP - WRITE SYNC PATTERN
2641 ; WSP WRITES A SYNC PATTERN OF ZEROS, FOLLOWED BY A SYNC CHARACTER
2642 ;
2643 ; ENTRY A INITIAL DELAY COUNTER
2644 ; C NUMBER OF ZERO BYTES TO WRITE
2645
2646 07EA 3D WSP: DCR A ;DELAY
2647 07EB C2EA07 JNZ WSP
2648
2649 ; DELAY IS UP, TURN ON WRITE GATE
2650
2651 07EE 3A0F00 LDA DEVCTL
2652 07F1 3C INR A ;SET WRITE GATE ON
2653 07F2 D37F OUT DPDC
2654
2655 ; WRITE # OF ZEROS SPECIFIED IN C
2656
2657 07F4 AF WSP1: XRA A
2658 07F5 CDFF07 CALL WNB ;WRITE A ZERO
2659 07F8 0D DCR C ;COUNT IT
2660 07F9 C2F407 JNZ WSP1
2661
2662 07FC 3EFD MVI A,DSYN ;WRITE A SYNC CHARACTER
2663 07FE 57 MOV D,A ;PRE-CLEAR CHECKSUM, SO WNB EXITS WITH D = 0
2664 ; JMP WNB ;IMPLICIT CALL, RETURN WNB
2665
2666
2667 PAGE
```

```
2668
2669 ; WNB - WRITE NEXT BYTE
2670 ; WRITE A BYTE TO DISK PRESUMING WRITE GATE ALREADY ON
2671 ;
2672
2673 07FF 5F WNB: MOV E,A ;SAVE CHARACTER TO BE WRITTEN
2674 0800 DB7D WNB1: IN UPST ;IS USRT READY FOR ANOTHER CHARACTER
2675 0802 A7 ANA A ;SET FLAGS
2676 0803 F20008 JP WNB1 ;NOT READY, WAIT SOME MORE
2677
2678 0806 7B MOV A,E ;GET CHARACTER
2679 0807 D37C OUT UPDF ;WRITE IT TO DISK
2680 0809 AA XRA D ;UPDATE CRC
2681 080A 07 RLC
2682 080B 57 MOV D,A
2683 080C C9 RET
2684
2685 ;ENDIF
2686
2687 ;PAGE
```

```

2688
2689             IF      H37T
2690
2691             ;      H37 DISK DEVICE DRIVER                23 FEB 82
2692
2693 H37DVD:      JMP      SET37          ;SETDSK ENTRY POINT
2694             JMP      RD37          ;READ SECTOR
2695             JMP      WR37          ;WRITE SECTOR
2696             JMP      RESH37        ;RESET
2697             JMP      MNTH37        ;MOUNT
2698
2699             ;
2700             ; SELECT DISK 1ST LOGIN
2701             ;
2702
2703 SET37:
2704             LXI      H,0            ;TRACK 0
2705             SHLD     HSTTRK         ;
2706             XRA      A              ;1ST SECTOR
2707             STA      HSTSEC        ; (SECTOR # 0 TO SPT-1)
2708             DCR      A              ;SET FLAG TO SUSPEND 'H37DONE'
2709             STA      SET37A        ; PROCESSING AND DO NO RETRIES
2710
2711             ; CHECK IF DRIVE IS AVAILABLE AND PROPER MEDIA INSERTED.
2712
2713             CALL     RDYH37        ;CHECK IF DRIVE IS READY
2714             JC       SET379        ; BR IF NOT
2715
2716             ; READ LABEL.
2717
2718             LHLD     DPBX          ;FORCE RESTORE OF HEAD
2719             LXI      D,DPETRK-DPEHTH
2720             DAD      D
2721             MVI     M,DPEUNK
2722
2723             IF      H37ED
2724
2725             CALL     RD37          ;TRY READING LABEL AT DENSITY
2726             ; CURRENTLY INDICATED IN TABLES
2727             JZ       SET373        ; BR IF SUCCESSFUL
2728
2729             LHLD     DPBX          ;UNABLE TO READ LABEL
2730             MOV      A,M           ; TRY OTHER DENSITY
2731             XRI      DPEDD
2732             MOV      M,A
2733             CALL     RD37          ;TRY TO READ LABEL
2734             JNZ      SET379        ; BR IF ERROR
2735
2736 SET373:
2737
2738             ELSE
2739
2740             MVI     A,FDCRDA       ;TRY READ ADDRESS COMMAND AT DENSITY
2741             LXI      D,H37TMP      ; CURRENTLY INDICATED IN TABLES
2742             CALL     H37RD
2743             JZ       SET373        ; BR IF SUCCESSFUL

```

```

2744
2745      LHL D PBX          ;UNABLE TO READ
2746      MOV  A,M          ; CHANGE TO OTHER DENSITY
2747      XRI  DPEDD
2748      MOV  M,A
2749      LXI  H,H37CTL
2750      MOV  A,M
2751      XRI  CONMFM
2752      MOV  M,A
2753      OUT  FD#CON
2754      MVI  A,FDCRDA      ;TRY READ ADDRESS COMMAND AGAIN
2755      LXI  D,H37TMP
2756      CALL H37RD
2757      JNZ  SET379        ; BR IF ERROR
2758
2759      SET373: LDA  H37TMP+FDRASL  ;Q. SECTOR LENGTH = 256
2760      CPI  FDSL256
2761      JNZ  SET379        ; BR IF NOT
2762
2763      CALL RD37          ;READ LABEL
2764      JNZ  SET379        ; BR IF ERROR
2765
2766      ENDIF
2767
2768      CALL CHKLAB        ;CHECK CHECKSUM OF LABEL
2769      JZ   SET373A       ; BR IF CORRECT CHECKSUM
2770
2771      LHL D PBX          ;IF SINGLE DENSITY THEN ASSUME NO LABEL
2772      MOV  A,M          ; IS PRESENT AND USE DEFAULT LABEL.
2773      ANI  DPEDD        ; OTHERWISE ERROR
2774      JNZ  SET379
2775      MVI  C,LABLEN-1
2776      LXI  D,HSTBUF+LABEL
2777      LXI  H,DFTL37
2778      CALL MOVEIT
2779
2780      ; MOVE LABEL INFO TO DPE'S HEATH EXTENSIONS.
2781
2782      SET373A:
2783      LHL D PBX          ;DENSITY/SIDES
2784      MOV  A,M
2785      ANI  DPETYPE+DPE9&T
2786      MOV  B,A
2787      LXI  D,HSTBUF+LABHTH+DPEFLAG-DPEHTH
2788      LDAX D
2789      ANI  DPEED+DPEDD+DPE2S
2790      ORA  B
2791      MOV  M,A
2792
2793      INX  D              ;CP/M RECORDS PER SECTOR
2794      INX  D
2795      LDAX D
2796      INX  H
2797      INX  H
2798      MOV  M,A
2799

```

```

2800                INX    D                ;CP/M RECORDS PER ALLOCATION BLOCK
2801                LDAX   D
2802                INX    H
2803                MOV    M,A
2804
2805                INX    D                ;DPEFLG2
2806                INX    D
2807                INX    D
2808                LDAX   D
2809                ANI    OFFH-DPEIMG
2810                MOV    B,A
2811                INX    H
2812                INX    H
2813                INX    H
2814                MOV    A,M
2815                ANI    DPEIMG
2816                ORA    B
2817                MOV    M,A
2818                IF     (DPEFLG2-DPERPAB-3)
2819                %:    (DPEFLG2-DPERPAB) NE 3
2820                ENDIF
2821
2822                ; IF LABEL INDICATES THAT THE MEDIA IS DOUBLE SIDED, THEN
2823                ; CHECK OUT THE DRIVE FOR DOUBLE SIDED CAPABILITY.
2824
2825                LDA    HSTBUF+LABHTH+DPEFLAG-DPERH
2826                ANI    DPE2S
2827                JZ     SET374            ;BR IF MEDIA IS NOT DOUBLE SIDED
2828
2829                MVI    A,FDCRDA+FDSS1
2830                LXI    D,H37TMP
2831                CALL   H37RD            ;TRY TO READ A SECTOR HEADER ON 2ND SIDE
2832                JNZ    SET379            ; BR IF ERROR
2833
2834                LDA    H37TMP+FDASID ;CHECK SIDE INFO
2835                CPI    1
2836                JNZ    SET379            ; BR IF NOT 2ND SIDE
2837
2838                ; STEP IN 2 TRACKS, READ ADDRESS, AND STEP BACK OUT 2 TRACKS.
2839                ; IF READ ADDRESS FINDS TRACK 1 INSTEAD OF TRACK 2,
2840                ; THEN ASSUME 48 TPI MEDIA GENERATED
2841                ; ON A 48 TPI DRIVE WAS INSERTED INTO THE 96 TPI DRIVE; THEREFORE,
2842                ; USE AS A R/O DISK WITH DOUBLE STEPPING.
2843                ;
2844                ; THERE ARE TWO 48 TPI MEDIA FORMATS THAT ARE SUPPORTED ON
2845                ; A 96 TPI DRIVE.
2846                ; 1) MEDIA WAS FORMATTED ON A 96 TPI DRIVE AND ONLY USES
2847                ; THE FIRST HALF OF THE DISK SURFACE. (E.G. A 48 TPI MEDIA
2848                ; IS DUPLICATED ONTO MEDIA IN A 96 TPI DRIVE)
2849                ; 2) MEDIA WAS FORMATTED ON A 48 TPI DRIVE. THE HARDWARE
2850                ; GROUP HAS INFORMED ME THAT THE 96 TPI DRIVE CAN RELIABLY
2851                ; READ SUCH MEDIA BUT CANNOT WRITE ON IT. TO GO BETWEEN
2852                ; TRACKS IT IS NECESSARY TO DOUBLE THE NUMBER OF STEPS.
2853                ;
2854                ; THE FOLLOWING ARE THE POSSIBLE OUTCOMES OF THE READ ADDRESS
2855                ; MEDIA DRIVE DRIVE OUTCOME

```

```

2856          ;   FORMAT      GENERATED ON      INSERTED IN      TRACK
2857          ;   -----
2858          ;   48 TPI        48 TPI            48 TPI        2
2859          ;   48 TPI        48 TPI            96 TPI        1
2860          ;   48 TPI        96 TPI            48 TPI        ERROR
2861          ;   48 TPI        96 TPI            96 TPI        2
2862          ;   96 TPI        96 TPI            48 TPI        ERROR
2863          ;   96 TPI        96 TPI            96 TPI        2
2864          ;
2865
2866          SET374:
2867          MVI      A,2
2868          STA      TRACK
2869          CALL     SDT37          ;STEP IN TWO TRACKS
2870
2871          MVI      A,FDCRDA
2872          LXI      D,H37TMP
2873          CALL     H37RD          ;DO READ ADDRESS
2874          JNZ      SET379          ; BR IF ERROR
2875
2876          LDA      H37TMP+FDRATRK ;CHECK IF TRACK 2
2877          CPI      2
2878          JZ       SET374D        ; BR IF YES
2879          ; 1) 48 TPI MEDIA GENERATED ON 48 TPI
2880          ; DRIVE INSERTED INTO 48 TPI DRIVE
2881          ; 2) 48 TPI MEDIA GENERATED ON 96 TPI
2882          ; DRIVE INSERTED INTO 96 TPI DRIVE
2883          ; 3) 96 TPI MEDIA INSERTED IN 96 TPI
2884
2885          CPI      1
2886          JNZ      SET379          ;CHECK IF TRACK 1
2887          ; BR IF NOT
2888
2889          LHLD     DPBX
2890          MOV      A,M
2891          ORI      DPE48R0
2892          MOV      M,A
2893          ; SET FLAG TO INDICATE 48 TPI MEDIA
2894          ; GENERATED ON 48 TPI DRIVE INSERTED
2895          ; INTO 96 TPI DRIVE. THE MEDIA
2896          ; IS TREATED AS R/O
2897
2898          SET374D: CALL     RST37          ;STEP OUT TWO TRACKS BY DOING RESTORE
2899          ; (TRKPT VARIABLE WAS SET ABOVE)
2900
2901          ; MOVE LABEL INFO TO DISK PARAMETER BLOCK.
2902
2903          SET375: LHLD     SETDSKC          ;GET DPE ADDRESS
2904          LXI      B,DPEDPB          ;GET DPB ADDRESS
2905          DAD      B
2906          CALL     HLYHL
2907          LXI      D,HSTBUF+LABDPB ;GET ADDR OF INFO IN LABEL
2908          MVI      C,DPBL          ;COUNT TO MOVE
2909          CALL     MOVEITX          ;MOVE INFO
2910
2911          ; RETURN WITH DPE ADDRESS IN (HL).
2912
2913          XRA      A
2914          ; INDICATE NO ERROR
2915
2916          SET378: MVI      A,0
2917          STA      SET37A          ;CLEAR 'H37DONE' SUSPENSION FLAG
2918          ; (MVI USED TO CLEAR ACCUMULATOR

```

```

2912                                     ; SINCE I WANT TO PRESERVE PSW/C BIT)
2913         CALL      H37DONE             ; DONE WITH DRIVE FOR NOW ('H37DONE'
2914                                     ; DOESN'T DISTURB PSW/C BIT EITHER)
2915         RET
2916
2917         ; ERROR OCCURRED.
2918
2919     SET379:
2920         STC                     ; INDICATE ERROR
2921         JMP      SET378
2922
2923         ;
2924
2925     DFTL37 DB      LABVER             ; DEFAULT LABEL
2926           DB      DPEH37,0,2,8,0,0,0,0
2927           DW      20
2928           DB      3,7,0
2929           DW      91,63,00C0H,16,3
2930
2931     SET37A DB      0                 ; SUSPEND 'H37DONE' FLAG
2932                                     ; 0 = NO NOT 0 = YES
2933
2934     H37TMP DS      FDRAL
2935
2936         PAGE
2937         ;
2938         ; H37WAIT -- LOW LEVEL I/O ROUTINE TO ISSUE COMMAND AND WAIT
2939         ; FOR COMPLETION.
2940         ;
2941         ; ENTRY: (A)=COMMAND
2942         ; ((SP))=RET ADDR
2943         ; EXIT: (A)=STATUS BYTE
2944         ; RET IS DONE VIA H37 INTERRUPT HANDLER
2945         ; USES: A,F,B,H,L
2946         ;
2947
2948     H37WAIT:
2949         POP      H                     ; GET RET ADDR
2950         SHLD    H37IRET               ; INFORM INTERRUPT HANDLER
2951
2952         MOV     B,A
2953         MVI     A,FD#CD               ; ACCESS C/D REGS
2954         OUT     FD#INT
2955         MOV     A,B
2956
2957         OUT     FD#CMD                 ; ISSUE COMMAND
2958         JMP     $                       ; WAIT
2959
2960
2961
2962
2963         ;
2964         ; H37RD -- LOW LEVEL I/O ROUTINE TO INPUT DATA FROM H37.
2965         ;
2966         ; ENTRY: (A)=COMMAND
2967         ; (DE)=BUFFER ADDRESS

```



```
2968 ; ((SP))=RET ADDRESS
2969 ; EXIT: (A)=STATUS BYTE
2970 ; PSW/Z = 0 IF ERROR
2971 ; = '1' IF 'NO ERROR'
2972 ; USES: A,F,B,D,E,H,L
2973 ;
2974 ;
2975 H37RD:
2976 LXI H,H37RD2 ;SET INTERRUPT HANDLER RET ADDR
2977 SHLD H37IRET
2978 ;
2979 MOV B,A
2980 LDA H37CTL ;TURN ON DRQ
2981 ORI CONDRQ
2982 OUT FD#CON
2983 ;
2984 MVI A,FD#CD ;ACCESS C/D REGS
2985 OUT FD#INT
2986 ;
2987 MOV A,B
2988 LXI H,H37RD1
2989 OUT FD#CMD ;ISSUE COMMAND
2990 ;
2991 H37RD1:
2992 HLT ;WAIT FOR NEXT INPUT BYTE
2993 IN FD#DAT ;INPUT BYTE
2994 STAX D ;PUT IT INTO BUFFER
2995 INX D ;BUMP BUFFER POINTER
2996 PCHL ;LOOP
2997 ;
2998 ; TURN OFF DRQ ROUTINE. (ALSO USED BY WR37)
2999 H37RD2:
3000 PUSH PSW
3001 LDA H37CTL ;TURN OFF DRQ
3002 OUT FD#CON
3003 POP PSW
3004 ;
3005 ANA A ;SET PSW/Z TO INDICATE ERROR STATUS
3006 RET
3007 ;
3008 ;
3009 ;
3010 ;
3011 ;
3012 ; H37DONE -- DONE WITH H37 FOR NOW
3013 ;
3014 ; USES: H,L
3015 ;
3016 ; THE SELECT DISK DEVICE DRIVER ENTRY USES OTHER ROUTINES
3017 ; IN THE DRIVER WHICH USE 'H37DONE'. SINCE SELECT USES
3018 ; LOW LEVEL I/O ROUTINES ALSO, THE 'H37DONE' PROCESSING
3019 ; MUST BE TEMPORARILY SUSPENDED UNTIL SELECT IS DONE.
3020 ;
3021 ;
3022 H37DONE:
3023 PUSH PSW
```

```
3024
3025          LDA     SET37A          ;CHECK IF 'H37DONE' IS SUSPENDED
3026          ANA     A              ; TEMPORARILY
3027          JNZ     H37DONE1       ; BR IF IT IS
3028
3029          LXI     H,H37CTL        ;TURN OFF IRQ
3030          MOV     A,M
3031          ANI     OFFH-CONIRQ
3032          OUT     FD#CON
3033          MOV     M,A
3034
3035          LXI     H,DELAY37        ;SET DESELECT AND MOTOR TURN OFF
3036          SHLD   DLYM037         ; DELAY VALUES
3037
3038          H37DONE1:
3039          POP     PSW
3040          RET
3041
3042          PAGE
3043          ;
3044          ; RD37 -- HIGH LEVEL I/O ROUTINE TO READ H37 SECTORS.
3045          ;
3046          ; ENTRY: (HSTDPB) = ADDR OF HEATH EXTENSIONS FOR DRIVE
3047          ;          (HSTTRK) = TRACK
3048          ;          (HSTSEC) = SECTOR (0 TO SPT-1)
3049          ; EXIT: (ERFLAG) = 0 IF NO ERROR
3050          ;          <> 0 IF ERROR
3051          ;          PSW/Z = 0 IF ERROR
3052          ;          = 1 IF NO ERROR
3053          ; USES: ALL
3054          ;
3055
3056          RD37:  CALL   SDP37          ;SET UP
3057
3058          RD370: CALL   SDT37          ;SEEK THE DESIRED TRACK
3059
3060          LDA     SIDE              ;GET SIDE SELECT
3061          ORI     FDCRDS+FDLSLF    ;SET UP COMMAND
3062          LXI     D,HSTBUF         ;GET BUFFER ADDR
3063          CALL   H37RD             ;READ IN DATA
3064          JZ      RD373           ; BR IF NO ERRORS
3065
3066          CALL   H37E              ;CHECK IF I SHOULD RETRY
3067          JNC    RD370            ; BR IF YES
3068
3069          ORI     OFFH              ; OTHERWISE FLAG ERROR
3070          STA     ERFLAG
3071
3072          RD373: JMP     H37DONE       ;EXIT THRU 'H37DONE'
3073
3074          PAGE
3075          ;
3076          ; WR37 -- I/O ROUTINE TO WRITE SECTOR TO H37
3077          ;
3078          ; ENTRY: (HSTDPB) = ADDR OF HEATH EXTENSIONS FOR DRIVE
3079          ;          (HSTTRK) = TRACK
```

```

3080 ; (HSTSEC) = SECTOR (0 TO SPT-1)
3081 ; EXIT: (ERFLAG) = 0 IF NO ERROR
3082 ; ;
3083 ; PSW/Z = 0 IF ERROR
3084 ; = 1 IF NO ERROR
3085 ; USES: ALL
3086 ;
3087 ;
3088 WR37:
3089 LALD HSTDPB ;CHECK FOR 48 TPI R/O
3090 MOV A,M
3091 ANI DPE48R0
3092 MVI A,FDSWPV ;ASSUME ERROR CODE
3093 JNZ WR37E ;BR IF IT IS -- NO WRITY
3094 ;
3095 CALL SDP37 ;SET UP
3096 ;
3097 WR370: CALL SDT37 ;SEEK THE DESIRED TRACK
3098 ;
3099 MVI A,FD#CD
3100 OUT FD#INT ;ACCESS C/D REGS
3101 LDA H37CTL
3102 ORI CONDRQ ;TURN ON DRQ
3103 OUT FD#CON
3104 LDA SIDE ;GET SIDE
3105 ORI FDCWRS+FDPSLF ;SET UP COMMAND
3106 LXI H,WR372 ;INTERRUPT RETURN ADDRESS
3107 SHLD H37IRET
3108 LXI H,WR371 ;LOOP ADDRESS
3109 LXI D,HSTBUF
3110 OUT FD#CMD ;SEND THE COMMAND
3111 ;
3112 WR371: LDAX D
3113 HLT
3114 OUT FD#DAT
3115 INX D
3116 PCHL
3117 ;
3118 WR372: CALL H37RD2 ;TURN OFF DRQ USING 'H37RD2'
3119 ;
3120 JZ WR373 ;BR IF NO I/O ERROR
3121 ;
3122 WR37E: CALL H37E ;CHECK IF I SHOULD RETRY
3123 JNC WR370 ;BR IF YES
3124 ;
3125 ORI OFFH ;FLAG AS I/O ERROR
3126 STA ERFLAG
3127 ;
3128 WR373: JMP H37DONE ;EXIT THRU H37DONE
3129 ;
3130 PAGE
3131 ;
3132 ; H37E -- CHECK IF I SHOULD DO RETRIES.
3133 ;
3134 ; ENTRY: (ERRCNT) = RETRY COUNTER
3135 ; EXIT: PSW/C = 0 IF DO RETRY

```

```

3136 ;           = 1 IF DON'T
3137 ;           (ERRCNT) UPDATED
3138 ;   USES:  ALL
3139 ;
3140 ;   I/O RECOVERY PROCEDURE:
3141 ;   1) RETRY I/O OPERATION
3142 ;   2) STEP HEAD IN 1 TRACK, THEN RETRY I/O OPERATION
3143 ;   3) RETRY I/O OPERATION
3144 ;   4) STEP HEAD OUT 1 TRACK, THEN RETRY I/O OPERATION
3145 ;   5) RETRY I/O OPERATION
3146 ;   6) RESTORE HEAD, THEN RETRY I/O OPERATION
3147 ;   7) RETRY I/O OPERATION
3148 ;   8) STEP HEAD IN 1 TRACK, THEN RETRY I/O OPERATION
3149 ;   9) RETRY I/O OPERATION
3150 ;   10) STEP HEAD OUT 1 TRACK, THEN RETRY I/O OPERATION
3151 ;   11) RETRY I/O OPERATION
3152 ;   12) FLAG AS HARD ERROR
3153 ;
3154 ;
3155 ;   H37E:
3156 ;   STA   ERRTYP           ;SAVE ERROR CODE
3157 ;
3158 ;   ANI   FDSNRD+FDSWPV   ;CHECK FOR NOT READY OR WRITE PROTECT
3159 ;   JNZ   H37E9           ; BR IF YES - NO RETRIES
3160 ;
3161 ;   LDA   SET37A          ;IF NOT DOING SELECT
3162 ;   ANA   A
3163 ;   JNZ   H37E0
3164 ;   LHLD  SECNT37        ;BUMP SOFT ERROR COUNTER
3165 ;   INX   H
3166 ;   SHLD  SECNT37
3167 ;
3168 ;   H37E0:
3169 ;   LXI   H,ERRCNT       ;UPDATE RETRY COUNTER
3170 ;   DCR   M
3171 ;   JZ    H37E9         ; BR IF EXHAUSTED RETRIES
3172 ;
3173 ;   MOV   A,M
3174 ;   CPI   6
3175 ;   JNC   H37E1
3176 ;   SUI   6
3177 ;   H37E1:
3178 ;   JNZ   H37E2         ;BR IF NOT TIME TO DO RESTORE HEAD
3179 ;   CALL  RST37        ;RESTORE HEAD BEFORE TRYING AGAIN
3180 ;   JMP   H37E8
3181 ;
3182 ;   H37E2:
3183 ;   CPI   4             ;CHECK IF TIME TO STEP OUT
3184 ;   JNZ   H37E3         ; BR IF NOT
3185 ;   LXI   H,TRACK       ;DECREMENT TO NEXT TRACK
3186 ;   DCR   M
3187 ;   CP    SDT37         ;IF NEXT TRACK >=0 THEN STEP OUT
3188 ;   LXI   H,TRACK       ;RESTORE DESIRED TRACK
3189 ;   INR   M
3190 ;   JMP   H37E8
3191 ;

```

```

3192          H37E3:
3193          CPI      2          ;CHECK IF TIME TO STEP IN
3194          JNZ      H37E8      ; BR IF NOT
3195          LHLD     HSTDPB      ;GET MAXIMUM TRACK #
3196          MOV      A,M
3197          ANI      DPE96T
3198          MVI      A,79
3199          JNZ      H37E3A
3200          MVI      A,39
3201          H37E3A:
3202          LXI      H,TRACK      ;INCREMENT TO NEXT TRACK
3203          INR      M
3204          CMP      M          ;CHECK IF MAX TRACK # >= NEXT TRACK
3205          CNC      SDT37      ;STEP IF NOT
3206          LXI      H,TRACK      ;RESTORE DESIRED TRACK
3207          DCR      M
3208
3209          H37E8:
3210          XRA      A          ;INDICATE TRY AGAIN
3211          RET
3212
3213          H37E9:
3214          LXI      H,H37MSG
3215          CALL     PRERR        ;PRINT EXTENDED ERROR MSG
3216          STC
3217          RET          ;INDICATE DON'T TRY AGAIN
3218
3219          H37MSG DB      ?H37?,0
3220
3221          PAGE
3222          ;
3223          ; H37 INTERRUPT HANDLER.
3224          ;
3225          ; USES INTERRUPT LEVEL 4
3226          ; THE INTERRUPT HANDLER RETURNS CONTROL TO THE USER PROGRAM
3227          ; AT THE ADDRESS IN ?H37IRET?.
3228          ;
3229          ; EXIT: (A) = STATUS BYTE
3230          ; USES: A,F
3231          ;
3232
3233          H37ISR: MVI      A,10      ;DELAY AWHILE TO LET STATUS SETTLE
3234          H37ISR1: DCR      A
3235          JNZ      H37ISR1
3236
3237          IN      FD#STA          ;INPUT STATUS TO CLEAR INTERRUPT
3238          XTHL
3239          LHLD     H37IRET      ;SAVE (HL) DISCARD RET ADDR
3240          XTHL          ;GET NEW RETURN ADDRESS
3241          XTHL          ;RESTORE (HL) SET NEW RET ADDR
3242          EI          ;RE-ENABLE INTERRUPTS
3243          RET
3244          PAGE
3245          ;
3246          ; SDP37 -- SET DEVICE PARAMETERS
3247          ;

```

```

3248 ; ENTRY: (HSTDPB) = ADDR OF HEATH EXTENSIONS FOR DRIVE
3249 ; (HSTRK) = TRACK
3250 ; (HSTSEC) = SECTOR (0 TO SPT-1)
3251 ; USES: ALL
3252 ;
3253
3254 SDP37:
3255 CALL ONH37 ;SELECT DRIVE
3256
3257 LDA SET37A
3258 ANA A
3259 MVI A,12 ;SET TRY COUNTER
3260 JZ SDP371
3261 MVI A,4 ;ONLY 4 TRIES IF DOING SELECT
3262 SDP371: STA ERRCNT
3263
3264 LDA HSTRK ;GET TRACK #
3265 STA TRACK
3266 MVI B,0 ;DEFAULT TO SIDE 0
3267 LHLD HSTDPB
3268 MOV A,M
3269 ANI DPE2S ;CHECK IF MEDIA IS DOUBLE SIDED
3270 JZ SDP374 ;BR IF NOT
3271 LXI H,TRACK ;IS
3272 MOV A,M ; DOUBLE SIDED
3273 ANA A ; THEREFORE DIVIDE TRACK #
3274 RAR ; BY 2 TO GET REAL TRACK #
3275 MOV M,A
3276 JNC SDP374 ; EVEN TRACKS ON SIDE 0
3277 MVI B,FD#S1 ; ODD TRACKS ON SIDE 1
3278 SDP374: MOV A,B
3279 STA SIDE ;SAVE SIDE
3280 LDA HSTSEC ;GET SECTOR #
3281 INR A ;MAKE 1 = SPT
3282 STA SECTOR
3283
3284 LHLD HSTDPB ;SET TRKPT FOR THIS UNIT
3285 LXI D,DPE#TRK-DPE#H
3286 DAD D
3287 SHLD TRKPT
3288 MOV A,M ;GET CURRENT TRACK
3289 RAL ;IF MSB==1 THEN DON'T KNOW WHERE
3290 JC RST37 ; HEAD IS, SO RESTORE
3291 MVI A,FD#TS
3292 OUT FD#INT ;ACCESS T/S REGS
3293 MOV A,M ;UPDATE TRACK REG
3294 OUT FD#TRK ; WITH CURRENT VALUE FOR THIS DRIVE
3295 RET
3296
3297 PAGE
3298 ;
3299 ; ONH37 -- TURN ON MOTOR, SELECT DRIVE, AND SET SETTLE DELAY COUNTERS
3300 ;
3301
3302 ONH37:
3303 LXI H,0

```

```

3304          SHLD   DLYM037
3305          LHL   HSTDPB          ;GET THE DRIVE SELECT CODE AND DENSITY
3306          MOV    A,M
3307          ANI   DPEDD          ;CHECK BIT DENSITY
3308          JZ    ONH37A          ; BR IF SINGLE
3309          MVI   A,CONMFM        ;SET DOUBLE BIT DENSITY CONTROL FLAG
3310          ONH37A: INX   H
3311          ORA   M              ;OR IN UNIT SELECT
3312          ORI   CONMD+CONIRQ    ;OR THE MOTOR & IRQ ON
3313          OUT  FD#CON
3314          MOV   B,A            ;SAVE THIS VALUE TEMPORARILY
3315          LXI  H,H37CTL        ;GET THE CURRENT VALUE OF THE CONTROL PORT
3316          MOV   A,M
3317          ANI  CONMD          ;IF THE MOTOR WAS ON
3318          JNZ  ONH37B          ; THEN WE DON'T HAVE TO WAIT FOR IT TO COME UP
3319          PUSH H
3320          LHL  HSTDPB          ;FIND OUT HOW FAST THE DRIVE COMES UP TO SPEED
3321          LXI  D,DPESEK-DPEHTE
3322          DAD  D
3323          MOV  A,M
3324          POP  H
3325          RAL
3326          IF    DPEMD-10000000B ;SETS CARRY IF UP FAST
3327          %:   DPEMD NE 10000000B
3328          ENDF
3329          MVI  A,(1000+3)/4+1    ;NORMAL TIMING (APPROX 1 SECOND)
3330          JNC  ONH37C
3331          RAR
3332          RAR
3333          ANI  03FH
3334          JMP  ONH37C
3335          ONH37B: MOV   A,M          ;GET THE OLD VALUE OF THE CONTROL PORT
3336          ANI  CONDS0+CONDS1+CONDS2+CONDS3 ;CHECK SELECT DRIVE(S)
3337          ANA  B              ;CHECK TO SEE IF SAME HEAD ALREADY DOWN
3338          MVI  A,0
3339          JNZ  ONH37C          ;YES, ALREADY LOADED, NO DELAY
3340          MVI  A,(50+3)/4+1    ;MUST DELAY FOR HEAD LOAD
3341          ONH37C: STA  DLYW
3342          MOV  M,B            ;SET NEW VALUE OF CONTROL PORT
3343
3344          RET
3345
3346          PAGE
3347          ;
3348          ; RST37 -- RESTORE HEAD
3349          ;
3350          ; ENTRY: (TRKPT) = ADDRESS OF DPETRK SLOT IN HEATH EXTENSION OF DPE
3351          ; EXIT:  VIA H37WAIT
3352          ; USES:  ALL
3353          ;
3354
3355          RST37: CALL  WBS37
3356          LHL  TRKPT          ;INDICATE TRACK IS 0
3357          MVI  M,0
3358
3359          INX  H              ;HL => STEP RATE

```

```

3360          IF      (DPETRK+1)-DPESEK
3361          %:      DPESEK NE (DPETRK+1)
3362          ENDF
3363          MOV      A,M
3364          ANI      OFFH-DPEMO
3365          ORI      FDCRST
3366          JMP      H37WAIT          ;ISSUE COMMAND
3367
3368          PAGE
3369          ;
3370          ; MOUNT H37 MEDIA.
3371          ;
3372
3373          MNTH37:  LHLD  HSTDPB          ;SET TRACK POINT TO UNKNOWN
3374                  LXI  D,DPETRK-DPEHTH
3375                  DAD  D
3376                  MVI  M,DPEUNK
3377
3378          ;+      JMP      RESH37          ;RESET DRIVE
3379
3380
3381
3382
3383          ;
3384          ; RESET H37
3385          ;
3386
3387          RESH37:  MVI  A,FD#CD          ;ACCESS C/D REGS
3388                  OUT  FD#INT
3389                  MVI  A,FD#CFI+FD#FINI ;TERMINATE ANY PRESENT ACTIVITY
3390                  OUT  FD#CMD
3391                  XRA  A
3392                  OUT  FD#CON          ;TURN OFF HARDWARE
3393                  STA  H37CTL
3394                  LXI  H,0
3395                  SHLD DLYMOS37
3396                  SHLD H37IRET
3397                  IN  FD#DAT          ;CLEAR ANY PENDING DRQ
3398
3399                  MVI  A,10          ;DELAY FOR AWHILE
3400          RESH371: ; TO LET STATUS SETTLE
3401                  DCR  A
3402                  JNZ  RESH371
3403                  IN  FD#STA          ;CLEAR ANY PENDING IRQ
3404
3405                  RET
3406
3407          PAGE
3408          ;
3409          ; SDT37 -- SEEK DESIRED TRACK AND SET SECTOR REG FOR DESIRED SECTOR
3410          ;
3411          ; ENTRY: (TRACK) = TRACK
3412          ;          (SECTOR) = SECTOR
3413          ; USES:  ALL
3414          ;
3415

```



```

3416          SDT37: LHL  TRKPT
3417          MOV  A,M          ;GET CURRENT TRACK
3418          LXI  H,TRACK      ;GET DESIRED TRACK #
3419          CMP  M
3420          JZ   SDT372        ;ALREADY AT DESIRED TRACK
3421
3422          CALL WBS37
3423          MOV  A,M
3424          CALL SDT376        ;DO SEEK
3425
3426          LHL  HSTDPB        ;CHECK IF 48TPI R/O MEDIA IN 96TPI DRIVE
3427          MOV  A,M
3428          ANI  DPE48R0
3429          JZ   SDT371        ; BR IF NOT == NO NEED TO DOUBLE STEP
3430
3431          MVI  A,FD#TS        ;GO THROUGH SEEK PROCEDURE AGAIN A
3432          OUT  FD#INT         ; A SECOND TIME
3433          LHL  TRKPT
3434          MOV  A,M
3435          OUT  FD#TRK        ;RESET CONTROLLER'S TRACK REG
3436          LDA  TRACK
3437          CALL SDT376        ;DO 2ND SEEK
3438
3439          SDT371: MVI  A,FD#TS ;ACCESS T/S REGS
3440          OUT  FD#INT
3441          LDA  TRACK         ;OUTPUT DESIRED TRACK TO TRACK REG
3442          OUT  FD#TRK        ; THIS IS DONE IN CASE SEEK ABORTED
3443          ; WHEN IT TRIED TO STEP TO NEGATIVE
3444          ; TRACK LEAVING TRACK REGISTER
3445          ; CONTAINING 0.
3446          LHL  TRKPT
3447          MOV  M,A           ;UPDATE IN MEMORY TRACK VALUE
3448
3449          MVI  A,(15+3)/4+1  ;SETTLE DELAY COUNT (15 MS)
3450          LXI  H,DLYW        ;CHECK IF DELAY COUNTER
3451          CMP  M             ; IS >= STEP SETTLE TIME
3452          JC   SDT372        ; IT IS
3453          MOV  M,A           ;FORCE DELAY FOR SETTLE TIME
3454
3455          SDT372: MVI  A,FD#TS ;ACCESS T/S REGS
3456          OUT  FD#INT
3457          LDA  SECTOR
3458          OUT  FD#SEC
3459
3460          SDT373: LDA  DLYW    ;WAIT UNTIL MOTOR IS UP TO SPEED,
3461          ORA  A             ; AND HEAD SETTLES DUE TO
3462          JNZ  SDT373        ; LOADING OR STEPPING
3463
3464          RET
3465
3466          ; DO SEEK
3467          ; (A) = DESIRED TRACK
3468
3469          SDT376: MOV  B,A
3470          MVI  A,FD#CD
3471          OUT  FD#INT        ;ACCESS C/D REGS

```

```
3472      MOV     A,B
3473      OUT     FD#DAT      ;TELL CONTROLLER DESIRED TRACK
3474
3475      LHL    TRKPT      ;GET STEP RATE
3476      INX     H
3477      MOV     A,M
3478      ANI     OFFH-DPEMO
3479      ORI     FDCSEK+FDHFLB ;OR IN COMMAND
3480      JMP     H37WAIT    ;ISSUE COMMAND AND WAIT
3481                      ; (RET THRU H37WAIT)
3482
3483      PAGE
3484      ;
3485      ; RDYH37 -- CHECK IF UNIT READY
3486      ; 1. DRIVE IS AVAILABLE
3487      ; 2. CORRECT TYPE OF MEDIA HAS BEEN INSERTED
3488      ;
3489      ; ENTRY: NONE
3490      ; EXIT: PSW/C = 0 IF READY
3491      ;       = 1 IF NOT READY
3492      ; USES: ALL
3493      ;
3494      ; THE NUMBER OF HOLE TRANSITIONS IS COUNTED IN THE TIME IT TAKES
3495      ; FOR 2 REVOLUTIONS (400MS). IF THE DISK INSERTED IS SOFT SECTORED,
3496      ; THEN 2 HOLES PLUS/MINUS 1 (4+-2 TRANSITIONS) SHOULD BE SEEN.
3497      ;
3498
3499      RDYH37:
3500      CALL    ONH37      ;TURN OF MOTOR AND SELECT DRIVE
3501
3502      LXI     H,DLYW     ;WAIT UNTIL DRIVE IS UP TO SPEED
3503      RDYH37A:
3504      MOV     A,M
3505      ANA     A
3506      JNZ     RDYH37A
3507
3508      MVI     A,FD#CD    ;ACCESS C/D REGS
3509      OUT     FD#INT
3510      MVI     A,FDCFI+FDFINI ;FORCE TYPE STATUS
3511      OUT     FD#CMD
3512      MVI     A,10
3513      RDYH37B:
3514      DCR     A          ;DELAY AWHILE TO LET CONTROLLER SETTLE
3515      JNZ     RDYH37B
3516
3517      LXI     H,TICCNT   ;GET TIME VALUE
3518      MVI     A,200
3519      ADD     M
3520      MOV     B,A       ;(B) = TIME VALUE
3521
3522      MVI     C,0        ;(C) = HOLE COUNTER
3523      MOV     D,C        ;(D) = INIT HOLE STATUS TO NO HOLE
3524
3525      RDYH37C:
3526      IN      FD#STA     ;GET HOLE STATUS
3527      ANI     FDSIND
```

```
.....
3528          CMP      D          ;CHECK IF CHANGE IN STATUS
3529          JZ       RDYH37D     ; BR IF NO CHANGE
3530
3531          MOV      D,A         ;SAVE NEW STATUS
3532          INR      C          ;COUNT TRANSITION
3533
3534          MVI      A,FDHDD     ;DEBOUNCE DELAY
3535 RDYH37C1:
3536          DCR      A
3537          JNZ      RDYH37C1
3538
3539 RDYH37D:
3540          MOV      A,B         ;CHECK IF TIME UP
3541          CMP      M
3542          JNZ      RDYH37C     ; BR IF NOT
3543          MOV      A,C         ;TIME UP --- CHECK # OF HOLES
3544          CPI      1*2
3545          JC       RDYH37E     ;IF < 1 THEN ERROR
3546          CPI      3*2+1
3547          CMC
3548          JNC      RDYH37F     ;IF <= 3 THEN OK
3549
3550 RDYH37E:
3551          MVI      A,FDSNRD    ;ERROR CODE FOR UNIT NOT READY
3552          CALL     H37E        ;REPORT ERROR
3553
3554 RDYH37F:
3555          JMP      H37DONE     ;RETRON VIA "H37DONE"
3556
3557
3558
3559
3560          ;
3561          ; WBS37 --- WAIT BEFORE STEPPING
3562          ; IT IS A DRIVE REQUIREMENT THAT AFTER A WRITE OPERATION, A STEP
3563          ; COMMAND SHOULD NOT BE EXECUTED BEFORE 1 MS AFTER THE WRITE.
3564          ; THEREFORE, TO INSURE THIS, WBS37 IS USED BEFORE ANY STEP
3565          ; OPERATIONS TO DELAY FOR APPROXIMATELY 1 MS.
3566          ;
3567          ; USES: A,F
3568          ;
3569
3570 WBS37: MVI      A,150
3571 WBS371: DCR      A
3572          JNZ      WBS371
3573          RET
3574
3575          ENDIF
3576
3577          PAGE
```

```

3578
3579             IF          H47T
3580
3581             ;           H47 DISK DEVICE DRIVER                23 JUL 81
3582
3583     H47DVD:  JMP          SETD47          ;SELECT DISK ENTRY POINT
3584             JMP          RD47           ;READ
3585             JMP          WR47           ;WRITE
3586             JMP          RESH47        ;RESET
3587             XRA A ! RET ! NOP         ;MOUNT
3588
3589             ;
3590             ;           8 INCH DISK DESCRIPTORS
3591             ;
3592             ;           DW          &XLATE#TABLE      ;POINTER TO TRANSLATE TABLE
3593             ;           DW          &PARAM#BLOCK     ;POINTER TO PARAMETER BLOCK
3594             ;           DB          DENSITY AND SIDES
3595             ;           DB          RECORDS#PER#SECTOR
3596             ;           DB          RECORDS#PER#ALLOCATION
3597
3598
3599     H47PMS:  DW          XLT0S,DPBOSS    ;FOR   SINGLE DENSITY SINGLE SIDED
3600             DB          0,1,8
3601
3602             DW          XLT0S,DPBOSD    ;           SINGLE           DOUBLE
3603             DB          DPE2S,1,16
3604
3605             DW          XLT0D,DPB0DS    ;           DOUBLE           SINGLE
3606             DB          DPEDD,2,16
3607
3608             DW          XLT0D,DPB0DD    ;           DOUBLE           DOUBLE
3609             DB          DPEDD+DPE2S,2,16
3610
3611             IF          H47ED
3612
3613             DW          0,DPBOES        ;           EXTENDED           SINGLE
3614             DB          DPEED+DPEDD,8,16
3615
3616             DW          0,DPBOED        ;           EXTENDED           DOUBLE
3617             DB          DPEED+DPEDD+DPE2S,8,16
3618
3619             ENDIF
3620             PAGE
3621     SETD47:  MVI          A,DRAS
3622             CALL         WCD
3623
3624             LHL         DPBX
3625             INX         H
3626             MOV         A,M
3627             ORI         001H
3628             CALL         WBD
3629
3630             CALL         W4TR
3631             CALL         H47IND          ;READ THE AUXILIARY STATUS INFORMATION
3632             PUSH        PSW
3633

```

```

3634      ANI    03H          ;FIND SECTOR LENGTH
3635      CPI    2
3636      IF     H47ED
3637      JC     SETD1        ;IF LEN <> 128 OR 256
3638      MVI    A,2          ; THEN MAKE INDEX 2
3639      ELSE
3640      JNC    SETD9        ;IF LEN <> 128 OR 256 THEN ERROR
3641      ENDIF
3642
3643      SETD1:  ADD    A          ;*2 TO ALLOW FOR SINGLE/DOUBLE DENSITY
3644      MOV    D,A          ;SAVE INDEX TO DATE
3645
3646      POP    PSW
3647      ANI    10H          ;CHECK FOR SIDE 1
3648      MOV    A,D
3649      JZ     SETD2
3650
3651      ORI    1            ;FLAG SIDE 1 AVAILABLE
3652
3653      SETD2:  MOV    B,A
3654      ADD    A          ;*2
3655      ADD    B          ;*3
3656      ADD    A          ;*6
3657      ADD    B          ;*7
3658
3659      LXI    H,H47PMS
3660      CALL  DADA
3661
3662      XCHG
3663      LHALD  SETDSKC        ;DE NOW POINTS TO PARAMETERS FOR THIS DISK
3664      LDAX  D            ;HL POINTS TO DPE FOR THIS DRIVE
3665      MOV   M,A          ;STORE THE NEW TRANSLATE TABLE
3666      INX  D
3667      INX  H
3668      LDAX  D
3669      MOV   M,A
3670      INX  D
3671
3672      PUSH  D
3673      LXI  D,DPEDPB-1    ;BUMP HL TO POINT TO DPB POINTER
3674      DAD  D
3675      POP  D
3676
3677      LDAX  D            ;NOW SET UP NEW DPB POINTER
3678      MOV  M,A
3679      INX  D
3680      INX  H
3681      LDAX  D
3682      MOV  M,A
3683      INX  D
3684
3685      LHALD  DPBX          ;GET POINTER TO THIS DRIVE
3686      MOV   A,M          ;FLAG DENSITY AND SIDENESS
3687      ANI  OFFH-DPEED-DPEDD-DPE2S
3688      MOV  B,A
3689      LDAX  D

```

```

3690      ORA      B
3691      MOV      M,A
3692      INX      D          ;RECORDS PER SECTOR
3693      INX      H
3694      INX      H
3695      LDAX    D
3696      MOV      M,A
3697      INX      D          ;AND RECORDS PER ALLOCATION
3698      INX      H
3699      LDAX    D
3700      MOV      M,A
3701
3702      XRA      A          ;INDICATE NO ERRORS
3703      RET
3704
3705      IF      NOT H47ED
3706      SETD9:  STC          ;INDICATE ERROR
3707      RET
3708      ENDIF
3709
3710      PAGE
3711      ;
3712      ; RESET H47.
3713      ;
3714
3715      RESH47: MVI      A,DCRS
3716      CALL     H47OUTC
3717      CALL     W4DONE      ;WAIT FOR THE CONTROLLER TO BE DONE
3718      XRA      A          ;CLEAR CONTROL REG
3719      CALL     H47OUTC
3720      RET
3721
3722      PAGE
3723      RD47:  MVI      A,DRD          ;DO A BUFFERED READ
3724      CALL     SET47
3725      JC      RDERR
3726
3727      RDH3:  CALL     H47INS          ;GET THE CONTROL PORT
3728      ANI     DSTR+DSDONE+DSERR ;WAIT FOR ANY LINE OF INTEREST
3729      JZ      RDH3          ;NOTHING YET
3730      ANI     DSDONE+DSERR      ;LOOK FOR ERROR OR END OF SECTOR
3731      JNZ     RDH4
3732      CALL     H47IND          ;GET DATA BYTE
3733      MOV      M,A          ;SAVE IT
3734      INX      H          ;BUMP MEMORY POINTER
3735      JMP     RDH3
3736
3737      RDH4:  CALL     H47INS          ;REREAD IN CASE ERROR WAS LATE
3738      ANI     DSERR          ;IF THERE WAS NO ERROR
3739      RZ          ; THEN RETURN
3740
3741      RDERR:
3742      ER47:  MVI      A,DRS          ;READ DISK SUBSYSTEM STATUS
3743      CALL     WCD
3744      CALL     W4TR
3745      CALL     H47IND

```

```

3746          STA      ERRTYP          ;SAVE ERROR CODE
3747
3748          LXI      H,H47MSG        ;PRINT EXTENDED ERROR MSG
3749          CALL     PRERR
3750
3751          CALL     RESH47           ;RESET THE DISK SUBSYSTEM
3752
3753          MVI      A,OFFH           ;FLAG ERROR
3754          STA      ERFLAG
3755          RET
3756
3757          H47MSG DB      'H47',0
3758
3759          PAGE
3760          WR47: MVI      A,DWR          ;DO A H47 BUFFERED WRITE
3761          CALL     SET47           ;DO COMMON SETUP
3762          JC       WRERR
3763          CALL     H47INS          ;CHECK ON DISK STATUS
3764          ANI      DSERR
3765          JNZ     WRERR           ;WHOOOPS
3766          WRH3: CALL     H47INS          ;CHECK DISK STATUS
3767          ANI      DSTR+DSDONE+DSERR
3768          JZ       WRH3
3769          ANI      DSDONE+DSERR
3770          JNZ     WRH4
3771          MOV      A,M             ;WRITE OUT THE NEXT BYTE
3772          CALL     H47OUTD
3773          INX      H               ;BUMP MEMORY POINTER
3774          JMP      WRH3
3775
3776          WRH4: CALL     H47INS          ;REREAD IN CASE ERROR WAS LATE
3777          ANI      DSERR
3778          RZ
3779
3780          WRERR: JMP      ER47          ;PRINT THE ERROR MESSAGE AND CODE
3781
3782          PAGE
3783          ;
3784          ; SET47 - COMMON H47 SETUP FOR READ/WRITE
3785          ;
3786
3787          SET47: CALL     WCD          ;WRITE THE COMMAND IN A TO DISK CONTROLLER
3788          RC
3789
3790          LHLD     HSTDPB
3791          MOV      A,M
3792          RAR                      ;IF LEAST SIGNIFICANT BIT IS 1 THEN DS
3793          IF      DPE2S-1
3794          %: DPE2S NE 1
3795          ENDF
3796          MVI      A,0
3797          STA      SIDE
3798          LDA      HSTTRK
3799          JNC     SET472          ;DISK IS SINGLE SIDED
3800          RRC                      ;DIVIDE TRACK BY TWO, SIDE INTO MSB
3801          PUSH    PSW

```

```
.....
3802          ANI      080H
3803          STA      SIDE
3804          POP      PSW
3805          ANI      07FH
3806
3807          SET472:  CALL   WBD
3808                      RC
3809
3810          LHL      HSTDPB
3811          INX      H          ;HLC POINTS TO SPECIFIED UNIT CODE
3812
3813          LDA      HSTSEC      ;GET DESIRED SECTOR
3814          INR      A          ;IBM DISK SECTORS NUMBERED 1 TO N
3815          ORA      M          ;OR IN THE SELECTED DRIVE
3816
3817          LXI      H, SIDE
3818          ORA      M
3819
3820          CALL     WBD
3821          RC
3822
3823          LXI      H, HSTBUF      ;{TEMPORARY} DESTINATION FOR DATA
3824          RET
3825
3826          PAGE
3827          ; WCD - WRITE COMMAND TO DISK
3828          ; DISK SHOULD BE "DONE" TO ACCEPT A NEW COMMAND
3829
3830          WCD:      CALL     W4DONE      ;WAIT UNTIL DONE BEFORE COMMANDING
3831                      RC          ;ERROR - DONE TIMEOUT
3832          CALL     H47OUTD      ;SEND COMMAND
3833          CALL     W4ND
3834          RET
3835
3836          ;
3837          ; WBD - WRITE BYTE TO DISK
3838          ; A BYTE CAN BE SENT WHEN TR IS ASSERTED
3839
3840          WBD:      CALL     W4TR
3841                      RC
3842          CALL     H47OUTD
3843          RET
3844
3845          ;
3846          ; W4DONE - WAIT FOR DONE TO BE ASSERTED
3847          ; TIME OUT IN ABOUT 4 SEC; RETURN WITH C SET
3848
3849          W4DONE:   PUSH     PSW
3850                      PUSH     B
3851          LXI      B, 0FFFFH
3852          W4D1:    CALL     H47INS
3853                      ANI      DSDONE      ;IS IT DONE YET?
3854                      JNZ      W4D2      ;YES, CLEAN UP AND RETURN
3855                      DCX      B          ;DECREMENT TIME OUT TIMER
3856                      MOV      A, B      ;IS IT ZERO YET?
3857                      ORA      C
```



```
.....
3858          JNZ     W4D1          ;NO, WAIT A WHILE LONGER
3859          POP     B              ;TIME OUT - RETURN WITH C SET
3860          POP     PSW
3861          STC
3862          RET
3863
3864          W4D2: POP     B
3865          W4D2: POP     PSW
3866          W4D2: ORA     A          ;CLEAR CARRY
3867          W4D2: RET
3868
3869          ;
3870          ;          W4ND - WAIT FOR NOT DONE
3871          ;
3872
3873          W4ND: PUSH    PSW
3874          W4ND1: CALL   H47INS
3875          W4ND1: ANI    DSDONE
3876          W4ND1: JNZ    W4ND1
3877          W4ND1: POP    PSW       ;RETURN AFTER DONE REMOVED
3878          W4ND1: RET
3879
3880          ;
3881          ;          W4TR - WAIT FOR TR TO BE ASSERTED
3882          ;
3883
3884          W4TR: PUSH    PSW
3885          W4TR1: CALL   H47INS     ;GET THE DISK STATUS
3886          W4TR1: ANI    DSDONE+DSTR
3887          W4TR1: JZ     W4TR1
3888          W4TR1: ANI    DSDONE
3889          W4TR1: JNZ    W4TR2
3890          W4TR1: POP    PSW
3891          W4TR1: ORA    A
3892          W4TR1: RET
3893          W4TR2: POP    PSW
3894          W4TR2: STC
3895          W4TR2: RET
3896
3897          PAGE
3898          H47INS: IN     78H          ;INPUT STATUS BYTE
3899          H47INSI EQU   %-1
3900          RET
3901
3902          H47OUTC: OUT    78H          ;OUTPUT CONTROL BYTE
3903          H47OUTC1 EQU  %-1
3904          RET
3905
3906          H47IND: IN     79H          ;INPUT DATA BYTE
3907          H47INDI EQU   %-1
3908          RET
3909
3910          H47OUTD: OUT    79H          ;OUTPUT DATA BYTE
3911          H47OUTD1 EQU  %-1
3912          RET
3913
.....
```

3914

ENDIF

3915

PAGE

3916

```

3917
3918          IF      H&7T
3919
3920          ;      H&7 DEVICE DRIVER MODULE                26 MAR 82
3921          ;
3922          ;*      JMTITTSLER / BILL ZURNEY
3923          ;      HEATH/ZENITH SOFTWARE GROUP
3924          ;      HILLTOP ROAD
3925          ;      SAINT JOSEPH, MICHIGAN 49085
3926          ;
3927
3928 H&7DVD:  JMP      SET&7          ;SELECT DISK ENTRY POINT
3929          JMP      RD&7           ;READ
3930          JMP      WR&7           ;WRITE
3931          JMP      RESH&7        ;RESET
3932          XRA  A ! RET ! NOP     ;MOUNT
3933
3934          SET&7:
3935          XRA      A              ;1ST SECTOR WILL BE READ
3936          STA      HSTSEC        ; (SECTOR # 0 TO SPT-1)
3937
3938          LHLD    DPBX
3939          MOV     A, M
3940          ANI    DPETYPF
3941          CPI    DPEH&7F        ;CHECK FOR FLOPPY
3942          JZ     SET&7I         ;BR IF YES
3943
3944          ; 1ST TIME SELECTION FOR HARD DISK.
3945
3946          LXI    H, 0            ;READ LABEL
3947          SHLD   HSTTRK
3948          CALL   RD&7
3949          JNZ    SET&79         ; BR IF ERROR
3950
3951          CALL   CHKLAB         ;CHECK CHECKSUM OF LABEL
3952          JNZ    SET&79         ; BR IF INCORRECT CHECKSUM
3953
3954          IF     PARTITN
3955
3956          LHLD   DPBX           ;CHECK IF LABEL'S BEGINNING OF
3957          LXI    B, DPETRK-DPEHTH ; PARTITION SECTOR NUMBER MATCHES
3958          DAD   B              ; DRIVE TABLE'S
3959          CALL   HLIHL
3960          XCHG
3961          LHLD   HSTBUF+LABHTH+DPETRK-DPEHTH
3962          CALL   CPHLDE
3963          JNZ    SET&79         ;BR IF NOT -- PARTITION HAS BEEN MOVED
3964
3965          LHLD   DPBX           ;CHECK IF LABEL'S LAST SECTOR # + 1
3966          LXI    B, DPEUPB-DPEHTH ; OF PARTITION MATCHES
3967          DAD   B              ; DRIVE TABLE'S
3968          CALL   HLIHL
3969          XCHG
3970          LHLD   HSTBUF+LABHTH+DPEUPB-DPEHTH
3971          CALL   CPHLDE
3972          JNZ    SET&79         ;BR IF NOT -- PARTITION SIZE HAS CHANGED

```

```

3973
3974                ENDIF
3975
3976                LHL D,DPBX                ;UPDATE CP/M RECORDS PER ALLOCATION BLOCK
3977                LXI B,DPERPAB-DPEPTH
3978                DAD B
3979                LXI D,HSTBUF+LABHTH+DPERPAB-DPEPTH
3980                LDAX D
3981                MOV M,A
3982
3983                LHL SETDSKC                ;UPDATE DISK PARAMETER BLOCK VALUES
3984                LXI B,DPEDPB
3985                DAD B
3986                CALL HLIHL
3987                LXI D,HSTBUF+LABDPB
3988                MVI C,DPBL
3989                CALL MOVEITX
3990
3991                JMP SET674
3992
3993                ; 1ST TIME SELECTION FOR FLOPPY.
3994
3995                SET671:
3996                LHL DPBX                ;GET ADDR OF HEATH EXTENSIONS FOR DRIVE
3997                MOV A,M                ;GET DENSITY FROM TABLE
3998                ANI DPEDD
3999                JZ SET671A                ; CURRENT DENSITY IS SINGLE
4000                MVI A,HDFDEN                ;DOUBLE DENSITY
4001
4002                SET671A:
4003                STA SET67A                ;ASSUME CURRENT DENSITY
4004                CALL FDD67                ;SET CURRENT DENSITY/SINGLE SIDED
4005                JNZ SET679                ;BR IF ERROR
4006                LXI H,1                ;TRY READING TRACK 1 SECTOR 1
4007                SHLD HSTTRK
4008                CALL RD67
4009                JZ SET672                ;BR IF NOT READ ERROR
4010
4011                LDA ERRRTYP
4012                CPI HDEIAM                ;CHECK FOR ID ADDR MARK NOT FOUND
4013                JZ SET671C                ; BR IF ID ADDR MARK NOT FOUND
4014                CPI HDERNF                ;CHECK FOR RECORD NOT FOUND
4015                JNZ SET679                ; BR IF OTHER TYPE OF ERROR
4016
4017                SET671C:
4018                LXI H,SET67A                ;TRY OTHER DENSITY
4019                MOV A,M
4020                XRI HDFDEN
4021                MOV M,A
4022                CALL FDD67                ;SET OTHER DENSITY/SINGLE SIDED
4023                CALL RD67                ;VERIFY OTHER DENSITY
4024                JNZ SET679                ; BR IF NOT
4025
4026                SET672: LXI H,SET67A
4027                MOV A,M
4028                ORI HDFSID                ;TRY DOUBLE SIDED

```

```

4029          MOV     M,A
4030          CALL    FDD67          ;SET DENSITY/SIDE DESCRIPTION
4031          JNZ     SET679          ;BR IF ERROR
4032
4033          CALL    RD67            ;TRY READING 2ND SIDE
4034          JZ      SET673          ;BR IF NO READ ERROR
4035          LDA     ERRYP
4036          CPI     HDEDNR          ;CHECK FOR DRIVE NOT READY
4037          JNZ     SET679          ; BR IF OTHER TYPE OF ERROR
4038          LXI    H,SET67A
4039          MOV     A,M
4040          ANI    'OFFH-HDFSID'    ;BACK OFF TO SINGLE SIDED
4041          MOV     M,A
4042
4043          SET673: LDA    SET67A
4044          MOV     B,A
4045          ADD     A                ;#2
4046          ADD     B                ;#3
4047          ADD     A                ;#6
4048          ADD     B                ;#7
4049          LXI    H,H67PMS
4050          CALL    DADA            ;HL = ADDR OF SPECIFIC DISK TYPE VALUES
4051          XCHG                    ;DE NO POINTS TO PARAMETERS FOR THIS DISK
4052          LALD   SETDSK          ;HL POINTS TO DPE FOR THIS DRIVE
4053
4054          LDAX   D                ;UPDATE XLATE TABLE ADDR
4055          MOV     M,A
4056          INX   D
4057          INX   H
4058          LDAX   D
4059          MOV     M,A
4060          INX   D
4061          LXI    B,DPEDPB-1      ;BUMP HL TO POINT TO DPB POINTER
4062          DAD   B
4063          LDAX   D                ;NOW SET UP NEW DPB POINTER
4064          MOV     M,A
4065          INX   D
4066          INX   H
4067          LDAX   D
4068          MOV     M,A
4069          LHL   DPBX             ;GET POINTER TO DRIVE SPECIFIC VALUES
4070          XCHG                    ;(DE)=DRIVE SPECIFIC VALUES POINTER
4071                                ;(HL)=H67 DISK DESCRIPTORS POINTER
4072          INX   H
4073          LDAX   D
4074          ANI    'OFFH-DPEDD-DPE2S'
4075          ORA   M
4076          STAX  D                ;UPDATE DENSITY/SIDE FLAGS
4077          INX   D
4078          INX   D
4079          INX   H
4080          MOV     A,M
4081          STAX  D                ;RECORDS PER SECTOR
4082          INX   H
4083          INX   D
4084          MOV     A,M

```

```
4085 STAX D ;RECORDS PER ALLOCATION
4086
4087 LDA SET67A
4088 CALL FDD67 ;SET CORRECT DENSITY/SIDE DESCRIPTION
4089 JNZ SET679 ;BR IF ERROR
4090
4091 SET674:
4092 XRA A ;INDICATE NO ERRORS
4093 RET
4094
4095 SET679: STC ;INDICATE ERROR
4096 RET
4097
4098 ; DISK DESCRIPTORS
4099 ;
4100 ; DW &XLATE$TABLE ;POINTER TO TRANSLATE TABLE
4101 ; DW &PARAM$BLOCK ;POINTER TO PARAMETER BLOCK
4102 ; DB DENSITY AND SIDES
4103 ; DB RECORDS$PER$SECTOR
4104 ; DB RECORDS$PER$ALLOCATION
4105
4106 H67PMS: DW XLT0S,DPB0SS ;SINGLE DENSITY/SINGLE SIDED
4107 DB 0,1,8
4108
4109 DW XLT0S,DPB0SD ;SINGLE DENSITY/DOUBLE SIDED
4110 DB DPE2S,1,16
4111
4112 DW XLT0D,DPB0DS ;DOUBLE DENSITY/SINGLE SIDED
4113 DB DPEDD,2,16
4114
4115 DW XLT0D,DPB0DD ;DOUBLE DENSITY/DOUBLE SIDED
4116 DB DPEDD+DPE2S,2,16
4117
4118 SET67A: DS 1 ;DENSITY/SIDE DESCRIPTION VALUE
4119
4120 PAGE
4121 ;
4122 ; RESET H67 CONTROLLER.
4123 ;
4124
4125 RESH67: MVI A,HDFRES
4126 CALL H67OUTC
4127 MVI A,10 ;DELAY AWHILE
4128 RESH671:
4129 DCR A
4130 JNZ RESH671
4131
4132 RET
4133
4134 PAGE
4135 ;
4136 ; RECALIBRATE HEAD.
4137 ;
4138
4139 RCL67: MVI A,HDCRCL
4140 STA CMDBUF+HDOOP
```

```

4141          CALL      SETUP3
4142          MVI       A,1           ;INDICATE DON'T DO RS ON ERROR
4143          STA      RS67B
4144          JMP      CMPSTAT
4145
4146          PAGE
4147          ;
4148          ; READ SENSE BYTES.
4149          ;
4150          ; ENTRY:  COMMAND BUFFER ALREADY CONTAINS UNIT SELECT VALUE
4151          ; EXIT:   4 SENSE BYTES ARE AT 'RS67A'
4152          ;          ERR'TYP' CONTAINS ERROR TYPE & CODE
4153          ;          (A) CONTAINS ERROR TYPE & CODE
4154          ; USES:   ALL
4155          ;
4156
4157          RS67:  MVI     A,HDCRS
4158          STA     CMDBUF+HDOOP
4159          XRA     A
4160          STA     CMDBUF+HDOCON
4161          CALL    SETUP3
4162          MVI     A,1           ;INDICATE DON'T DO RS IF ERROR
4163          STA     RS67B
4164          LXI     H,RS67A
4165          MVI     M,0
4166
4167          IF      H67BLKIO
4168          MVI     A,4           ;NUMBER OF BYTES TO READ
4169          STA     RD673         ; MODIFY COUNT INSTRUCTION
4170          ENDDIF
4171          CALL    RD671
4172
4173          MVI     A,0           ;ASSUME NO STATUS IN CASE OF ERROR ON RS
4174          JNZ     RS671
4175          LDA     RS67A
4176          RS671: ANI     HDSET+HDSEC
4177          STA     ERR'TYP
4178          RET
4179
4180          RS67A  DS     4
4181          RS67B  DS     1
4182
4183          PAGE
4184          ;
4185          ; FLOPPY DISK DESCRIPTION.
4186          ;
4187          ; ENTRY:  (A) = TRACK FORMAT CODE
4188          ; EXIT:   PSW/2 = 0 IF ERROR
4189          ;          = 1 IF NO ERROR
4190          ;          EXIT VIA 'CMPSTAT'
4191          ; USES:   ALL
4192          ;
4193
4194          FDD67: STA     CMDBUF+HD6TFC
4195          LHL     HSTDPB
4196          INX     H

```

```

4197          MOV     A,M
4198          STA     CMDBUF+HD&LUN
4199          MVI     A,HDCFDD
4200          STA     CMDBUF+HD&OP
4201          CALL    SETUP3
4202          JMP     CMPSTAT
4203
4204          PAGE
4205          ;
4206          ; READ SECTOR.
4207          ;
4208          ; ENTRY: (HSTDPB) = ADDR OF DPE HEATH EXTENSIONS FOR DRIVE
4209          ;          (HSTRK) = TRACK
4210          ;          (HSTSEC) = SECTOR (0 TO SPT-1)
4211          ; EXIT:  PSW/Z = 0 IF ERROR
4212          ;          = 1 IF NO ERROR
4213          ;          'ERFLAG' = 0 IF NO ERROR
4214          ;          '<>' 0 IF ERROR
4215          ;          'HSTBUF' CONTAINS SECTOR
4216          ; USES:  ALL
4217          ;
4218
4219          RD67: CALL    H67I0INIT      ;INIT I/O
4220          RD67A: CALL    RD670        ;DO READ
4221          JZ      H67XOK              ; BR IF NO ERROR
4222          CALL    H67RETRY           ;CHECK IF I SHOULD DO RETRY FOR FLOPPY
4223          JNC    RD67A              ; BR IF I SHOULD
4224          JMP     H67EXIT            ; OTHERWISE EXIT
4225
4226          RD670: MVI     A,HDCRD      ;READ COMMAND
4227          CALL    SETUP              ;SETUP COMMAND BUFFER, GET ATTENTION, SEND CMD
4228          RNZ                    ; RET IF ERROR
4229          LXI     H,HSTBUF           ;POINTER TO DATA STORAGE
4230          IF     H67BLKIO
4231          MVI     A,128              ;BLOCK COUNT
4232          STA     RD673              ; MODIFY COUNT INSTRUCTION
4233          ENDIF
4234
4235          ; LOW LEVEL I/O READ ROUTINE
4236          ;
4237          ; ENTRY: (HL)=BUFFER ADDRESS
4238          ; EXIT:  VIA CMPSTAT
4239          ; USES:  ALL
4240
4241          IF     H67BLKIO
4242
4243          RD671: LDA     H67IND1      ;GET DATA INPUT PORT #
4244          MOV     C,A
4245          RD672: CALL    H67INS       ;GET THE BUS STATUS
4246          ANA     A                  ;LOOK FOR REQ
4247          IF     HDBREQ-10000000B
4248          %:    HDBREQ NE 10000000B
4249          ENDIF
4250          JP     RD672
4251          ANI     HDBCMD              ;CHECK FOR COMPLETION
4252          JNZ     CMPSTAT

```



```

4253      MVI      B,0          ;BLOCK COUNT
4254      RD673:  EQU      $-1          ; (MODIFIED BY CALLING ROUTINE)
4255      DB      OEDH,OB2H      ;DO BLOCK INPUT
4256      JMP      RD672
4257
4258      ELSE
4259
4260      RD671:  CALL     H67INS          ;GET THE BUS STATUS
4261      ANA      A              ;LOOK FOR REQ
4262      IF      HDBREQ=10000000B
4263      %:      HDBREQ NE 10000000B
4264      ENDIF
4265      JP      RD671
4266      ANI      HDBCMD          ;CHECK FOR COMPLETION
4267      JNZ     CMPSTAT
4268      CALL     H67IND          ;INPUT DATA FROM THE CONTROLLER
4269      MOV      M,A            ;STORE IT IN THE HOST BUFFER
4270      INX     H
4271      JMP     RD671
4272
4273      ENDIF
4274
4275      PAGE
4276      ;
4277      ; WRITE SECTOR.
4278      ;
4279      ; ENTRY: (HSTDPB) = ADDR OF DPE HEATH EXTENSIONS FOR DRIVE
4280      ; (HSTTRK) = TRACK
4281      ; (HSTSEC) = SECTOR (0 TO SPT-1)
4282      ; EXIT:  PSW/Z = 0 IF ERROR
4283      ;          1 IF NO ERROR
4284      ;          ^ERFLAG = 0 IF NO ERROR
4285      ;          <> 0 IF ERROR
4286      ;          DATA AT ^HSTBUF WRITTEN
4287      ; USES:  ALL
4288      ;
4289
4290      WR67:  CALL     H67IDINIT        ;INIT I/O
4291      WR67A: CALL     WR670            ;DO WRITE
4292      JZ     H67XOK          ; BR IF NO ERROR
4293      CALL     H67RETRY          ;CHECK IF I SHOULD DO RETRY FOR FLOPPY
4294      JNC     WR67A            ; BR IF I SHOULD
4295      JMP     H67EXIT          ; OTHERWISE EXIT
4296
4297      WR670: MVI      A,HDCWR        ;WRITE COMMAND
4298      CALL     SETUP            ;SETUP COMMAND BUFFER, GET ATTENTION, SEND CMD
4299      RNZ
4300      LXI     H,HSTBUF          ;POINTER TO DATA SOURCE
4301
4302      IF      H67BLKIO
4303
4304      WR671: LDA      H67OUTD1        ;GET OUTPUT DATA PORT #
4305      MOV      C,A
4306      WR672: CALL     H67INS          ;GET THE BUS STATUS
4307      ANA      A              ;LOOK FOR REQ
4308      IF      HDBREQ=10000000B

```

```
4309      %:      HDBREQ NE 10000000B
4310      ENDIF
4311      JP      WR672
4312      ANI      HDBCMD      ;CHECK FOR COMPLETION
4313      JNZ      CMPSTAT
4314      MVI      B,128      ;128 BYTE BLOCK
4315      DB      0EDH,0B3H   ;DO BLOCK OUTPUT
4316      JMP      WR672
4317
4318      ELSE
4319
4320      WR671:  CALL   H67INS      ;GET THE BUS STATUS
4321      ANA      A      ;WAIT FOR REQ
4322      IF      HDBREQ-10000000B
4323      %:      HDBREQ NE 10000000B
4324      ENDIF
4325      JP      WR671
4326      ANI      HDBCMD      ;CHECK FOR COMPLETION
4327      JNZ      CMPSTAT
4328      MOV      A,M      ;GET THE NEXT BYTE
4329      CALL   H67OUTD      ;SEND IT TO THE DISK
4330      INX      H
4331      JMP      WR671
4332
4333      ENDIF
4334
4335      PAGE
4336      ;
4337      ; INIT I/O VARIABLES FOR RETRYING ON FLOPPY.
4338      ;
4339
4340      H67IOINIT:
4341      LDA      ERFLAG
4342      STA      H67SEF
4343      MVI      A,3
4344      STA      H67RCNT
4345      RET
4346
4347      H67SEF DS 1
4348      H67RCNT DS 1
4349
4350
4351      ;
4352      ; CHECK IF I SHOULD DO RETRY FOR FLOPPY.
4353      ;
4354      ; EXIT - PSW/C - 0=RETRY , 1=NO RETRY
4355      ;
4356
4357      H67RETRY:
4358      LHL     HSTDPB      ;CHECK IF DOING I/O TO FLOPPY
4359      MOV     A,M
4360      ANI     DPETYPF
4361      CPI     DPEH67F
4362      JNZ     H67RETRY1   ; BR IF NOT
4363
4364      LDA     ERRTYP      ;CHECK ERROR TYPE
```

```

4365          ANI     HDECLS
4366          CPI     HDECLSI
4367          JNZ     H67RETRY1      ; BR IF NOT TYPE 1 ERROR
4368
4369          CALL    RCL67          ;RESTORE HEAD ON DRIVE
4370
4371          ANA     A              ;CLEAR CARRY BIT
4372          LXI     H,H67RCNT      ;DECREMENT RETRY COUNTER
4373          DCR     M
4374          RNZ
4375          ; RET INDICATING DO RETRY IF COUNT <> 0
4376          H67RETRY1:
4377          STC              ;RET INDICATING DON'T RETRY
4378          RET
4379
4380
4381          ;
4382          ; H67 READ/WRITE EXIT POINT
4383          ;
4384
4385          H67XOK:
4386          LDA     H67SEF          ;EXIT WITH "ERFLAG" AT THE SAME VALUE
4387          STA     ERFLAG          ; AS ON ENTRY
4388          XRA     A              ;INDICATE NO ERROR
4389          RET
4390
4391          H67EXIT:
4392          LDA     ERFLAG          ;EXIT INDICATING ERROR STATUS IN "ERFLAG"
4393          ORA     A
4394          RET
4395
4396          PAGE
4397          ;
4398          ; CHECK COMPLETION STATUS.
4399          ;
4400          ; EXIT: PSW/Z = 0 IF ERROR
4401          ;          = 1 IF NO ERROR
4402          ;          "ERFLAG" = 0 IF NO ERROR
4403          ;          <> 0 IF ERROR
4404          ; USES: ALL
4405          ;
4406
4407          CMPSTAT: CALL    H67IND      ;INPUT THE COMPLETION STATUS
4408          MOV     C,A              ;SAVE TEMPORARILY
4409          LREQ:  CALL    H67INS      ;WAIT FOR LAST REQ
4410          ANA     A              ;REQ?
4411          IF     HDBREQ-10000000B
4412          %:    HDBREQ NE 10000000B
4413          ENDIF
4414          JP     LREQ              ;NOT YET
4415          MOV     B,A              ;SAVE FOR CHECKING LATER
4416          CALL    H67IND          ;GET LAST BYTE
4417
4418          EI                      ;ALLOW INTERRUPTS AGAIN
4419
4420          DRA     A              ;SHOULD BE A BYTE OF ZEROS

```

```

4421          MVI    A,HDENZM      ;ERROR CODE
4422          JNZ    H67ER        ; BR IF ERROR
4423
4424          MOV    A,B
4425          ANI    HDBPE         ;CHECK FOR PARITY ERROR ON BUS
4426          MVI    H,HDEBP      ;ERROR CODE
4427          JNZ    H67ER        ; BR IF ERROR
4428
4429          MOV    A,C           ;GET THE COMPLETION BYTE
4430          ANI    HDFERR+HDFPE  ;CHECK COMPLETION STATUS
4431          RZ
4432          ; RET IF NO ERRORS
4433
4433          ANI    HDFERR        ;CHECK IF I/O ERROR OR BAD PARITY
4434          MVI    A,HDEPAR      ;ERROR CODE FOR BAD PARITY
4435          JZ     H67ER        ; BR IF NOT I/O ERROR
4436
4437          LDA    RS67B         ;CHECK IF ERROR DURING REQUEST SENSE
4438          ANA    A
4439          RNZ
4440          ; IF YES -- THEN DON'T TRY ANOTHER
4441
4441          CALL   RS67          ;DO A REQUEST SENSE TO GET ERROR CODE
4442
4443          H67ER: STA    ERRTP    ;SAVE ERROR CODE
4444
4445          CPI    HDEFW         ;CHECK FOR WRITE FAULT
4446          CZ     RCL67        ; IF YES -- RECALIBRATE HEAD TO CLEAR ERROR
4447
4448          LXI    H,H67MSG      ;PRINT EXTENDED ERROR MESSAGE
4449          CALL   PRERR
4450
4451          ORI    OFFH          ;INDICATE ERROR
4452          STA    ERFLAG
4453          RET
4454
4455          H67MSG DB    'H67',0
4456
4457          PAGE
4458          SETUP: LXI    H,CMDBUF ;POINTER TO THE COMMAND BUFFER
4459          MOV    M,A           ;SAVE COMMAND IN BUFFER STRING
4460          INX    H             ;POINT TO LOGICAL UNIT SLOT
4461          XCHG
4462          LHLD  HSTDPB        ;(DE)=COMMAND BUFFER POINTER
4463          ;GET UNIT SELECT VALUE
4463          INX    H
4464          MOV    A,M
4465          STAX  D             ;PLACE IT IN COMMAND BUFFER
4466          INX    D             ;BUMP COMMAND BUFFER POINTER
4467          PUSH  D             ;SAVE COMMAND BUFFER POINTER FOR LATER
4468
4469          ; COMPUTE LOGICAL SECTOR NUMBER.
4470          LHLD  HSTTRK        ;START WITH CP/M TRACK #
4471          MOV    D,H
4472          MOV    E,L
4473          DAD   H             ;#2
4474          DAD   D             ;#3
4475          DAD   H             ;#6
4476          DAD   H             ;#12

```

```

4477          DAD      D          ;#13
4478          DAD      H          ;#26
4479          IF      NSPT67-26
4480          %:      NSPT67 NE 26
4481          ENDIF
4482          LDA      HSTSEC      ;SECTORS NUMBERED 0 TO SPT-1
4483          CALL     DADA        ;HL IS NOW THE LOGICAL SECTOR NUMBER
4484          XCHG     ;NOW DE IS
4485          LHL      HSTDPB      ;ADD TRACK 0 OFFSET
4486          LXI      B,DPETRK-DPEHTH
4487          DAD      B
4488          CALL     HLIHL       ;(HL) = TRACK 0 OFFSET
4489          XCHG     ;(DE) = TRACK 0 OFFSET
4490          ;(HL) = LOGICAL SECTOR #
4491          DAD      D
4492
4493          ; CHECK IF WITHIN PARTITION BOUNDARIES.
4494          MOV      A,D
4495          ORA      E
4496          JZ       SETUP2      ;BR IF FLOPPY OR NOT IN PARTITION MODE
4497          ; (ASSUMED IF TRACK 0 OFFSET = 0)
4498
4499          CALL     CPHLDE      ;CHECK LOGICAL SECTOR # AGAINST
4500          ; BEGINNING OF PARTITION
4501          JC       SETUP9      ; BR IF BEFORE
4502
4503          XCHG     ;(DE) = LOGICAL SECTOR #
4504          LHL      HSTDPB      ;GET LAST SECTOR # + 1 OF PARTITION
4505          LXI      B,DPEUPB-DPEHTH
4506          DAD      B
4507          CALL     HLIHL
4508          XCHG     ;(DE) = LAST SECTOR # + 1 OF PARTITION
4509          ;(HL) = LOGICAL SECTOR #
4510          CALL     CPHLDE
4511          JNC      SETUP9      ; BR IF AFTER PARTITION
4512
4513          SETUP2: XCHG          ;(DE) = LOGICAL SECTOR NUMBER
4514
4515          ; PUT LOGICAL SECTOR NUMBER INTO COMMAND BUFFER
4516          POP      H
4517          MOV      M,D          ;MSB FIRST
4518          INX     H
4519          MOV      M,E
4520          INX     H
4521          MVI     M,1          ;1 BLOCK
4522          INX     H
4523          MVI     M,0          ;0 THE CONTROL BYTE
4524
4525          ; SEND COMMAND TO H67 CONTROLLER.
4526
4527          SETUP3:
4528          XRA     A            ;INDICATE DO RS ON ERROR
4529          STA     RS67B
4530
4531          LXI     D,-1          ;INIT TIMEOUT COUNTER
4532

```

```
4533 GETCON: CALL H&7INS ;GET THE STATUS
4534 ANI HDBBSY ;IF NOT BUSY
4535 JZ SETUP3A ; THEN GO AHEAD
4536 DCX D
4537 MOV A,D ;CHECK TIMEOUT COUNTER
4538 ORA E
4539 JZ SETUP8 ; BR IF TIMEOUT
4540 JMP GETCON
4541
4542 SETUP3A:
4543 MVI A,HDFSEL ;ASSERT SEL AND DATA0
4544 CALL H&7OUTC
4545
4546 LXI D,-1 ;INIT TIMEOUT COUNTER
4547
4548 CBUSY: CALL H&7INS
4549 ANI HDBBSY ;IF BUSY
4550 JNZ SETUP3B ; THEN WE GOT ITS ATTENTION
4551 DCX D
4552 MOV A,D ;CHECK TIMEOUT COUNTER
4553 ORA E
4554 JZ SETUP8 ; BR IF TIMEOUT
4555 JMP CBUSY
4556
4557 SETUP3B:
4558 DI ;DON'T WANT TO BE BOTHERED
4559
4560 MVI A,HDFDE ;DATA ENABLE
4561 CALL H&7OUTC
4562
4563 LXI H,CMDBUF
4564 OUTCOM: CALL H&7INS
4565 ANI HDBREQ+HDBCMD+HDBIO
4566 IF HDBREQ=10000000B
4567 %: HDBREQ NE 10000000B
4568 ENDIF
4569 JP OUTCOM ;WAIT FOR REQ
4570 CPI HDBREQ+HDBCMD+HDBIO ;CHECK FOR REQ/CMD/OUTPUT
4571 JNZ SETUP4
4572 MOV A,M ;GET NEXT BYTE OF COMMAND
4573 CALL H&7OUTD
4574 INX H
4575 JMP OUTCOM
4576
4577 SETUP4: XRA A ;INDICATE NO ERROR IN SETUP
4578 RET
4579
4580 ; ERROR IN SETUP DUE TO TIMEOUT.
4581
4582 SETUP8: MVI A,HDET0 ;ERROR CODE
4583 JMP H&7ER ;HANDLE ERROR
4584
4585 ; ERROR IN SETUP DUE TO OUT OF BOUNDS CONDITION.
4586
4587 SETUP9: POP H ;DISCARD COMMAND BUFFER POINTER
4588 MVI A,HDE0B ;ERROR CODE
```

```
.....
4589                JMP      H67ER          ;HANDLE ERROR
4590
4591                PAGE
4592                ;
4593                ; PRIMITIVE H67 I/O PORT ROUTINES.
4594                ;
4595
4596                H67OUTD: DUT      0          ;OUTPUT TO DATA PORT
4597                H67OUTD1 EQU     $-1
4598                RET
4599
4600                H67IND: IN       0          ;INPUT FROM DATA PORT
4601                H67IND1 EQU     $-1
4602                RET
4603
4604                H67OUTC: DUT      0          ;OUTPUT TO CONTROL PORT
4605                H67OUTC1 EQU     $-1
4606                RET
4607
4608                H67INS: IN       0          ;INPUT FROM BUS STATUS PORT
4609                H67INS1 EQU     $-1
4610                RET
4611
4612                ; H67 COMMAND BUFFER
4613                ; INITIALIZED FOR SEEK OPERATION AT COLD BOOT
4614
4615                CMDBUF: DB      HDCSEK      ;OPCODE
4616                DB      0                ;LUN 1 LOG ADR2
4617                DB      0CH              ;LOG ADR1
4618                DB      80H              ;LOG ADR0
4619                DB      1                ;NUMBER OF BLOCKS
4620                DB      0                ;CONTROL BYTE
4621
4622                ENDIF
4623
4624                PAGE
.....
```

```
4625
4626 080D C31C08 NULDVD: JMP SETNUL
4627 0810 C31C08      JMP RDNUL
4628 0813 C31C08      JMP WRNUL
4629 0816 C31C08      JMP RESNUL
4630 0819 C31C08      JMP MNTNUL
4631
4632          SETNUL:
4633          RDNUL:
4634          WRNUL:
4635          RESNUL:
4636          MNTNUL:
4637 081C 3EFF      MVI  A, OFFH
4638 081E 32AE10     STA  ERFLAG
4639 0821 37        STC
4640 0822 C9        RET
4641
4642          PAGE
```



```

4643
4644 ;
4645 ; 2 MS CLOCK INTERRUPT SERVICE ROUTINE
4646 ;
4647 IF TOD
4648 NDAYS DB 31,28,31,30,31,30,31,31,30,31,30,31
4649 ENDF
4650 0823 0000000000TODVAL DB 0,0,0,0,0,0 ;TIME OF DAY (SEC [0-59] ,
4651 ; MIN [0-59] , HRS [0-23] , DAY[1-N] ,
4652 ; MON [1-12] , YR [0-255])
4653 0829 0000 EVTCTR DW 0 ;EVENT DOWN COUNTER
4654 082B 00 DLYMO: DB 0
4655 082C 00 DLYH: DB 0
4656 082D 00 DLYW: DB 0
4657
4658 082E 22B410 CLOCK: SHLD HSAV ;SAVE AF, HL
4659 0831 E1 POP H ;GET THE RETURN ADDRESS
4660 0832 22B610 SHLD RETSAV ;SAVE IT, BUT NOT ON USER STACK
4661 0835 F5 PUSH PSW ;SAVE AF, HL
4662
4663 0836 210D00 LXI H,CTLPRT ;GET THE CURRENT VALUE OF THE CONTROL PORT
4664 0839 7E MOV A,M
4665 083A D3F2 OUT H88CTL ;AND OUTPUT AGAIN, RESETTING INT REQ
4666
4667 083C 23 INX H ;POINT TO THE H8FLAG
4668 083D 7E MOV A,M
4669 083E B7 ORA A ; IF 0 THEN RUNNING IN H/Z89
4670 083F CA4408 JZ CLK0 ; THEN DON'T OUTPUT TO 3608
4671 0842 D3F0 OUT H8CTL ; ELSE CONTAINS H8TR TO RESET H8 CLOCK
4672
4673 0844 2A0B00 CLK0: LHLD TICCNT ;GET THE TICK COUNTER
4674 0847 23 INX H ;INCREMENT IT
4675 0848 220B00 SHLD TICCNT
4676
4677 084B 7D MOV A,L ;IS IT A MULTIPLE OF 1/2 SECOND?
4678 084C B7 ORA A
4679 084D C27A08 JNZ CLKRET ; IF NOT
4680
4681 IF TOD
4682 MOV A,H ;IS IT A MULTIPLE OF 1 SECOND?
4683 RAR
4684 JC CLK1 ; BR IF NOT
4685 LXI H,TODVAL ;HANDLE TIME OF DAY
4686 INR M ; SECONDS
4687 MOV A,M
4688 CPI 60
4689 JC CLK1
4690 MVI M,0
4691 INX H ; MINUTES
4692 INR M
4693 MOV A,M
4694 CPI 60
4695 JC CLK1
4696 MVI M,0
4697 INX H ; HOURS
4698 INR M

```

```

4699      MOV     A,M
4700      CPI     24
4701      JC      CLK1
4702      MVI     M,0
4703      INX     H                ; DAYS
4704      INX     H
4705      MOV     A,M
4706      LXI     H,NDAYS-1
4707      ADD     L
4708      MOV     L,A
4709      MOV     A,H
4710      ACI     0
4711      MOV     H,A
4712      MOV     A,M
4713      LXI     H,TODVAL+3
4714      INR     M
4715      CMP     M
4716      JNC     CLK1
4717      MVI     M,1
4718      INX     H                ; MONTHS
4719      INR     M
4720      MOV     A,M
4721      CPI     13
4722      JC      CLK1
4723      MVI     M,1
4724      INX     H                ; YEARS
4725      INR     M
4726      ENDIF
4727
4728      CLK1:
4729
4730      IF      EVENT
4731      LHL     EVTCTR            ;DOWN COUNT EVENT COUNTER IF <> 0
4732      MOV     A,H
4733      ORA     L
4734      JZ      CLK2
4735      DCX     H
4736      SHLD   EVTCTR
4737      ENDIF
4738
4739      CLK2:
4740
4741      IF      H17T
4742      LXI     H,DLYMO            ;POINTER TO MOTOR DELAY TIMER
4743      MOV     A,M
4744      ORA     A                ;IF ALREADY ZERO
4745      JZ      CLK4                ; THEN DON'T DECREMENT
4746
4747      DCR     M                ;DECREMENT TIMER
4748      JNZ     CLK3                ; IF IT HAS NOT TIMED OUT CHECK HEADS
4749
4750      LDA     DEVCTL            ;GET THE CURRENT VALUE OF CONTROL PORT
4751      ANI     OFFH-DFMO        ;TURN OFF MOTOR
4752      STA     DEVCTL
4753      OUT     DPDC
4754

```

```

4755 0866 23      CLK3:  INX   H           ;POINT TO THE HEAD DELAY
4756 0867 7E      MOV   A,M
4757 0868 B7      ORA   A           ;IF ALREADY ZERO
4758 0869 CA7A08  JZ    CLK4        ; THEN DON'T DECREMENT
4759
4760 086C 35      DCR   M           ;DECREMENT TIMER
4761 086D C27A08  JNZ   CLK4        ; IF IT HAS NOT TIMED OUT THEN SKIP
4762
4763 0870 3A0F00   LDA   DEVCTL      ;DESELECT THE DRIVE
4764 0873 E6F1     ANI   OFFH-U0-UI-U2
4765 0875 320F00   STA   DEVCTL
4766 0878 D37F     OUT   DPDC
4767
4768
4769                CLK4:
4770                IF    H37T
4771                LXI   H,DLYM037      ;POINTER TO MOTOR DELAY TIME FOR H37
4772                MOV   A,M
4773                ORA   A           ;IF ALREADY ZERO
4774                JZ    CLKRET        ; THEN DON'T DECREMENT
4775
4776                DCR   M           ;DECREMENT TIMER
4777                JNZ   CLK5        ; IF IT HAS NOT TIMED OUT CHECK HEADS
4778
4779                LDA   H37CTL        ;GET THE CURRENT VALUE OF CONTROL PORT
4780                ANI   OFFH-CONMO     ;TURN OFF MOTOR
4781                STA   H37CTL
4782                OUT   FD$CON
4783
4784                CLK5:  INX   H           ;POINT TO THE HEAD DELAY FOR H37
4785                MOV   A,M
4786                ORA   A           ;IF ALREADY ZERO
4787                JZ    CLKRET        ; THEN DON'T DECREMENT
4788
4789                DCR   M           ;DECREMENT TIMER
4790                JNZ   CLKRET        ; IF IT HAS NOT TIMED OUT THEN SKIP
4791
4792                LDA   H37CTL        ;DESELECT THE DRIVE
4793                ANI   OFFH-CONDS0-CONDS1-CONDS2-CONDS3
4794                STA   H37CTL
4795                OUT   FD$CON
4796                ENDIF
4797
4798 087A 3A0B00   CLKRET: LDA   TICCNT
4799 087D 1F      RAR
4800 087E D88A08   JC    CLKR2
4801 0881 212D08  LXI   H,DLYW     ;CHECK WAIT TIMER
4802 0884 7E      MOV   A,M           ; AND DECREMENT IT IF IT IS NOT
4803 0885 B7      ORA   A           ; ALREADY ZERO
4804 0886 C88A08  JZ    CLKR2
4805 0889 35      DCR   M
4806 088A F1     CLKR2: POP   PSW           ;RESTORE THE MACHINE STATE
4807 088B 2AB610  LHLD RETSAV
4808 088E E5     PUSH  H
4809 088F 2AB410  LHLD  HSAV
4810 0892 FB     EI

```

4811 0893 C9 RET
4812
4813 PAGE

```

4814
4815 ;
4816 ; CHKLAB -- CHECK CHECKSUM OF LABEL
4817 ;
4818 ; ENTRY: 'HSTBUF' CONTAINS SECTOR WITH LABEL
4819 ; EXIT: 'PSW/Z' = 0 IF 'BAD' CHECKSUM
4820 ; = 1 IF GOOD CHECKSUM
4821 ; USES: 'A;F;B;H;L'
4822 ;
4823
4824 CHKLAB:
4825 0894 AF XRA A ;ZERO ACCUM
4826 0895 0619 MVI B,LABLEN ;GET LENGTH OF LABEL
4827 0897 213&0D LXI H,HSTBUF+LABEL
4828
4829 CHKLABI:
4830 089A 86 ADD M ;ADD VALUES
4831 089B 23 INX H
4832 089C 05 DCR B
4833 089D C29A08 UNZ CHKLABI
4834
4835 08A0 3C INR A ;INR CHECKSUM VALUE AND SET/RESET PSW/Z
4836
4837 08A1 C9 RET
4838
4839 ;
4840 ; CPHLDE - COMPARE (HL) TO (DE)
4841 ; USES 'A;F'
4842 ;
4843
4844 CPHLDE:
4845 08A2 7C MOV A,H
4846 08A3 BA CMP D
4847 08A4 C0 RNZ
4848 08A5 7D MOV A,L
4849 08A6 BB CMP E
4850 08A7 C9 RET
4851 ;
4852 ; DADA -- ADD 0,A TO HL
4853 ; USES 'AF'
4854
4855 DADA: ADD L
4856 08A9 6F MOV L,A
4857 08AA D0 RNC
4858 08AB 24 INR H
4859 08AC C9 RET
4860 ;
4861 ; GETDPE -- GET ADDRESS OF DPE
4862 ;
4863 ; ENTRY: (A) = LOGICAL/MAPPED DRIVE #
4864 ; EXIT: (HL) = ADDRESS OF DPE
4865 ; USES: 'A;F;D;E;H;L'
4866 ;
4867
4868 GETDPE:
4869 08AD E&0F ANI 0FH ;GET MAPPED DRIVE #

```

```

4870 08AF 6F      MOV     L,A          ;FIND DPE ADDR
4871
4872 08B0 2600    MVI     H,0
4873 08B2 54      MOV     D,H
4874 08B3 5D      MOV     E,L
4875 08B4 29      DAD     H             ;#2
4876 08B5 19      DAD     D             ;#3
4877 08B6 29      DAD     H             ;#6
4878 08B7 29      DAD     H             ;#12
4879 08B8 29      DAD     H             ;#24
4880                IF     DPEL-24
4881                %:    DPEL NE 24
4882                ENDF
4883
4884 08B9 115200   LXI     D,DPBASE
4885 08BC 19      DAD     D
4886
4887 08BD C9      RET
4888
4889                ;
4890                ; GETDPEX -- GET ADDR OF DPE'S HEATH EXTENSIONS
4891                ;
4892                ; ENTRY: (A) = LOGICAL/MAPPED DRIVE #
4893                ; EXIT: (HL) = ADDR OF HEATH EXTENSIONS
4894                ; USES: A,F,D,E,H,L
4895                ;
4896
4897                GETDPEX:
4898 08BE CDAD08   CALL    GETDPE       ;GET ADDR OF DPE
4899
4900 08C1 111000   LXI     D,DPEHTH     ;GET ADDR OF HEATH EXTENSIONS
4901 08C4 19      DAD     D
4902
4903 08C5 C9      RET
4904
4905                ;
4906                ; HLIHL - LOAD HL INDIRECT THROUGH HL
4907                ; USES AF
4908
4909 08C6 7E      HLIHL: MOV     A,M
4910 08C7 23      INX     H
4911 08C8 66      MOV     H,M
4912 08C9 6F      MOV     L,A
4913 08CA C9      RET
4914
4915                ;
4916                ; MOVEITX -- MOVE DATA FROM ONE AREA OF MEMORY TO ANOTHER
4917                ;
4918                ; ENTRY: (C) = COUNT
4919                ; (DE) = SOURCE
4920                ; (HL) = DESTINATION
4921                ; USES: ALL
4922                ;
4923
4924                MOVEITX:
4925 08CB EB      XCHG          ;(HL)=SOURCE (DE)=DESTINATION

```

```
4926
4927          IF      $-MOVEIT
4928          %:      MOVEIT MUST IMMEDIATELY FOLLOW MOVEITX
4929          ENDIF
4930
4931          ;
4932          ; MOVEIT -- MOVE DATA FROM ONE AREA OF MEMORY TO ANOTHER
4933          ;
4934          ; ENTRY:  (C) = COUNT
4935          ;          (DE) = DESTINATION
4936          ;          (HL) = SOURCE
4937          ; USES:  ALL
4938          ;
4939
4940 08CC 3E81  MOVEIT: MVI    A,81H
4941 08CE C680          ADI    80H
4942 08D0 E2D808       JPO    MOVEIT1      ;BR IF RUNNING ON 8080
4943
4944 08D3 0600          MVI    B,0
4945 08D5 EDB0          DB    '0EDH;0B0H'      ;USE 'Z80' BLOCK MOVE INSTRUCTION
4946 08D7 C9           RET
4947
4948          MOVEIT1:
4949 08D8 7E           MOV    A,M      ;MOVE DATA USING 8080 CODE
4950 08D9 12           STAX  D
4951 08DA 23           INX  H
4952 08DB 13           INX  D
4953 08DC 0D           DCR  C
4954 08DD C2D808       JNZ   MOVEIT1
4955 08E0 C9           RET
4956
4957          PAGE
```

```

4958
4959 ;*****
4960 ;
4961 ; LOGICAL DEVICE ROUTINES
4962 ;
4963 ; THESE ROUTINES HANDLE THE LOGICAL TO PHYSICAL
4964 ; DEVICE MAPPING ESTABLISHED BY THE CP/M IOBYTE
4965 ;
4966 ;
4967 ;
4968 ; CONSOLE STATUS
4969 ;
4970 ;
4971 08E1 CDE908 CONST: CALL CONS ;GET STATUS OF SPECIFIC DEVICE
4972 08E4 B7 ORA A
4973 08E5 C8 RZ ;IF NOT READY RETURN 0 IN A
4974 08E6 3EFF MVI A,OFFH ; ELSE RETURN FF
4975 08E8 C9 RET
4976 ;
4977 08E9 3A0300 CONS: LDA IOBYTE ;USE BITS 1-0 FOR CONSOLE DEVICE
4978 08EC CD6209 CALL INDXIT
4979 08EF 820A DW TTYSTAT
4980 08F1 6E09 DW CRTSTAT
4981 08F3 F708 DW RDRST ;2: BATCH MODE (USE READER DEVICE)
4982 08F5 6E09 DW CRTSTAT
4983 ;
4984 ; READER STATUS
4985 ;
4986 08F7 3A0300 RDRST: LDA IOBYTE
4987 08FA 0F RRC
4988 08FB CD6309 CALL GOTOIT
4989 08FE 820A DW TTYSTAT
4990 0900 1C0C DW BUSY ;UNIMPLEMENTED INPUTS
4991 0902 F00A DW MDSTAT
4992 0904 6E09 DW CRTSTAT
4993 ;
4994 ; CONSOLE INPUT
4995 ;
4996 0906 3A0300 CONIN: LDA IOBYTE
4997 0909 CD6209 CALL INDXIT
4998 090C 680A DW TTYIN ;0: TTY
4999 090E 9609 DW CRTIN ;1: CRT
5000 0910 5309 DW READER ;2: BAT (READER INPUT)
5001 0912 9609 DW CRTIN ;UC1: CRT INPUT, LST: OUTPUT
5002 ;
5003 ; CONSOLE OUT
5004 ;
5005 0914 3A0300 CONOUT: LDA IOBYTE
5006 0917 CD6209 CALL INDXIT
5007 091A 930A DW TTYOUT ;0: TTY
5008 091C 480A DW CRTOUT ;1: CRT
5009 091E 3209 DW LIST ;2: BAT (OUTPUT TO LST)
5010 0920 3209 DW LIST ;UC1: CRT INPUT, LST: OUTPUT
5011 ;
5012 ; LISTST - LIST STATUS CHECK
5013 ;

```



```

5014
5015 0922 3A0300 LISTST: LDA IOBYTE ;GET THE CURRENT IOBYTE
5016 0925 07 RLC ;SHIFT INTO POSITION
5017 0926 07 RLC
5018 0927 CD6209 CALL INDXIT
5019 092A 250B DW TTYOS ;0: TTY
5020 092C 3C0B DW CRTOS ;1: CRT
5021 092E 760B DW LPTOS ;2: LPT
5022 0930 E40B DW DBDOS ;3: DIABLO
5023
5024 ;
5025 ; LIST OUT
5026 ;
5027 ;
5028 0932 3A0300 LIST: LDA IOBYTE
5029 0935 07 RLC ;BITS 7-6 TO 2-1
5030 0936 07 RLC
5031 0937 CD6209 CALL INDXIT
5032 093A 930A DW TTYOUT ;0: TTY
5033 093C 480A DW CRTOUT ;1: CRT
5034 093E A50A DW LPTOUT ;2: LPT
5035 0940 CD0A DW DBD ;3: DIABLO
5036 ;
5037 ; PUNCH OUT
5038 ;
5039 ;
5040 0942 3A0300 PUNCH: LDA IOBYTE ;BITS 4-5 TO 1-2
5041 0945 0F RRC
5042 0946 0F RRC
5043 0947 0F RRC
5044 0948 CD6309 CALL GOTOIT
5045 094B 930A DW TTYOUT ;0: TTY
5046 094D 200C DW DMYOUT
5047 094F 0A0B DW MDOUT ;2: UP1 MODEM PORT OUTPUT
5048 0951 480A DW CRTOUT
5049 ;
5050 ; READER IN
5051 ;
5052 ;
5053 0953 3A0300 READER: LDA IOBYTE ;BITS 3-2 TO 2-1
5054 0956 0F RRC
5055 0957 CD6309 CALL GOTOIT
5056 095A 680A DW TTYIN ;0: TTY
5057 095C 1E0C DW DMYIN
5058 095E EE0A DW MDIN ;2: UR1 MODEM PORT INPUT
5059 0960 9609 DW CRTIN
5060 ;
5061 ; DISPATCH SUBROUTINE = INDEXED TABLE JUMP
5062 ;
5063 0962 07 INDXIT: RLC
5064 0963 E606 GOTOIT: ANI 06H ;MASK BITS
5065 0965 E3 XTHL ;SAVE HL, GET TABLE ADDRESS
5066 0966 CD80B CALL DADA ;ADD 0,A TO HL
5067 0969 CD608 CALL HLIHL ;GET ADDRESS IN HL
5068 096C E3 XTHL ;XCHG ROUTINE ADDRESS, OLD HL
5069 096D C9 RET ;DISPATCH

```

5070
5071

PAGE

```

5072
5073 ;*****
5074 ;
5075 ; PHYSICAL DEVICE ROUTINES
5076 ;
5077 ; ACCESSED VIA THE LOGICAL DEVICE ROUTINES ABOVE
5078 ;
5079 ;
5080 ;
5081 ; "CRT" PHYSICAL STATUS ROUTINE
5082 ; USES H84PT1
5083 ;
5084 CRTSTAT:
5085 IF NOT INTINP
5086 LDA MODE ;GET THE MODE BYTE
5087 RAR ;IF THE LSB = 1
5088 JC CRTS1 ; THEN CONSOLE ON H8-5
5089 IF MODEB0=1
5090 %: MODEB0 NE 1
5091 ENDIF
5092
5093 LXI H;H84PT1 ;POINTER TO BASE PORT
5094 JMP US ;GET STATUS
5095
5096 CRTS1: IN H85CRT+1 ;GET 8251 STATUS REGISTER
5097 ANI 02H ;MASK RXRDY
5098 RET
5099 ENDIF
5100
5101 IF INTINP
5102 096E 3A070D LDA CRTB ;FIND OUT HOW MANY CHARACTERS ARE IN THE BUFFER
5103 0971 B7 ORA A
5104 0972 C0 RNZ ;RET IF CHARACTER AVAILABLE
5105
5106 ; INSURE INTERRUPTS FOR CRT INPUT ARE ENABLED.
5107 ; A USER PROGRAM MAY HAVE TURN THEM OFF.
5108 0973 3A3600 CRTS2: LDA MODE ;G. CRT ON H8-5 CARD
5109 0976 IF RAR
5110 0977 D28809 JNC CRTS2A ; BR IF NOT
5111 IF MODEB0=1
5112 %: MODEB0 NE 1
5113 ENDIF
5114
5115 097A DBFB IN H85CRT+1 ;IF TRANSMITTER IS EMPTY, THEN INSURE
5116 097C E604 ANI 04H ; INTERRUPTS ARE ENABLED. MUST WAIT FOR
5117 097E CA9309 JZ CRTS3 ; TXE SO I DON'T LOSE OUTPUT
5118 0981 3E17 MVI A,17H ;ENABLE RX & TX PLUS INTERRUPTS
5119 0983 D3FB OUT H85CRT+1
5120 0985 C39309 JMP CRTS3
5121
5122 0988 3A3600 CRTS2A: LDA H84PT1 ;ENABLE RECEIVER INTERRUPTS ON 8250
5123 098B 3C INR A
5124 098C 329209 STA CRTS2B
5125 098F 3E01 MVI A,1
5126 0991 D300 OUT 0
5127 0992 = CRTS2B EQU #-1

```

```

5128
5129 0993 FB      CRTS3: EI          ;INSURE MASTER ENABLE
5130
5131 0994 AF      XRA      A          ;INDICATE NO CHARACTER AVAILABLE
5132 0995 C9      RET
5133      ENDIF
5134
5135      ;
5136      ;"CRT" PHYSICAL INPUT ROUTINE
5137      ;
5138
5139      CRTIN:
5140      IF      NOT INTINP
5141      LDA      MODE      ;GET MODE BYTE
5142      RAR      ;IF LSB = 1
5143      JC      CRTI1      ; THEN CONSOLE ON H8-5
5144      IF      MODEB0-1
5145      %:      MODEB0 NE 1
5146      ENDIF
5147
5148      LXI      H,H84PT1
5149      CALL     UI          ;GET CHAR FROM 8250
5150      ANI      7FH        ;MASK PARITY
5151      RET
5152
5153      CRTI1: IN      H85CRT+1      ;CHECK IF RXRDY
5154      ANI      02H
5155      JZ      CRTI1      ;WAIT FOR CHARACTER
5156
5157      IN      H85CRT      ;GET CHARACTER
5158      ANI      7FH        ;MASK PARITY
5159      RET
5160      ENDIF
5161
5162      IF      INTINP
5163 0996 CD6E09    CRTIN1: CALL     CRTSTAT      ;CHECK IF CHARACTER AVAILABLE
5164 0997 CA9609    JZ      CRTIN1      ;BR IF NO CHARACTER AVAILABLE
5165
5166 099C F3      DI          ;A CHARACTER IS AVAILABLE -- DON'T
5167      ; LET ANYONE BOTHER ME WHILST I GET IT
5168 099D 21070D    LXI      H,CRTB      ;POINTER TO NUMBER OF CHARS IN BUFFER
5169 09A0 35      DCR      M          ;MARK ONE TAKEN
5170 09A1 2A080D    LHL     CRTGET      ;GET THE POINTER TO THE CHAR
5171 09A4 4E      MOV      C,M        ;PUT THE CHAR IN C
5172 09A5 23      INX      H          ;ADVANCE THE POINTER
5173 09A6 7D      MOV      A,L        ;CHECK THAT IT WASN'T ADVANCED PAST END
5174 09A7 FEE2    CPI      CRTBND MOD 256
5175 09A9 C2AF09    JNZ     CRTIN2
5176 09AC 21BA10    LXI      H,CRTBUF
5177 09AF 22080D    CRTIN2: SHLD     CRTGET
5178 09B2 FB      EI          ;ALLOW ME TO BE BOTHERED
5179 09B3 79      MOV      A,C        ;PUT THE CHARACTER IN A (TOO)
5180 09B4 C9      RET
5181
5182      ; CRT INTERRUPT SERVICE ROUTINE
5183

```

```

5184 09B5 22B410 CRTISR: SHLD HSAV ;SAVE THE PROCESSOR STATE
5185 09B8 E1 POP H ;GET RETURN ADDRESS
5186 09B9 22B610 SHLD RETSAV
5187 09BC F5 PUSH PSW
5188 09BD 210000 LXI H,0 ;SAVE THE OLD SP
5189 09C0 39 DAD SP
5190 09C1 22B810 SHLD OLDSP
5191 09C4 31F210 LXI SP,LCLSTK ;SET UP OUR VERY OWN STACK
5192 09C7 213800 LXI H,HS4PT1 ;POINTER TO SERIAL DEVICE STRUCTURE
5193 09CA 3E02 MVI A,2 ;INPUT INTERRUPT IDENTIFICATION REG
5194 09CC CD410A CALL IPINX
5195 09CF FE04 CPI 0100B ;CHECK FOR RECEIVED DATA AVAILABLE INT
5196 09D1 C2390A JNZ CRTIS6 ;IT WASN'T THIS 8250
5197
5198 IF BRKKEY
5199 MVI A,5 ;CHECK FOR BREAK
5200 CALL IPINX
5201 ANI 10H
5202 JNZ CRTIS8
5203 ENDIF
5204
5205 09D4 CD400A CALL IU11 ;GET THE CHARACTER
5206
5207 CRTIS1:
5208 09D7 E67F ANI 7FH ;MASK PARITY BIT
5209 09D9 F5 PUSH PSW ;SAVE THE CHARACTER
5210 09DA 3A070D LDA CRTB ;GETTING NEAR THE END OF THE BUFFER?
5211 09DD FE24 CPI CRTLEN-4
5212 09DF DA110A JC CRTIS2 ;NOT YET
5213
5214 09E2 3A3600 LDA MODE ;WARN HIM BY SENDING BELL
5215 09E5 1F RAR
5216 IF MODEB0-1
5217 X: MODEB0 NE I
5218 ENDIF
5219 09E6 D2F409 JNC CRTIS1B ;BR IF NOT HS-5
5220 CRTIS1A:
5221 09E9 DBFB IN HS5CRT+1 ;WAIT FOR HS-5 TRANSMITTER READY
5222 09EB 1F RAR
5223 09EC D2E909 JNC CRTIS1A
5224 09EF 3EFA MVI A,HS5CRT ;SET OUTPUT DATA PORT ADDRESS
5225 09F1 C3020A JMP CRTIS1C
5226 CRTIS1B:
5227 09F4 3E05 MVI A,5 ;WAIT FOR 8250 TRANSMITTER READY
5228 09F6 213800 LXI H,HS4PT1
5229 09F9 CD410A CALL IPINX
5230 09FC E620 ANI 20H
5231 09FE CAF409 JZ CRTIS1B
5232 0A01 7E MOV A,M ;SET OUTPUT DATA PORT ADDRESS
5233 CRTIS1C:
5234 0A02 32080A STA CRTIS1D ;MODIFY OUT INSTRUCTION WITH DATA PORT ADDR
5235 0A05 3E07 MVI A,BELL
5236 0A07 D300 OUT 0 ;SEND BELL CHARACTER
5237 0A08 = CRTIS1D EQU $-1
5238
5239 0A09 3A070D LDA CRTB ;CAN WE ACCEPT THIS CHARACTER

```

```

5240 0A0C FE28          CPI      CRTLEN
5241 0A0E CA350A       JZ      CRTISS
5242
5243 0A11 F1           CRTIS2: POP      PSW          ;RECALL THE CHARACTER
5244 0A12 2A0A0D       LHL    CRTPUT      ;THE BUFFER PUT POINTER
5245 0A15 77           MOV     M,A         ;PUT THE CHARACTER IN THE BUFFER
5246 0A16 23           INX    H            ;ADVANCE THE POINTER
5247 0A17 7D           MOV     A,L         ;CHECK FOR WRAP-AROUND
5248 0A18 FEE2        CPI      CRTBND MOD 256
5249 0A1A C2200A       JNZ    CRTIS3
5250 0A1D 21BA10       LXI    H,CRTBUF
5251 0A20 220A0D       CRTIS3: SHLD   CRTPUT
5252 0A23 21070D       LXI    H,CRTB
5253 0A26 34           INR    M            ;ANOTHER CHARACTER IS AVAILABLE
5254
5255 0A27 2AB810       CRTIS4: LHL    OLDSP      ;RESTORE THE OLD STACK
5256 0A2A F9           SPHL
5257 0A2B F1           POP     PSW         ;RESTORE THE MACHINE STATE
5258 0A2C 2AB610       LHL    RETSAV
5259 0A2F E5           PUSH   H
5260 0A30 2AB410       LHL    HSAV
5261 0A33 FB           EI              ;ENABLE MORE INTERRUPTS
5262 0A34 C9           RET              ;AND RETURN
5263 0A35 F1           CRTIS5: POP     PSW         ;CLEAN STACK
5264 0A36 C3270A       JMP     CRTIS4
5265
5266 0A39 DBFB        CRTIS6: IN     H85CRT+1    ;GET STATUS
5267                IF     BRKKEY
5268                ANI    20H      ;HAD AN OVERRUN?
5269                JNZ    CRTI11    ;YES, BREAKOUT
5270                ENDIF
5271
5272 0A3B DBFA          IN     H85CRT          ;IF THE CRT 8250 DIDN'T DO IT, THE 8251 DID
5273 0A3D C3D709       JMP     CRTIS1
5274
5275                IF     BRKKEY
5276                CRTIS8: CALL   IUI1      ;GET THE GARBAGE
5277                LXI    D,6000    ;WAIT FOR THE DUST TO SETTLE
5278                CRTIS9: MVI    A,5
5279                CALL   IPINX
5280                ANI    9
5281                JNZ    CRTIS8
5282                DCX    D
5283                MOV     A,D
5284                ORA    E
5285                JNZ    CRTIS9
5286                CALL   IUI1      ;MAKE SURE THERE IS NO GARBAGE PRESENT
5287
5288                CRTI10: LXI    H,CRTBUF
5289                SHLD   CRTGET
5290                SHLD   CRTPUT
5291                XRA    A
5292                STA    CRTB
5293                IF     H17T
5294                CALL   RESH17
5295                ENDIF

```

```

5296          IF      H37T
5297          CALL    RESH37
5298          ENDIF
5299          IF      H47T
5300          CALL    RESH47
5301          ENDIF
5302          IF      H67T
5303          CALL    RESH67
5304          ENDIF
5305          CALL    FLUSH1          ;FLUSH (ABORT) HOST BUFFER
5306          EI
5307          JMP     BOOT
5308
5309          CRTI11: IN      H85CRT
5310          MVI     A,17H
5311          OUT    H85CRT+1
5312
5313          LXI     D,6000
5314          CRTI12: IN      H85CRT+1
5315          ANI     22H
5316          JNZ    CRTI11
5317          DCX    D
5318          MOV    A,D
5319          ORA    E
5320          JNZ    CRTI12
5321
5322          IN      H85CRT
5323          JMP    CRTI10
5324          ENDIF
5325
5326          ; IUI1 - INPUT FROM UART AT INTERRUPT TIME
5327
5328          0A40 AF      IUI1: XRA    A
5329          ;          JMP    IPINX
5330
5331          ;
5332          ; IPIN - INPUT BYTE FROM PORT IN (A) AT INTERRUPT TIME
5333          ;
5334
5335          0A41 86      IPINX: ADD    M
5336          0A42 32460A IPIN: STA    IPIN+1
5337          0A45 DB00   IPINI: IN     00H          ;SELF-MODIFYING CODE
5338          0A47 C9      RET
5339
5340          ;          ENDIF
5341          ;
5342          ; "CRT" PHYSICAL OUTPUT ROUTINES
5343          ;
5344
5345          0A48 CD3C0B CRTOUT: CALL   CRTOS
5346          0A4B B7      ORA     A
5347          0A4C CA480A JZ      CRTOUT
5348
5349          0A4F 3A3600   LDA     MODE          ;GET MODE BYTE
5350          0A52 1F      RAR          ;IF LSB = 1
5351          0A53 DA590A JC      CRT01          ; THEN CONSOLE ON HS-5

```

```
5352          IF      MODEB0-1
5353          %:      MODEB0 NE 1
5354          ENDF
5355
5356 0A56 C3310C      JMP      U0          ;OUTPUT CHARACTER IN C
5357
5358 0A59 E5          CRT01: PUSH     H
5359 0A5A 23          INX      H
5360 0A5B 23          INX      H          ;POINT TO FLAG BYTE
5361 0A5C 7E          MOV      A,M
5362 0A5D 17          RAL
5363 0A5E E1          POP      H
5364 0A5F 79          MOV      A,C
5365 0A60 DC920C     CC      MUC          ;MAP TO UPPER CASE
5366 0A63 D3FA       OUT      H85CRT
5367
5368 0A65 C3410C     JMP      POUT2        ;CHECK FOR NULLS
5369
5370          ;
5371          ; TTY INPUT
5372          ;
5373
5374 0A68 213B00     TTYIN: LXI      H,H84PT2
5375 0A6B 3A3700     LDA      MODE2        ;CHECK FOR H89-11
5376 0A6E E601       ANI      MODE2B0
5377 0A70 C2790A     JNZ      TTYIN1        ; BR IF H89-11
5378 0A73 CD520C     CALL     UI
5379 0A76 C37F0A     JMP      TTYIN2
5380 0A79 214400     TTYIN1: LXI     H,H11PT2
5381 0A7C CD700C     CALL     EPI
5382 0A7F E67F       TTYIN2: ANI     07FH
5383 0A81 C9         RET
5384
5385          ;
5386          ; TTY STATUS
5387          ;
5388 0A82 213B00     TTYSTAT: LXI    H,H84PT2
5389 0A85 3A3700     LDA      MODE2        ;CHECK FOR H89-11
5390 0A88 E601       ANI      MODE2B0
5391 0A8A CA210C     JZ       US          ; BR IF NOT
5392 0A8D 214400     LXI     H,H11PT2
5393 0A90 C3600C     JMP      EPS
5394
5395          ;
5396          ; TTY OUTPUT
5397          ;
5398
5399 0A93 CD250B     TTYOUT: CALL    TTY0S
5400 0A96 B7         ORA      A
5401 0A97 CA930A     JZ       TTYOUT
5402 0A9A 3A3700     LDA      MODE2        ;CHECK FOR H89-11
5403 0A9D E601       ANI      MODE2B0
5404 0A9F C27B0C     JNZ     EPO          ; BR IF H89-11
5405 0AA2 C3310C     JMP      U0
5406
5407          ;
```



```

5408          ; LINE PRINTER OUT
5409          ;
5410
5411 0AA5 3A010D  LPTOUT: LDA    DCLPOS      ;IF DON'T CHECK LP OUTPUT STATUS
5412 0AA8 B7      ORA    A
5413 0AA9 C2B30A  JNZ    LPTOU2      ; THEN SKIP THE TEST
5414
5415 0AAC CD760B  LPTOU1: CALL   LPTOS      ; ELSE, WAIT FOR READY LP OUTPUT STATUS
5416 0AAF B7      ORA    A
5417 0AB0 CAAC0A  JZ     LPTOU1
5418
5419 0AB3 213E00  LPTOU2: LXI    H,H84PT3    ;POINTER TO DEVICE STRUCTURE
5420 0AB6 11040D  LXI    D,LPTCTS          ;AND ONE TO CHAR TO SEND
5421
5422 0AB9 AF      XRA    A          ;FORCE A CHECK OF LP OUTPUT STATUS
5423 0ABA 32010D  STA    DCLPOS          ; NEXT TIME
5424
5425 0ABD 3A3700  LDA    MODE2           ;CHECK FOR H89-11 PARALLEL
5426 0AC0 E603  ANI    MODE2B1+MODE2B0
5427 0AC2 FE03  CPI    MODE2B1+MODE2B0
5428 0AC4 C2310C  JNZ    UO              ; BR IF NOT
5429 0AC7 214700  LXI    H,H11PT3       ;POINTER TO DEVICE STRUCTURE FOR PARALLEL
5430 0ACA C37F0C  JMP    PPO
5431
5432          ;
5433          ; DIABLO ETX/ACK PROTOCOL DRIVER
5434          ;
5435
5436 0ACD CDE40B  DBD:   CALL   DBDOS
5437 0AD0 B7      ORA    A
5438 0AD1 CACD0A  JZ     DBD
5439 0AD4 CD310C  CALL   UO              ;SEND CHARACTER IN C TO PRINTER
5440
5441 0AD7 21ED0A  LXI    H,HSCNT        ;UPDATE HANDSHAKE COUNT
5442 0ADA 35      DCR    M
5443 0ADB FE1B  CPI    01BH          ;ESC?
5444 0ADD 7E      MOV    A,M
5445 0ADE C2E70A  JNZ    DBD1          ;WAS NOT AN ESCAPE
5446 0AE1 FE02  CPI    2              ;LAST CHAR WAS ESCAPE,
5447 0AE3 D0      RNC                ; MAKE CERTAIN AT LEAST TWO CHARS FOLLOW
5448 0AE4 3602  MVI    M,2           ; WITHOUT INTERVENING ETX
5449 0AE6 C9      RET
5450 0AE7 B7      DBD1:  ORA    A          ;TIME TO HANDSHAKE?
5451 0AE8 C0      RNZ
5452 0AE9 3E01  MVI    A,1           ;TELL DBDOS IT IS TIME TO HANDSHAKE
5453 0AEB 12      STAX   D
5454 0AEC C9      RET
5455
5456 0AED 20      HSCNT: DB    32
5457
5458          ;
5459          ; MDIN = MODEM INPUT ROUTINE
5460          ;
5461
5462 0AEE 214100  MDIN:  LXI    H,H84PT4
5463 0AF1 3A3700  LDA    MODE2           ;CHECK FOR H89-11

```

```

5464 0AF4 E601 ANI MODE2B0
5465 0AF6 C21E0C JNZ DMYIN ; BR IF H89-11
5466 0AF9 C3520C JMP UI
5467
5468 ;
5469 ; MDSTAT - MODEM INPUT STATUS
5470 ;
5471 ;
5472 0AFC 214100 MDSTAT: LXI H,H84PT4
5473 0AFF 3A3700 LDA MODE2 ;CHECK FOR H89-11
5474 0B02 E601 ANI MODE2B0
5475 0B04 C21C0C JNZ BUSY ; BR IF H89-11
5476 0B07 C3210C JMP US
5477
5478 ;
5479 ; MDOUT - MODEM OUTPUT
5480 ;
5481 ;
5482 0B0A 3A3700 MDOUT: LDA MODE2 ;CHECK FOR H89-11
5483 0B0D E601 ANI MODE2B0
5484 0B0F C2200C JNZ DMYOUT ; BR IF H89-11
5485 0B12 CD1C0B MDOUT1: CALL MDOS
5486 0B15 B7 ORA A
5487 0B16 CA120B JZ MDOUT1
5488 0B19 C3310C JMP UO
5489
5490 ;
5491 ; MDOS, TTYOS, AND CRTOS - MODEM, TTY, AND CRT OUTPUT STATUS
5492 ; RETURNS 00 FOR BUSY
5493 ; FF FOR READY TO ACCEPT ANOTHER CHARACTER
5494 ;
5495 0B1C 214100 MDOS: LXI H,H84PT4
5496 0B1F 11050D LXI D,MDCTS
5497 0B22 C3490B JMP CRTOS1
5498
5499 0B25 213B00 TTYOS: LXI H,H84PT2
5500 0B28 11020D LXI D,TTYCTS
5501 0B2B 3A3700 LDA MODE2 ;CHECK FOR H89-11
5502 0B2E E601 ANI MODE2B0
5503 0B30 CA490B JZ CRTOS1 ; BR IF NOT
5504 0B33 214400 LXI H,H11PT2
5505 0B36 CD680C CALL EPOS
5506 0B39 C34C0B JMP CRTOS1A
5507
5508 0B3C 213800 CRTOS: LXI H,H84PT1
5509 0B3F 11030D LXI D,CRTCTS
5510
5511 0B42 3A3600 LDA MODE ;HANDLE H8-5 CASE SPECIALLY
5512 0B45 1F RAR
5513 0B46 DA610B JC CRTOS3
5514
5515 0B49 CD290C CRTOS1: CALL UOS ;CHECK TO SEE IF THE UART CAN TAKE A CHAR
5516 CRTOS1A:
5517 0B4C CA5F0B JZ CRTOSB ; THEN RETURN FLAGGING BUSY
5518
5519 0B4F 1A LDAX D ;SEE IF THERE ARE ANY NULLS TO BE SENT

```

```

5520 0B50 B7          ORA   A
5521 0B51 C2560B     JNZ   CRT0S2      ;IF SO, GO SEND ONE
5522
5523 0B54 3D          DCR   A          ;ELSE, SET READY
5524 0B55 C9          RET
5525
5526 0B56 3D          CRT0S2: DCR   A          ;COUNT THIS NULL AS SENT
5527 0B57 12          STAX  D
5528 0B58 C5          PUSH B
5529
5530 0B59 0E00        MVI   C, NULL    ;SEND A NULL
5531 0B5B CD310C     CALL  00
5532
5533 0B5E C1          POP   B
5534
5535 0B5F AF          CRT0S8: XRA   A          ;RETURN CLAIMING TO BE STILL BUSY
5536 0B60 C9          RET
5537
5538 0B61 DBFB        CRT0S3: IN    H85CRT+1  ;SPECIAL CASE: H8-5 SERIAL CARD
5539 0B63 1F          RAR
5540 0B64 D25F0B     JNC   CRT0S8      ;STILL BUSY
5541
5542 0B67 1A          LDAX  D          ;ANY NULLS STILL TO SEND?
5543 0B68 B7          ORA   A
5544 0B69 C26E0B     JNZ   CRT0S4      ;IF SO, GO SEND ONE
5545
5546 0B6C 3D          DCR   A          ;RETURN READY
5547 0B6D C9          RET
5548
5549 0B6E 3D          CRT0S4: DCR   A          ;COUNT THIS NULL AS SENT
5550 0B6F 12          STAX  D
5551
5552 0B70 3E00        MVI   A, NULL    ;SEND A NULL
5553 0B72 D3FA        OUT   H85CRT
5554
5555 0B74 AF          XRA   A          ;RETURN BUSY
5556 0B75 C9          RET
5557
5558
5559 ;
5560 ; LPT0S - LINE PRINTER OUTPUT STATUS
5561 ; WITH HARDWARE HANDSHAKE
5562 ;
5563 0B76 11040D     LPT0S: LXI   D, LPT0S
5564
5565 0B79 3A3700     LDA   MODE2      ;CHECK FOR H89-11 PARALLEL PRINTER
5566 0B7C E603       ANI   MODE2B1+MODE2B0
5567 0B7E FE03       CPI   MODE2B1+MODE2B0
5568 0B80 C29E0B     JNZ   LPT0S3
5569 0B83 214700     LXI   H, H11PT3 ;POINTER TO PARALLEL PRINTER STRUCTURE
5570 0B86 3E02       MVI   A, PPDATC ;GET PRINTER STATUS
5571 0B88 CD590C     CALL  PINX
5572 0B8B 47         MOV   B, A      ;SAVE IT
5573 0B8C 3A3700     LDA   MODE2      ;GET PRINTER READY POLARITY
5574 0B8F E604       ANI   MODE2B2
5575 0B91 78         MOV   A, B      ;RESTORE STATUS

```

```

5576 0B92 C2960B      JNZ   LPT0S5      ;BR IF PRINTER READY STATUS IS ACTIVE HIGH
5577 0B95 2F          CMA          ; INVERT PRINTER STATUS IF NOT
5578 0B96 E680        LPT0S5: ANI   PPRDY      ;TEST FOR PRINTER READY
5579 0B98 CAE20B      JZ     LPT0SB      ; BR IF PRINTER NOT READY
5580 0B9B C3BF0B      JMP    LPT0S2      ; BR IF PRINTER READY
5581
5582 0B9E 213E00      LPT0S3: LXI   H,H84PT3
5583 0BA1 CD290C      CALL  UOS          ;CHECK TO SEE IF THE UART CAN TAKE A CHAR
5584 0BA4 CAE20B      JZ     LPT0SB      ;THE UART IS STILL BUSY
5585
5586 ;                ; HANDSHAKE USED FOR H14/WH24
5587 ;                ; IF YOUR PRINTER DOES NOT USE HANDSHAKE TO INDICATE "BUSY"
5588
5589 0BA7 3E06          MVI   A,6          ;INPUT MODEM STATUS REG
5590 0BA9 CD590C      CALL  PINX
5591 0BAC 47           MOV   B,A
5592 0BAD 3A3600      LDA   MODE         ;CHECK FOR POLARITY OF READY SIGNAL
5593 0BB0 E604        ANI   MODEB2
5594 0BB2 C2B80B      JNZ   LPT0S0      ; BR IF READY IS HIGH POLARITY
5595 0BB5 78          MOV   A,B          ;READY IS INDICATED BY LOW POLARITY
5596 0BB6 2F          CMA          ; THEREFORE, COMPLEMENT STATUS
5597 0BB7 47           MOV   B,A          ; BEFORE CHECKING
5598 0BB8 3A3500      LPT0S0: LDA   PRTRDY   ;GET LPT PRINTER READY MASK
5599 0BBB A0          ANA   B            ;CHECK APPROPRIATE READY LINE
5600 0BBC CAE20B      JZ     LPT0SB      ; BR IF NOT READY
5601
5602 0BBF 1A          LPT0S2: LDAX  D            ;ANY NULLS TO SEND?
5603 0BC0 B7          ORA   A
5604 0BC1 C2C90B      JNZ   LPT0S1      ;YES, THERE ARE NULLS REQUIRED
5605
5606 0BC4 3D          DCR   A            ;NO, RETURN WITH A = OFFH INDICATING READY
5607 0BC5 32010D      STA  DCLPOS       ;FLAG DON'T CHECK LP STATUS
5608 0BC8 C9          RET
5609
5610 0BC9 3D          LPT0S1: DCR   A            ;COUNT THIS NULL AS SENT
5611 0BCA 12          STAX D
5612
5613 0BCB C5          PUSH B            ;SAVE THE ORIGINAL CHARACTER
5614
5615 0BCC 0E00        MVI   C,NULL
5616 0BCE 3A3700      LDA   MODE2       ;CHECK FOR HS9-11 PARALLEL PRINTER
5617 0BD1 E603        ANI   MODE2B1+MODE2B0
5618 0BD3 FE03        CPI   MODE2B1+MODE2B0
5619 0BD5 C2DE0B      JNZ   LPT0S4      ; BR IF NOT
5620 0BD8 CD7F0C      CALL  PPO
5621 0BDB C3E10B      JMP   LPT0S4A
5622
5623 0BDE CD310C      LPT0S4: CALL  UO
5624
5625 ;                ; LPT0S4A:
5626 0BE1 C1          POP   B
5627
5628 0BE2 AF          LPT0SB: XRA  A            ;INDICATE BUSY
5629 0BE3 C9          RET
5630
5631 ;

```

```

5632 ; DBDOS - DIABLO OUTPUT STATUS
5633 ; IF CTS == 0 THEN OKAY TO SEND CHARACTERS
5634 ; CTS == 1 THEN SEND ETX, SET CTS TO 2
5635 ; CTS == 2 THEN WAIT FOR ACK, THEN SET CTS TO 0
5636
5637 OBE4 213E00 DBDOS: LXI H,H84PT3
5638 OBE7 11060D LXI D,DBDCTS
5639
5640 OBEA 1A LDAX D ;FIND OUT THE STATE OF OUTPUT
5641 OBEB FE02 CPI 2 ;IF NOT 2,
5642 OBED C2060C JNZ DBDOS1 ; THEN GO DO OUTPUT
5643
5644 ; MUST RECEIVE AN ACK FROM THE PRINTER
5645
5646 OBF0 CD210C CALL US ;CHECK UART FOR INCOMING
5647 OBF3 CA1C0C JZ DBDOSB ;NO CHARACTER BACK FROM PRINTER YET
5648 ; SO FLAG BUSY
5649 OBF6 CD580C CALL UII ;GET THE CHARACTER
5650 OBF9 E67F ANI 07FH ;STRIP OFF PARITY
5651 OBFB D606 SUI 'F' MOD 32 ;COMPARE IT TO ACK
5652 Obfd C21C0C JNZ DBDOSB ;NOT AN ACK, SO STILL BUSY
5653 OC00 12 STAX D ;WAS AN ACK, SO ABLE TO SEND MORE CHARS
5654
5655 OC01 3E20 MVI A,32 ;RESET THE HANDSHAKE COUNT
5656 OC03 32ED0A STA HSCNT
5657
5658 OC06 CD290C DBDOS1: CALL UOS ;CHECK TO SEE IF UART CAN TAKE A CHAR
5659 OC09 CA1C0C JZ DBDOSB ;UART IS NOT READY TO ACCEPT A CHARACTER
5660
5661 OC0C 1A LDAX D ;IS IT TIME TO SEND ETX?
5662 OC0D B7 ORA A
5663 OC0E C2130C JNZ DBDOS2 ;YES, GO SEND ETX
5664
5665 OC11 3D DCR A ;NO, INDICATE READY (A == 0FFH)
5666 OC12 C9 RET
5667
5668 OC13 3C DBDOS2: INR A ;FLAG THAT THE NEXT THING TO DO IS WAIT FOR ACK
5669 OC14 12 STAX D
5670
5671 OC15 C5 PUSH B
5672
5673 OC16 0E03 MVI C,'C' MOD 32 ;SEND THE ETX
5674 OC18 CD310C CALL UO
5675
5676 OC1B C1 POP B
5677
5678 BUSY:
5679 OC1C AF DBDOSB: XRA A
5680 OC1D C9 RET
5681
5682 ;
5683 ; DUMMY INPUT AND OUTPUT ROUTINES
5684 ;
5685
5686 OC1E 3E1A DMYIN: MVI A,'Z'-40H ;UNIMPLEMENTED INPUTS RETURN CTL-Z
5687 OC20 C9 DMYOUT: RET ;DUMMY OUTPUTS DO NOTHING

```

5688
5689
5690

PAGE

```

5691
5692 ;
5693 ; 8250 I/O ROUTINES
5694 ;
5695 ;
5696 ; U$ - GET UART (INPUT) STATUS
5697 ;
5698 0C21 3E05 US: MVI A,5 ;OFFSET TO THE STATUS REGISTER
5699 0C23 CD590C CALL PINX
5700 0C26 E601 ANI 1 ;MASK THE DATA AVAILABLE BIT
5701 0C28 C9 RET
5702 ;
5703 ; UOS - GET UART (OUTPUT) STATUS
5704 ;
5705 0C29 3E05 UOS: MVI A,5 ;OFFSET TO STATUS REG
5706 0C2B CD590C CALL PINX
5707 0C2E E620 ANI 20H
5708 0C30 C9 RET
5709 ;
5710 ; UO - OUTPUT TO UART
5711 ;
5712 0C31 7E UO: MOV A,M
5713 ; JMP POUT
5714 ;
5715 ;
5716 ; POUT - OUTPUT BYTE IN C TO PORT IN A
5717 ;
5718 ;
5719 0C32 32400C POUT: STA POUT1+1
5720 0C35 E5 PUSH H
5721 0C36 23 INX H
5722 0C37 23 INX H ;POINT TO FLAG BYTE
5723 0C38 7E MOV A,M
5724 0C39 17 RAL
5725 0C3A E1 POP H
5726 0C3B 79 MOV A,C
5727 0C3C DC920C CC MUC ;MAP TO UPPER CASE
5728 0C3F D300 POUT1: DUT 00H ;SELF-MODIFYING CODE
5729 0C41 FE0D POUT2: CPI PADCH ;CHECK IF THIS CHAR NEEDS PADDING (USUALLY CR)
5730 0C43 C0 RNZ ;NO
5731 ;
5732 0C44 E5 PUSH H ;FIND OUT NUMBER OF NULLS REQUIRED
5733 0C45 23 INX H
5734 0C46 23 INX H
5735 0C47 7E MOV A,M ;GET COUNT FROM DATA STRUCTURE
5736 0C48 E1 POP H
5737 0C49 1F RAR ;SHIFT INTO LEAST SIG 3 BITS
5738 0C4A 1F RAR
5739 0C4B 1F RAR
5740 0C4C 1F RAR
5741 0C4D E607 ANI 07H ;MASK ONLY COUNT
5742 0C4F C8 RZ ;RETURN IF NO NULLS ARE REQUIRED
5743 0C50 12 STAX D ;SAVE COUNT OF NULLS TO SEND IN XXXCTS
5744 ;
5745 0C51 C9 RET
5746 ;

```

```
5747
5748 ; UI - INPUT FROM UART
5749
5750 0C52 CD210C UI: CALL US
5751 0C55 CA520C JZ UI
5752 0C58 AF UI1: XRA A
5753 ; JMP PINX
5754
5755 ;
5756 ; PIN - INPUT BYTE FROM PORT IN A
5757 ;
5758
5759 0C59 86 PINX: ADD M
5760 0C5A 325E0C PIN: STA PINI+1
5761 0C5D DB00 PIN1: IN 00H ;SELF-MODIFYING CODE
5762 0C5F C9 RET
5763
5764
5765
5766
5767
5768 ;
5769 ; 2661-3 I/O ROUTINES
5770 ;
5771
5772 ; EPS - GET INPUT STATUS
5773
5774 0C60 3E01 EPS: MVI A,EPSTAT
5775 0C62 CD590C CALL PINX
5776 0C65 E602 ANI EPRXR
5777 0C67 C9 RET
5778
5779 ; EPOS - GET OUTPUT STATUS
5780
5781 0C68 3E01 EPOS: MVI A,EPSTAT
5782 0C6A CD590C CALL PINX
5783 0C6D E601 ANI EPTXR
5784 0C6F C9 RET
5785
5786 ; EPI - INPUT DATA
5787
5788 0C70 CD600C EPI: CALL EPS
5789 0C73 CA700C JZ EPI
5790 0C76 3E00 EPI1: MVI A,EPDATA
5791 0C78 C3590C JMP PINX
5792
5793 ; EPO - OUTPUT DATA
5794
5795 0C7B 7E EPO: MOV A,M
5796 IF EPDATA
5797 %: EPDATA NE 0
5798 ENDIF
5799 0C7C C3320C JMP POUT
5800
5801
5802
```



```
5803
5804
5805 ; 8255 I/O ROUTINES
5806 ;
5807
5808 ; PPO - OUTPUT DATA
5809
5810 0C7F 7E PPO: MOV A,M
5811 IF Ppdata
5812 %: Ppdata NE 0
5813 ENDIF
5814 0C80 CD320C CALL POUT
5815 0C83 7E MOV A,M
5816 0C84 C&03 ADI PPCTL
5817 0C86 32900C STA PPO1A
5818 0C89 AF XRA A
5819 IF PPDS-00000001B
5820 %: PPDS NE 00000001B
5821 ENDIF
5822 0C8A CD8FOC CALL PPO1
5823 0C8D 3E01 MVI A,PPDS
5824 0C8F D300 PPO1: OUT 0
5825 0C90 = PPO1A EQU $-1
5826 0C91 C9 RET
5827
5828
5829
5830
5831
5832 ;
5833 ; MUC - MAP CHARACTER IN A TO UPPER CASE
5834 ;
5835
5836 0C92 FE61 MUC: CPI "a" ;IF LESS THAN LOWER CASE 'A'
5837 0C94 D8 RC ; THEN ALREADY UPPER CASE
5838 0C95 FE7B CPI "z"+1 ;IF GREATER THAN LOWER CASE 'Z'
5839 0C97 D0 RNC ; THEN NOT A LOWER CASE LETTER
5840 0C98 D&20 SUI "a"-A ; CONVERT TO UPPER CASE
5841 0C9A C9 RET
5842
5843
5844 PAGE
```

```
5845
5846      ; PMSG - PRINT THE MESSAGE AT HL UNTIL NULL
5847      ;
5848
5849 0C9B 7E      PMSG:  MOV    A,M      ;GET A CHAR
5850 0C9C B7      ORA    A        ;CHECK FOR NULL
5851 0C9D C8      RZ
5852 0C9E 4F      MOV    C,A      ; ELSE
5853 0C9F E5      PUSH   H        ;SAVE THE POINTER
5854 0CA0 CD1409  CALL   CONOUT   ; PRINT THIS CHARACTER
5855 0CA3 E1      POP    H
5856 0CA4 23      INX    H        ; POINT TO NEXT
5857 0CA5 C39B0C  JMP    PMSG     ;REPEAT
5858
5859      ;
5860      ; HOUT - HEX OUTPUT ROUTINE
5861      ;
5862      ; TYPE CONTENTS OF A IN HEX ON CONSOLE
5863 0CA8 F5      HOUT:  PUSH   PSW      ;SAVE CONTENTS OF A
5864 0CA9 0F      RRC
5865 0CAA 0F      RRC
5866 0CAB 0F      RRC
5867 0CAC 0F      RRC
5868 0CAD CDB10C  CALL   NIBBLE   ;PUT OUT HIGH ORDER NIBBLE
5869 0CB0 F1      POP    PSW     ;FALL THROUGH TO PUT OUT LOW NIBBLE
5870 0CB1 E60F    NIBBLE: ANI    0FH   ;MASK
5871 0CB3 FE0A    CPI    10      ;> 10 ?
5872 0CB5 FABA0C  JM     NIBBLI   ;IF 0-9
5873 0CB8 C607    ADI    7        ; ELSE CONVERT TO A-F
5874 0CBA C630    NIBBLI: ADI    30H   ;BINARY TO ASCII
5875 0CBC 4F      MOV    C,A      ;TYPE IT ON THE CONSOLE
5876 0CBD C31409  JMP    CONOUT
5877
5878      PAGE
```

5879

5880

; BIOS MESSAGES

5881

;

5882

OCC0 OD0A

BTMSG:

DB

CR,LF

5883

OCC2 4552524F52

DB

'ERROR DURING WARM BOOT - PRESS ANY KEY',0

5884

OCE9 2052454144RDMSG:

DB

'READ',0

5885

OCEF 2057524954WRMSG:

DB

'WRITE',0

5886

OCF6 204552524FERRMSG:

DB

'ERROR',0

5887

OCFE OD0A00

CRLF:

DB

CR,LF,0

5888

5889

OD01 00

DCLPOS:

DB

0

;FORCE A CHECK OF LP OUTPUT STATUS

5890

OD02 00

TTYCTS:

DB

0

;CHARACTERS TO SEND COUNT FOR

TTY

5891

OD03 00

CRTCTS:

DB

0

;

CRT

5892

OD04 00

LPTCTS:

DB

0

;

LPT

5893

OD05 00

MDCTS:

DB

0

;

MODEM

5894

OD06 00

DBDCTS:

DB

0

;OUTPUT STATE MACHINE FOR

DBD

5895

5896

IF

INTINP

5897

OD07 00

CRTB:

DB

0

;NUMBER OF CHARACTERS IN THE CRT BUFFER

5898

OD08 BA10

CRTGET:

DW

CRTBUF

;POINTER TO NEXT CHAR TO BE TAKEN

5899

OD0A BA10

CRTPUT:

DW

CRTBUF

;POINTER TO NEXT POSITION TO STORE CHAR

5900

ENDIF

5901

5902

5903

PAGE

```
5904
5905          IF      H17T
5906 ODOC 1400      DPB17S: DW      20          ;SEC PER TRACK
5907 ODOE 03      DB       3
5908 ODOF 07      DB       7
5909 OD10 00      DB       0
5910 OD11 5B00      DW      91          ;DISK SIZE (IN K) - 1
5911 OD13 3F00      DW      63
5912 OD15 C0      DB      192
5913 OD16 00      DB       0
5914 OD17 1000      DW      16
5915 OD19 0300      DW       3
5916          ENDIF
5917
5918          IF      H47T OR H67T
5919          DPBOSS: DW      26          ;SECTORS PER TRACK
5920          DB      3,7,0          ;BLOCK SHIFT, BLOCK MASK, EXTENT MASK
5921          DW      242          ;DISK SIZE - 1
5922          DW      63          ;DIR MAX
5923          DB      192,0        ;ALLOCO,ALLOCI
5924          DW      16          ;CHECK SIZE
5925          DW      2          ;OFFSET
5926          DPBOSD: DW      26          ;SECTORS PER TRACK
5927          DB      4,15,1       ;BLOCK SHIFT, MASK, EXTENT MASK
5928          DW      246          ;DISK SIZE - 1
5929          DW      127          ;DIR MAX
5930          DB      0C0H,000H    ;ALLOCATION
5931          DW      32
5932          DW      2
5933
5934          DPBODS: DW      52
5935          DB      4,15,0
5936          DW      242
5937          DW      127
5938          DB      0C0H,000H
5939          DW      32
5940          DW      2
5941
5942          DPBODD: DW      52
5943          DB      4,15,0
5944          DW      493
5945          DW      255
5946          DB      0F0H,000H
5947          DW      64
5948          DW      2
5949          ENDIF
5950
5951          IF      H47T AND H47ED
5952          DPBOES: DW      64
5953          DB      4,15,0
5954          DW      299
5955          DW      127
5956          DB      0C0H,000H
5957          DW      32
5958          DW      2
5959
```



```
5970
5971          IF      H17T
5972  OD1B 0102090A11XLT17: DB    1,2,9,10,17,18
5973  OD21 050&0D0E      DB    5,8,13,14
5974  OD25 03040B0C13   DB    3,4,11,12,19,20
5975  OD2E 07080F10     DB    7,8,15,16
5976          ENDIF
5977
5978          IF      H47T OR H67T
5979          XLT0S: DB    1,7,13,19,25
5980          DB    5,11,17,23
5981          DB    3,9,15,21
5982          DB    2,8,14,20,26
5983          DB    6,12,18,24
5984          DB    4,10,16,22
5985
5986          XLT0D: DB    1,2,19,20,37,38
5987          DB    3,4,21,22,39,40
5988          DB    5,6,23,24,41,42
5989          DB    7,8,25,26,43,44
5990          DB    9,10,27,28,45,46
5991          DB    11,12,29,30,47,48
5992          DB    13,14,31,32,49,50
5993          DB    15,16,33,34,51,52
5994          DB    17,18,35,36
5995          ENDIF
5996
5997          PAGE
```

```

5998
5999 ;
6000 ; HOST BUFFER FLAGS THAT MUST BE INITIALIZED AT ASSEMBLY TIME.
6001 ;
6002
6003 0D2F 00 HSTACT DB 0 ;HOST BUFFER ACTIVE FLAG
6004 0D30 00 HSTWRT DB 0 ;HOST BUFFER PENDING WRITE FLAG
6005 0D31 00 UNACNT DB 0 ;UNALLOCATED RECORD COUNT
6006
6007
6008
6009
6010 ;
6011 0D32 = HSTBUF EQU %
6012
6013 ;
6014 ; THE FOLLOWING "ONE-TIME" CODE GETS OVERLAID BY DISK BUFFERS
6015 ; AND POSSIBLY RUN-TIME VARIABLES.
6016 ;
6017 ;
6018 ;
6019 ; BOOT IS EXECUTED FOR COLD START
6020 ;
6021 0D32 F3 CBOOT: DI
6022 0D33 311211 LXI SP,STACK
6023
6024 0D36 3A3400 LDA DEFIOB ;SET THE DEFAULT IOBYTE
6025 0D39 320300 STA IOBYTE
6026
6027 0D3C 3EC3 MVI A,M;#JMP
6028 0D3E 212E08 LXI H,CLOCK ;ESTABLISH POINTER TO CLOCK INT SERVICE ROUTINE
6029 0D41 320800 STA CLKVEC
6030 0D44 220900 SHLD CLKVEC+1
6031
6032 IF INTINP
6033 0D47 21B509 LXI H;CRTISR ;POINTER TO CRT INTERRUPT SERVICE ROUTINE
6034 0D4A 321800 STA SERVEC ;AT SERIAL VECTOR
6035 0D4D 221900 SHLD SERVEC+1
6036 ENDF
6037
6038 0D50 210D00 LXI H,CTLPRT ;GET THE CURRENT VALUE OF THE RAM AT 0 PORT
6039 0D53 7E MOV A,M ; ESTABLISHED BY BLDR
6040 0D54 D3F2 OUT H88CTL ;RESET THE CLOCK ON THE H/Z89
6041
6042 0D56 23 INX H ;POINT TO H8FLAG
6043 0D57 7E MOV A,M
6044 0D58 B7 ORA A ;IF 0 THEN RUNNING ON H/Z89
6045 0D59 CA5E0D JZ CBT0 ; THEN DON'T OUTPUT TO 3600
6046 0D5C D3F0 OUT H8CTL ; ELSE CONTAINS H8TR TO RESET H8 CLOCK
6047
6048 ; INITIALIZE 8251 (ONLY IF USED)
6049 ;
6050 0D5E 3A3600 CBT0: LDA MODE ;FIRST, ASSUME IT IS NOT USED
6051 0D61 E6FE ANI OFFH-MODEBO
6052 0D63 323600 STA MODE
6053

```

```

6054 0D66 3A0E00 LDA H8FLAG ;IF ON Z/H89
6055 0D69 B7 ORA A ; THEN THE CONSOLE IS NOT AN H8-5
6056 0D6A CA9D0D JZ CBT1 ;CONSOLE ON H8-4 CARD
6057
6058 0D6D 213800 LXI H,H84PT1 ;POINT TO CRT PORT
6059 0D70 7E MOV A,M ;GET BASE PORT NUMBER
6060 0D71 C603 ADI 3 ;SEE IF YOU CAN GET A RESPONSE FROM 8250 @ 3500
6061 0D73 323610 STA OUTH84+1
6062 0D76 F5 PUSH PSW
6063 0D77 3E03 MVI A,3 ;SET 'S' BIT WORDS
6064 0D79 CD3510 CALL OUTH84
6065 0D7C F1 POP PSW
6066 0D7D CD5A0C CALL PIN
6067 0D80 FE03 CPI 3
6068 0D82 CA9D0D JZ CBT1 ;CONSOLE ON H8-4 CARD
6069 0D85 3A3600 LDA MODE
6070 0D88 F601 ORI MODEBO ;CONSOLE MUST BE ON H8-5 CARD THEN
6071 0D8A 323600 STA MODE ;SO SET MODE
6072
6073 0D8D 3E15 MVI A,15H ;DUMMY MODE BYTE
6074 0D8F D3FB OUT H85CRT+1
6075
6076 0D91 3E40 MVI A,40H ;RESET 8251
6077 0D93 D3FB OUT H85CRT+1
6078
6079 0D95 3E4E MVI A,4EH ;S BIT WORDS, I STOP BIT, NO PARITY
6080 0D97 D3FB OUT H85CRT+1
6081
6082 IF INTINP
6083 0D99 3E17 MVI A,17H ;ENABLE TX AND RX WITH INTERRUPTS ON
6084 ELSE
6085 MVI A,15H ;ENABLE TX AND RX WITH INTERRUPTS OFF
6086 ENDIF
6087 0D9B D3FB OUT H85CRT+1
6088
6089 ;
6090 ; NOW INITIALIZE THE PORTS
6091 ;
6092 0D9D 2A3900 CBT1: LHL CRTBAUD ;PICK UP BAUD RATE
6093 0DA0 3A3800 LDA H84PT1 ; AND THE PORT NUMBER
6094 0DA3 CDF50F CALL IN8250 ;INITIALIZE THIS UART
6095
6096 IF INTINP
6097 0DA6 3A3800 LDA H84PT1 ;ENABLE 8250 RECEIVER INTERRUPTS
6098 0DA9 3C INR A
6099 0DAA 323610 STA OUTH84+1
6100 0DAD 3E01 MVI A,1
6101 0DAF CD3510 CALL OUTH84
6102 ENDIF
6103
6104 ; DETERMINE IF H89-11 BOARD IS IN SYSTEM
6105
6106 0DB2 3A4400 LDA H11PT2 ;GET BASE PORT OF H89-11 TTY PORT
6107 0DB5 47 MOV B,A ;SAVE IT
6108 0DB6 C603 ADI EPCMD ;TRY SETTING COMMAND PORT
6109 0DB8 323610 STA OUTH84+1

```



```

6110  ODBB 3E02      MVI  A,EPDTR
6111  ODBD CD3510   CALL  OUTH84
6112  ODC0 214400   LXI  H,H11PT2      ;SEE IF COMMAND PORT EXISTS
6113  ODC3 3E03      MVI  A,EPDTR
6114  ODC5 CD590C   CALL  PINX
6115  ODC8 FE02      CPI   EPDTR
6116  ODCA C2080E   JNZ  H893          ; BR IF NOT
6117  ODCC AF        XRA  A              ;ZERO COMMAND PORT
6118  ODCE CD3510   CALL  OUTH84
6119
6120  ODD1 3E04      MVI  A,4           ;CHECK TTY PORT FOR 8250
6121  ODD3 80        ADD  B
6122  ODD4 323610   STA  OUTH84+1
6123  ODD7 3E10      MVI  A,010H
6124  ODD9 CD3510   CALL  OUTH84
6125  ODDC 3E04      MVI  A,4
6126  ODDE CD590C   CALL  PINX
6127  ODE1 FE10      CPI   010H
6128  ODE3 CA080E   JZ   H893          ; BR IF 8250, THIS IS NOT H89-11 BOARD
6129
6130  ODE6 213700   LXI  H,MODE2      ;INDICATE H89-11 BOARD IS IN SYSTEM
6131  ODE9 7E        MOV  A,M
6132  ODEA F601     ORI  MODE2B0
6133  ODEC 77        MOV  M,A
6134  ODED 2A4500   LHLD TTY11B       ;INIT TTY PORT
6135  ODF0 3A4400   LDA  H11PT2
6136  ODF3 CD3810   CALL  IN2661
6137  ODF6 2A3F00   LHLD LPTBAUD     ;INIT SERIAL PRINTER PORT
6138  ODF9 3A3E00   LDA  H84PT3
6139  ODFC CDF50F   CALL  IN8250
6140  ODFF 3A4700   LDA  H11PT3      ;INIT PARALLEL PRINTER PORT
6141  OE02 CD7910   CALL  IN8255
6142  OE05 C32A0E   JMP  CBT1A
6143
6144  OE08 213700   H893: LXI  H,MODE2      ;INDICATE H89-11 BOARD IS NOT IN SYSTEM
6145  OE0B 7E        MOV  A,M
6146  OE0C E6FE     ANI  OFFH-MODE2B0
6147  OE0E 77        MOV  M,A
6148  OE0F 2A3C00   LHLD TTYBAUD     ;INIT TTY PORT
6149  OE12 3A3B00   LDA  H84PT2
6150  OE15 CDF50F   CALL  IN8250
6151  OE18 2A3F00   LHLD LPTBAUD     ;INIT PRINTER PORT
6152  OE1B 3A3E00   LDA  H84PT3
6153  OE1E CDF50F   CALL  IN8250
6154  OE21 2A4200   LHLD RDPBAUD     ;INIT MODEM PORT
6155  OE24 3A4100   LDA  H84PT4
6156  OE27 CDF50F   CALL  IN8250
6157
6158          ; PRINT SIGNON MESSAGE.
6159
6160  OE2A 218FOE   CBT1A: LXI  H,MSG0      ;PRINT THE SIGNON MESSAGE
6161  OE2D CD9B0C   CALL  PMSG
6162  OE30 3E12     MVI  A,(BIOSEND+255)/256 ;FINE OUT NEWLY RELOCATED SIZE
6163  OE32 1F       RAR          ;GET THE VALUE IN K BY DIVIDING BY 4
6164  OE33 1F       RAR          ; (DONE AT RUN TIME FOR RELOCATION)
6165  OE34 E63F     ANI  03FH

```

```

6166 0E36 C23B0E      JNZ   CBOOT1      ;IF THE TOP OF MEMORY IS NOT 0000H
6167 0E39 3E40        MVI   A,64        ; ELSE TAKE CARE OF THE 64K CASE
6168 0E3B CDD90F      CBOOT1: CALL  TYDN  ;TYPE A 2 DIGIT DECIMAL NUMBER
6169 0E3E 21930E      LXI   H,SMSG1
6170 0E41 CD9B0C      CALL  PMSG
6171
6172 0E44 FB          EI              ;ALLOW INTERRUPTS NOW
6173
6174                ;
6175                ; DO INITIALIZATION FOR BOOT DEVICE.
6176                ;
6177
6178 0E45 3A4900      LDA   BBDA        ;GET BOOT DEVICE BASE PORT #
6179 0E48 32DB0E      STA   CBIB
6180
6181 0E4B 21630E      LXI   H,CBII      ;SET RETURN ADDR
6182 0E4E E5          PUSH  H
6183
6184 0E4F 3A0400      LDA   LOGDSK      ;GET BOOT UNIT #
6185 0E52 4F          MOV   C,A
6186
6187 0E53 3A4800      LDA   BBDF        ;GET BOOT DEVICE FLAGS
6188 0E56 E6E0        ANI   DPETYPE
6189
6190
6191 0E58 FE40        CPI   DPEH17
6192 0E5A CADD0E      JZ    CBH17       ;BR IF H17
6193
6194
6195                IF   H37T
6196                CPI   DPEH37
6197                JZ    CBH37       ;BR IF H37
6198
6199                ENDIF
6200
6201                IF   H47T
6202                CPI   DPEH47
6203                JZ    CBH47       ;BR IF H47
6204
6205                ENDIF
6206
6207                IF   H67T
6208                CPI   DPEH67H
6209                JZ    CBH67       ;BR IF H67
6210
6211                ENDIF
6210 0E5D 0E07        MVI   C,BELL      ;BIOS IS NOT SET UP TO HANDLE
6211 0E5F CD1409      CALL  CONOUT      ; BOOT DEVICE
6212 0E62 76          HLT              ;HALT EVERYTHING
6213
6214                ;
6215                ; DO INITIALIZATION FOR OTHER DISK DEVICE (IF ANY).
6216                ;
6217
6218 0E63 AF          CBI1: XRA   A      ;INDICATE NOT BOOT DEVICE
6219 0E64 32DA0E      STA   CBIA
6220
6221 0E67 3ADB0E      LDA   CBIB        ;SWITCH BASE PORT #

```

```

6222 0E6A EE04      XRI   7CH-78H      ;DRIVE BASE PORT #'S ARE 78H & 7CH
6223 0E6C 32DB0E    STA   CBIB        ; WHICH DIFFER ONLY AT BIT 2
6224
6225 0E6F 21800E    LXI   H,CBI2      ;SET RET ADDR
6226 0E72 E5        PUSH  H
6227
6228 0E73 3A4800    LDA   BBDF        ;GET DEVICE FLAGS OF BOOT DEVICE
6229 0E76 E6E0      ANI   DPETYPE     ;MASK FOR DRIVE TYPE
6230 0E78 0E00      MVI   C,0         ;1ST UNIT IS UNIT 0
6231
6232              IF   H17T
6233 0E7A FE40      CPI   DPEH17      ;BOOT DEVICE H17
6234 0E7C C2DD0E    JNZ   CBH17      ;IF NOT, THEN OTHER DEVICE IS H17
6235              ENDIF
6236
6237              IF   H37T
6238 0E7E FE40      CPI   DPEH37      ;BOOT DEVICE H37
6239 0E80 C2DD0E    JNZ   CBH37      ;IF NOT, THEN OTHER DEVICE IS H37
6240              ENDIF
6241
6242              IF   H47T
6243 0E82 FE40      CPI   DPEH47      ;BOOT DEVICE H47
6244 0E84 C2DD0E    JNZ   CBH47      ;IF NOT, THEN OTHER DEVICE IS H47
6245              ENDIF
6246
6247              IF   H67T
6248 0E86 FE40      CPI   DPEH67H     ;BOOT DEVICE H67
6249 0E88 C2DD0E    JNZ   CBH67      ;IF NOT, THEN OTHER DEVICE IS H67
6250              ENDIF
6251
6252 0E7F E1        POP   H           ;NO OTHER DEVICE, DISCARD RET ADDR
6253
6254              CBI2:
6255              ;
6256              ;
6257              ; FINISH COLD BOOT AND SIGN ON.
6258              ;
6259
6260 0E80 AF        XRA   A           ;MAKE A THE DEFAULT DRIVE
6261 0E81 320400    STA   LOGDSK
6262
6263 0E84 210000    LXI   H,BIOS      ;PLACE ADDRESS OF START OF BIOS
6264 0E87 224E00    SHLD BBIOS       ; IN PAGE ZERO
6265
6266 0E8A 3E00      MVI   A,BT#CD    ;FLAG AS A COLD BOOT
6267 0E8C C32E01    JMP   GDW
6268
6269 0E8F 0D0A0A00  MSG0: DB   CR,LF,LF,0
6270 0E93 4B20484541MSG1: DB   'K HEATH/ZENITH CP/M 2.2'
6271              IF   EXPR
6272              DB   'X'
6273              ELSE
6274 0EAA 2E        DB   '.'
6275              ENDIF
6276 0EAB 303420    DB   VERS/10+'0',(VERS MOD 10)+'0',LEVEL
6277 0EAE 2030392F31 DB   '','','MONTH/10+'0',(MONTH MOD 10)+'0','/','/','DAY/10+'0'

```



```

6326
6327 OEDA 01      CBIA:  DB    1          ;0 = INIT AS OTHER DEVICE
6328                                     ;1 = INIT AS BOOT DEVICE
6329 OEDB          CBIB:  DS    1          ;BASE PORT #
6330 OEDC 00      CBIC:  DB    0          ;LOGICAL DRIVE #
6331
6332                                     IF    H17T
6333 ;
6334 ;   COLD BOOT INIT ROUTINE FOR H17.
6335 ;
6336
6337 OEDD 3ADB0E   CBH17: LDA    CBIB          ;CHECK IF VALID BASE PORT #
6338 OEE0 FE7C     CPI    7CH
6339 OEE2 C0       RNZ          ;ONLY 7CH ALLOWED
6340
6341 OEE3 0603     MVI    B,H17ND
6342 OEE5 1600     MVI    D,(DPE0-DPBASE)/DPBL
6343 OEE7 CD2D0F   CALL   CBTFIL          ;FILL IN DRIVE MAP TABLE
6344
6345 OEEA 3E10     MVI    A,DFMO          ;INIT H17 CONTROL REG IMAGE
6346 OEEC 320F00  STA    DEVCTL
6347
6348 OEEF 3ADA0E   LDA    CBIA          ;CHECK IF BOOT DEVICE
6349 OEF2 A7       ANA    A
6350 OEF3 CC2D06  CZ    RESH17          ;IF NOT, THEN RESET DEVICE
6351
6352 ;   INSURE THE HEAD ON ALL DRIVES IS NOT BEFORE TRACK 0
6353 ;
6354 OEF6 0603     MVI    B,H17ND          ;# DRIVES
6355 OEF8 3E0A     MVI    A,10          ;SET TO SEEK TO TRACK 10
6356 OEFA 329810  STA    TRACK
6357 OEFD 216200  LXI    H,DPE0+DPEH+H   ;GET ADDR FOR HSTDPB
6358
6359 CBH171:
6360 OF00 C5      PUSH   B
6361 OF01 228E10  SHLD  HSTDPB          ;SET ADDR INTO HSTDPB
6362 OF04 110600  LXI    D,DPEFLG2-DPEH+H ;ONLY DO THIS FOR REAL DRIVES
6363 OF07 19      DAD    D
6364 OF08 7E      MOV    A,M
6365 OF09 E602   ANI    DPEIMG
6366 OF0B C21E0F JNZ   CBH171A          ; BR IF IMAGINARY
6367 OF0E CDB906 CALL  SDP              ;TURN ON DRIVE AND RESTORE HEAD
6368 OF11 DB7F   IN     DPDC          ;CHECK IF HEAD MADE IT TO TRACK 0
6369 OF13 E602   ANI    DFT0          ; THIS CHECKS IF REAL DRIVE EXISTS
6370 OF15 CA1E0F JZ    CBH171A          ; BR IF DRIVE DOES NOT EXIST
6371 OF18 CDD506 CALL  SDT              ;STEP OUT 10 TRACKS
6372 OF1B CDF506 CALL  STZ              ;RESTORE HEAD
6373 CBH171A:
6374 OF1E 2A8E10 LHLD  HSTDPB          ;BUMP HSTDPB TO NEXT DRIVE
6375 OF21 111800 LXI    D,DPBL
6376 OF24 19      DAD    D
6377 OF25 C1      POP    B
6378 OF26 05      DCR    B          ;LOOP
6379 OF27 C2000F JNZ   CBH171
6380
6381 OF2A C33D05  JMP    XOK          ;RETURN VIA XOK

```

```

6382
6383             ENDIF
6384
6385             IF      H37T
6386             ;
6387             ; H37 COLD BOOT INIT ROUTINE.
6388             ;
6389
6390             CBH37: LDA    CBIB           ;CHECK IF VALID BASE PORT #
6391                   CPI    78H
6392                   RNZ           ;ONLY 78H ALLOWED
6393
6394                   MVI    B,H37ND
6395                   MVI    D,(DPE37#0-DPBASE)/DPEL
6396                   CALL   CBTFIL        ;FILL IN DRIVE MAP TABLE
6397
6398                   DI
6399                   MVI    A,M1#JMP      ;INSTALL H37 INTERRUPT SERVICE ROUTINE
6400                   LXI    H,H37ISR
6401                   STA    H37VEC
6402                   SHLD   H37VEC+1
6403                   EI
6404
6405                   MVI    A,CONMO       ;INIT CONTROL REG IMAGE
6406                   STA    H37CTL
6407
6408                   LDA    CBIA          ;CHECK IF BOOT DEVICE
6409                   ANA    A
6410                   CZ     RESH37        ;IF NOT, THEN RESET DEVICE
6411
6412             ; INSURE THE HEAD ON ALL DRIVES IS NOT BEFORE TRACK 0
6413
6414                   MVI    B,H37ND       ;# DRIVES
6415                   MVI    A,10          ;SET TO SEEK TO TRACK 10
6416                   STA    HSTTRK
6417                   LXI    H,DPE37#0+DPEH ;GET ADDR FOR HSTDPB
6418
6419             CBH37I:
6420                   PUSH   B
6421                   SHLD   HSTDPB        ;SET ADDR INTO HSTDPB
6422                   LXI    D,DPEFLG2-DPEH ;ONLY DO THIS FOR REAL DRIVES
6423                   DAD    D
6424                   MOV    A,M
6425                   ANI    DPEIMG
6426                   JNZ    CBH371A      ; BR IF IMAGINARY
6427                   CALL   SDF37        ;TURN ON DRIVE AND RESTORE HEAD
6428                   MVI    A,FD#CD
6429                   OUT    FD#INT
6430                   IN     FD#STA        ;CHECK IF HEAD MADE IT TO TRACK 0
6431                   ANI    FD#STK0      ; THIS CHECKS IF REAL DRIVE EXISTS
6432                   JZ     CBH371A      ; BR IF DRIVE DOES NOT EXIST
6433                   CALL   SDT37        ;STEP OUT 10 TRACKS
6434                   CALL   RST37        ;RESTORE HEAD
6435
6436             CBH371A:
6437                   LHLD   HSTDPB        ;BUMP HSTDPB TO NEXT DRIVE
6438                   LXI    D,DPEL

```

```
.....
6438          DAD      D
6439          POP      B
6440          DCR      B          ;LOOP
6441          JNZ      CBH371
6442
6443          JMP      H37DONE          ;RETURN VIA "H37DONE"
6444
6445          ENDIF
6446
6447          IF      H47T
6448          ;
6449          ; H47 COLD BOOT INIT ROUTINE.
6450          ;
6451
6452          CBH47: MVI      B,H47ND
6453          MVI      D,(DPE47#0-DPBASE)/DPEL
6454          CALL     CBTFIL          ;FILL IN DRIVE MAP TABLE
6455
6456          LDA      CBIB          ;SET PORT #'S
6457          IF      H47CTL
6458          %:      H47CTL NE 0
6459          ENDIF
6460          STA      H47INS1          ;STATUS PORT #
6461          STA      H47OUTC1        ;CONTROL PORT #
6462          INR      A
6463          IF      H47CTL*1-H47DAT
6464          %:      H47DAT NE H47CTL+1
6465          ENDIF
6466          STA      H47IND1          ;INPUT DATA PORT #
6467          STA      H47OUTD1        ;OUTPUT DATA PORT #
6468
6469          LDA      CBIB          ;CHECK BASE PORT ADDR
6470          CPI      7CH
6471          JNZ      CBH472          ;BR IF NOT PORT 7CH
6472          MVI      B,H47ND
6473          LXI      D,DPEL
6474          LXI      H,DPE47#0+DPEFLAG
6475          CBH471: MOV      A,M
6476          ORI      DPEP7C          ;SET PORT 7CH FLAG
6477          MOV      M,A
6478          DAD      D
6479          DCR      B
6480          JNZ      CBH471
6481
6482          CBH472: LDA      CBIA          ;CHECK IF BOOT DEVICE
6483          ANA      A
6484          CZ      RESH47          ;IF NOT, THEN RESET DEVICE
6485
6486          RET
6487          ENDIF
6488
6489          IF      H67T
6490          ;
6491          ; H67 COLD BOOT INIT ROUTINE.
6492          ;
6493
```

```

6494          CBH67:
6495
6496          IF      H67PART2
6497          LDA      BBDF          ;0. BOOTED FROM FLOPPY
6498          ANI      DPETYPF
6499          CPI      DPEH67F
6500          JNZ      CBH670        ; BR IF NOT
6501          INR      C              ;BUMP LOGICAL UNIT #
6502          CBH670:
6503          ENDIF
6504
6505          MVI      B,H67ND
6506          MVI      D,(DPE67*0-DPBASE)/DPEL
6507          CALL     CBTFIL        ;FILL IN DRIVE MAP TABLE
6508
6509          LDA      CBIB          ;SET PORT #'S
6510          IF      HD#DAT
6511          %:      HD#DAT NE 0
6512          ENDIF
6513          STA      H67IND1       ;INPUT DATA PORT #
6514          STA      H67OUTD1      ;OUTPUT DATA PORT #
6515          INR      A
6516          IF      (HD#DAT+1-HD#STA) OR (HD#DAT+1-HD#CON)
6517          %:      (HD#STA NE (HD#DAT+1)) OR (HD#CON NE (HD#DAT+1))
6518          ENDIF
6519          STA      H67INS1       ;STATUS PORT #
6520          STA      H67OUTC1      ;CONTROL PORT #
6521
6522          LDA      CBIB          ;CHECK BASE PORT ADDR
6523          CPI      7CH
6524          JNZ      CBH672        ; BR IF NOT PORT 7CH
6525          MVI      B,H67ND
6526          LXI      D,DPEL
6527          LXI      H,DPE67*0+DPEFLAG
6528          CBH671: MOV      A,M
6529          ORI      DPEP7C        ;SET PORT 7CH FLAG
6530          MOV      M,A
6531          DAD      D
6532          DCR      B
6533          JNZ      CBH671
6534
6535          CBH672:
6536          LDA      CBIA          ;CHECK IF BOOT DEVICE
6537          ANA      A
6538          JZ       CBH673        ; BR IF NOT BOOT DEVICE
6539          LDA      BBDF          ;CHECK IF BOOT DEVICE IS THE HARD DISK
6540          ANI      DPETYPF
6541          CPI      DPEH67H
6542          JZ       CBH675        ; BR IF IT IS
6543
6544          ;      IF NOT BOOT DEVICE, THEN INSURE HEAD IS NOT BEFORE TRACK 0 ON WINCHESTER.
6545
6546          CBH673:
6547          CALL     RESH67        ;RESET H67 CONTROLLER
6548          LDA      DPE67*0+DPEUNIT ;SET UNIT SELECT
6549          STA      CMDBUF+HD0LULA

```



```
.....
6550          CALL    SETUP3          ;ISSUE SEEK COMMAND TO INSURE
6551          MVI     A,I             ; THE HEAD IS NOT STUCK BEFORE TRACK 0
6552          STA     RS67B
6553          CALL    CMPSTAT          ;CHECK ERROR STATUS OF SEEK
6554          JNZ     CBH673B         ; BR IF ERROR
6555          CBH673A:
6556          CALL    H67INS           ;WAIT FOR SEEK TO FINISH (CONTROLLER NOT BUSY)
6557          ANI     HDDBSY
6558          JNZ     CBH673A
6559          CBH673B:
6560          JMP     RCL67            ;RESTORE HEAD AND RETURN
6561
6562          ;
6563
6564          CBH675:
6565          IF     PARTITN
6566          LDA     DPE67#0+DPEFLAG ;MARK PARTITION IS ASSIGNED
6567          ORI     DPEASGN
6568          STA     DPE67#0+DPEFLAG
6569          LHLD   BBP                ;GET SECTOR # FOR BEGINNING
6570          SHLD  DPE67#0+DPETRK      ; OF PARTITION
6571          LHLD   BUPB               ;GET LAST SECTOR # + 1
6572          SHLD  DPE67#0+DPEUPB     ; OR PARTITION
6573          ENDIF
6574          RET
6575          ENDIF
6576
6577          PAGE
```

```

6578
6579 ; CBTFIL - FILL THE LOGICAL TO PHYSICAL MAPPING TABLE
6580 ; FOR REAL DRIVES. THEN DO THE SAME FOR THE IMAGINARY
6581 ; DRIVES PLUS SET UP THE IMAGINARY'S LINK TO HIS
6582 ; CORRESPONDING REAL DRIVE.
6583 ;
6584 ; UPON ENTRY -- (B) = # DRIVES
6585 ; (C) = STARTING UNIT #
6586 ; (D) = STARTING DRIVE MAP #
6587 ; (CBIC) = NEXT LOGICAL DRIVE # TO BE ASSIGNED
6588 ; UPON EXIT -- (CBIC) UPDATED
6589 ; USES -- ALL
6590 ;
6591
6592 CBTFIL:
6593 OF2D 210000 LXI H,0 ;INIT CBTIA
6594 OF30 22D70F SHLD CBTIA
6595
6596 CBTFIL1:
6597 OF33 C5 PUSH B
6598 OF34 D5 PUSH D
6599
6600 OF35 3ADA0E LDA CBIA ;IF BOOT DEVICE THEN INSURE
6601 OF38 A7 ANA A ;BOOT UNIT IS MARKED REAL
6602 OF39 C4C10F CNZ CBTF7
6603
6604 OF3C AF XRA A ;INDICATE REAL CYCLE
6605 OF3D CD520F CALL CBTF0 ;HANDLE REAL DRIVES
6606
6607 OF40 D1 POP D
6608 OF41 C1 POP B
6609
6610 OF42 2AD70F LHLD CBTIA ;IF NO REAL DRIVES THEN MARK
6611 OF45 7C MOV A,H ;1ST AVAILABLE DRIVE AS REAL
6612 OF46 B5 ORA L
6613 OF47 C2500F JNZ CBTFIL2 ;BR IF REAL DRIVE FOUND
6614
6615 OF4A CDC10F CALL CBTF7 ;MARK 1ST AVAILABLE DRIVE REAL
6616
6617 OF4D C3330F JMP CBTFIL1 ;GO THRU REAL DRIVE CYCLE AGAIN
6618
6619 CBTFIL2:
6620 OF50 3E01 MVI A,1 ;INDICATE IMAGINARY CYCLE
6621
6622 ; THIS SECTION OF CODE IS RAN THROUGH TWICE.
6623 ; FIRST TIME IS FOR HANDLING THE REAL DRIVES.
6624 ; SECOND TIME IS FOR HANDLING THE IMAGINARY DRIVES.
6625
6626 OF52 32D60F CBTF0: STA CBTFA ;SAVE TYPE OF CYCLE INDICATOR
6627
6628 OF55 58 MOV E,B ;COPY OF # DRIVES
6629
6630 OF56 79 CBTF1: MOV A,C ;GET THIS DRIVE'S NUMBER
6631 OF57 B8 CMP B ;MOD # DRIVES
6632 OF58 DA5C0F JC CBTF2
6633 OF5B 90 SUB B

```

```

6634 0F5C 82      CBTF2: ADD    D          ; COMPUTE DISK ENTRY TABLE TO USE
6635
6636 0F5D C5      PUSH   B
6637 0F5E 47      MOV    B,A          ; COMBINE LOGICAL AND MAPPED DRIVE #'S
6638 0F5F 3ADC0E   LDA    CBIC         ; BIT 7-4 = LOGICAL
6639 0F62 87      ADD    A          ; BIT 3-0 = MAPPED
6640 0F63 87      ADD    A
6641 0F64 87      ADD    A
6642 0F65 87      ADD    A
6643 0F66 80      ADD    B
6644 0F67 47      MOV    B,A          ; (B) = LOGICAL/MAPPED DRIVE #'S
6645 0F68 D5      PUSH   D
6646 0F69 CDBE08   CALL  GETDPEX      ; GET ADDR OF DPE'S HEATH EXTENSIONS
6647 0F6C EB      XCHG             ; (DE) = HEATH EXTENSIONS
6648 0F6D 210600   LXI   H,DPEFLG2-DPEH1H
6649 0F70 19      DAD   D
6650 0F71 7E      MOV    A,M
6651 0F72 E602    ANI   DPEIMG       ; CHECK IF IMAGINARY DRIVE
6652 0F74 3AD60F   LDA    CBTF4       ; GET CYCLE INDICATOR ALSO
6653 0F77 C2950F   JNZ   CBTF3       ; BR IF IMAGINARY DRIVE
6654
6655          ; HANDLE REAL DRIVE IF THIS IS REAL DRIVE CYCLE
6656 0F7A A7      ANA    A
6657 0F7B C2AA0F   JNZ   CBTF4       ; BR IF THIS IS NOT REAL DRIVE CYCLE
6658
6659 0F7E E5      PUSH   H          ; IF THIS IS FIRST REAL DRIVE ENCOUNTERED
6660 0F7F 2AD70F   LHL   CBT1A       ; THEN REMEMBER ITS HEATH EXTENSION
6661 0F82 7C      MOV    A,H        ; ADDRESS
6662 0F83 B5      ORA   L
6663 0F84 E1      POP   H
6664 0F85 C28D0F   JNZ   CBTF2A
6665 0F88 EB      XCHG
6666 0F89 22D70F   SHLD  CBT1A
6667 0F8C EB      XCHG
6668
6669 0F8D 23      CBTF2A: INX    H          ; PLACE LOGICAL/MAPPED IN DPELUN SLOT
6670          IF    DPEFLG2+1-DPELUN
6671          ;:    (DPEFLG2+1) NE DPELUN
6672          ENDF
6673 0F8E 70      MOV    M,B
6674
6675 0F8F CDB20F   CALL  CBTF6       ; MAP DRIVE
6676
6677 0F92 C3AA0F   JMP   CBTF4
6678
6679          ; HANDLE IMAGINARY DRIVE IF THIS IS THE IMAGINARY DRIVE CYCLE
6680 0F95 A7      CBTF3: ANA    A
6681 0F96 CAAA0F   JZ    CBTF4       ; BR IF THIS IS NOT IMAGINARY DRIVE CYCLE
6682
6683 0F99 E5      PUSH   H          ; (DE) = ADDR OF HEATH EXTENSIONS
6684          ; (HL) = ADDR OF 2ND FLAG BYTE
6685
6686 0F9A CDB20F   CALL  CBTF6       ; MAP DRIVE
6687
6688 0F9D 2AD70F   LHL   CBT1A       ; MOVE THE REAL DRIVE'S TABLE
6689 0FA0 0E08    MVI   C,DPEHL    ; INTO THIS IMAGINARY DRIVE'S TABLE

```

```

6690 OFA2 CDCC08      CALL    MOVEIT
6691
6692 OFA5 E1          POP     H              ;(HL) = ADDR OF 2ND FLAG BYTE
6693 OFA6 7E          MOV     A,M
6694 OFA7 F602        ORI     DPEIMG        ;REMARK AS IMAGINARY DRIVE
6695 OFA9 77          MOV     M,A
6696
6697 OFAA D1          CBTF4: POP     D
6698 OFAB C1          POP     B
6699 OFAC 0C          INR     C              ;ROUND 'ROBIN' TO 'NEXT' DRIVE
6700 OFAD 1D          DCR     E              ;COUNT THIS ONE AS DONE
6701 OFAE C2560F      JNZ     CBTF1
6702
6703 OFB1 C9          RET
6704
6705                ; PLACE MAPPED DRIVE # INTO MAP DRIVE TABLE.
6706                ; (B) = MAPPED DRIVE #
6707
6708 OFB2 3ADCOE      CBTF6: LDA     CBIC              ;GET LOGICAL DRIVE #
6709 OFB5 214000      LXI     H,BDMAP        ;GET ADDR OF MAP DRIVE
6710 OFB8 CDA808      CALL   DADA              ; TABLE SLOT
6711 OFBB 70          MOV     M,B              ;PLACE MAPPED DRIVE # THERE
6712 OFBC 21DC0E      LXI     H,CBIC          ;BUMP VALUE NEXT LOGICAL DRIVE #
6713 OFBF 34          INR     M
6714 OFC0 C9          RET
6715
6716                ; INSURE 1ST DRIVE OF GROUP IS REAL DRIVE (NOT IMAGINARY).
6717                ; THE 1ST DRIVE HAS TO BE MARKED REAL SO IMAGINARY DRIVES,
6718                ; IF ANY, HAVE A REAL UNIT TO USE.
6719
6720                CBTF7:
6721 OFC1 C5          PUSH   B
6722 OFC2 D5          PUSH   D
6723
6724 OFC3 79          MOV     A,C              ;GET ADDR OF HEATH EXTENSIONS
6725 OFC4 82          ADD     D
6726 OFC5 CDBE08      CALL   GETDPEX
6727 OFC8 22D70F      SHLD  CBTIA            ;SAVE ADDR OF ITS DPE'S HEATH
6728                ; EXTENSIONS FOR IMAGINARY DRIVES
6729 OFCB 110600      LXI     D,DPEFLG2-DPEH3H
6730 OFCE 19          DAD     D
6731 OFCF 7E          MOV     A,M
6732 OFD0 E6FD        ANI     OFFH-DPEIMG    ;MARK REAL (NOT IMAGINARY)
6733 OFD2 77          MOV     M,A
6734
6735 OFD3 D1          POP     D
6736 OFD4 C1          POP     B
6737
6738 OFD5 C9          RET
6739
6740
6741 OFD6            CBTFA DS     1              ;CYCLE TYPE INDICATOR SLOT
6742 OFD7            CBTIA DS     2              ;ADDR OF REAL DRIVE'S DPE HEATH EXT.
6743
6744                PAGE

```

6745

6746 ; TYDN - TYPE A TWO DIGIT DECIMAL NUMBER ON CONSOLE

6747 ; ENTRY A VALUE

6748 ;

6749

6750 OFD9 OE00 TYDN: MVI C:0 ; INITIALIZE QUOTIENT

6751 OFDB D60A TYDN1: SUI 10 ; REPEATEDLY SUBTRACT 10

6752 OFDD DAE40F JC TYDN2 ; IF UNDERFLOW

6753 OFE0 0C INR C ; ELSE INCREMENT THE QUOTIENT

6754 OFE1 C3DB0F JMP TYDN1 ; AND SUBTRACT AGAIN

6755

6756 OFE4 C80A TYDN2: ADI 10 ; CORRECT THE UNDERFLOW

6757 OFE6 F5 PUSH PSW ; SAVE THE REMAINDER

6758 OFE7 79 MOV A:C ; GET THE QUOTIENT

6759 OFE8 C630 ADI 030H ; ASCII ADJUST IT

6760 OFEA 4F MOV C:A

6761 OFEB CD1409 CALL CONOUT ; SEND IT TO CONSOLE

6762 OFEE F1 POP PSW ; RECALL REMAINDER

6763 OFEF C630 ADI 030H ; ASCII ADJUST

6764 OFF1 4F MOV C:A

6765 OFF2 C31409 JMP CONOUT ; PRINT IT, WITH IMPLICIT RETURN

6766

6767

PAGE

```

6768
6769 ; IN8250 - INITIALIZE AN 8250
6770 ; HL CONTAINS BAUD RATE DIVISOR (WORD)
6771 ; A HAS BASE PORT NUMBER
6772 ;
6773
6774 IN8250: MOV B,A ;SAVE BASE PORT NUMBER IN B
6775 XCHG ;MOVE BAUD RATE DIVISOR TO DE
6776 LXI H,OUTH84+1 ;POINT TO PORT IN OUT INSTRUCTION
6777 MVI A,3 ;BAUD RATE ACCESS BIT ON BASE+3 PORT
6778 ADD B ;GET ACTUAL PORT
6779 MOV C,A ;SAVE IN C FOR LATER
6780 MOV M,A ;AND MODIFY OUTPUT INSTRUCTION
6781 MVI A,83H ;SET DIVISOR LATCH ACCESS BIT
6782 CALL OUTH84 ;TO A "1"
6783 INR M ;POINT TO MODEM CONTROL REGISTER
6784 MVI A,0FH ;AND SET DSR & CTS HIGH FOR DIABLO
6785 CALL OUTH84 ; AND OTHER TERMINALS WHICH REQUIRE THEM
6786 MOV M,B ;SET PORT TO LEAST SIG BYTE
6787 MOV A,E
6788 CALL OUTH84
6789 MOV A,D ;NOW DO MOST SIG BYTE
6790 ANI 0FH ;AND OFF CONTROL FLAGS
6791 INR M ;ON NEXT PORT
6792 CALL OUTH84
6793 MOV M,C ;RESET PORT TO DIVISOR LATCH ACCESS
6794 CPI B10 SHR 8 ;IF SET FOR GREATER THAN 110
6795 MVI A,3 ; THEN SET NO PARITY, 8 BIT WORDS, 1 STOP BIT
6796 JC IN821
6797 ORI 4 ; ELSE SET TWO STOP BITS FOR 110 AND BELOW
6798 IN821: CALL OUTH84
6799 DCR M ;NOW SET PORT FOR INTERRUPT CONTROL
6800 DCR M
6801 XRA A ;DISABLE ALL DEVICE INTERRUPTS
6802 CALL OUTH84 ;DISABLE INTS
6803
6804 ; DELAY FOR APPROXIMATELY TWO CHARACTER TIMES
6805
6806 XCHG ;PUT BAUD RATE DIVISOR IN HL
6807 DAD H ;MULTIPLY BY 16 TO GET DELAY
6808 DAD H
6809 DAD H
6810 DAD H
6811 LOOP1: DCX H
6812 MOV A,L
6813 ORA H
6814 JNZ LOOP1
6815 RET
6816
6817 ; SELF MODIFYING OUT INSTRUCTION USED BY IN8250
6818
6819 OUTH84: OUT 0 ;PORT IS MODIFIED
6820 RET
6821
6822 PAGE

```

```
6823
6824
6825      ; IN2661 - INITIALIZE A 2661-3
6826      ; HL CONTAINS BAUD RATE DIVISOR (WORD)
6827      ; A HAS BASE PORT NUMBER
6828      ;
6829
6830 IN2661: MOV     B,A           ;SAVE BASE PORT #
6831        XCHG                    ;SAVE BAUD RATE
6832        LXI     H,OUTH84+1     ;GET ADDR OF OUT INSTRUCTION TO MODIFY
6833        ADI     EPCMD           ;RET MODE REG POINTER
6834        CALL    PIN            ;BY INPUTTING FROM COMMAND REG
6835        MVI     A,EPCMD        ;SHUT DOWN 2661
6836        ADD     B
6837        MOV     M,A
6838        XRA     A
6839        CALL    OUTH84
6840        MVI     A,EPMODE       ;SET MODE REG 1
6841        ADD     B
6842        MOV     M,A
6843        MOV     A,E           ; CHECK # STOP BITS
6844        CPI     EPB300
6845        MVI     A,EP5B1
6846        JNC     IN2661B
6847        MVI     A,EP5B2
6848 IN2661B:
6849        ORI     EPCL8+EPA16X
6850        CALL    OUTH84
6851        MVI     A,70H         ;SET MODE REG 2
6852        ORA     E
6853        CALL    OUTH84
6854        MVI     A,EPCMD       ;SET COMMAND REG
6855        ADD     B
6856        MOV     M,A
6857        MVI     A,EPNORM+EPRTS+EPRESE+EPRXEN+EPDTR+EPTXEN
6858        CALL    OUTH84
6859        MVI     A,EPDATA      ;FLUSH INPUT BUFFER REGS
6860        ADD     B
6861        CALL    PIN
6862        MVI     A,EPDATA
6863        ADD     B
6864        CALL    PIN
6865        RET
6866
6867
6868
6869
6870      ; IN8255 - INITIALIZE AN 8255
6871      ; A HAS BASE PORT NUMBER
6872      ;
6873
6874 IN8255: MOV     B,A           ;SAVE BASE PORT #
6875        LXI     H,OUTH84+1     ;GET ADDR OF OUT INSTRUCTION TO MODIFY
6876        MVI     A,PPCTL        ;SET CONTROL WORD
6877        ADD     B
6878        MOV     M,A
```



```
.....
6890
6891      ;+*****
6892      ;+
6893      ;+ IF COLD BOOT CODE IS SMALLER THAN HOST BUFFER,
6894      ;+ THEN FILL OUT 'HSTBUF' WITH DS STATEMENT.
6895      ;+       IF      (CLEN-HSTSIZ) SHR 15
6896      ;+       DS      HSTSIZ-CLEN
6897      ;+ OTHERWISE REORG SO RUN-TIME VARIABLES CAN ALSO OVERLAY
6898      ;+ COLD BOOT CODE.
6899      ;+       ELSE
6900 OE32      ORG      HSTBUF+HSTSIZ
6901      ;+       ENDF
6902      ;+
6903      ;+*****
6904
6905 OE32      DIRBUF: DS      128
6906
6907      ;+       IF      H17T
6908 OE82      ALV0:  DS      12
6909 OE8E      CSV0:  DS      16
6910 OECE      ALV1:  DS      12
6911 OE8A      CSV1:  DS      16
6912 OE8A      ALV2:  DS      12
6913 OE86      CSV2:  DS      16
6914      ;+       ENDF
6915
6916      ;+       IF      H37T
6917      ;+       DPB37#0 DS      DPBL
6918      ;+       ALV37#0 DS      50
6919      ;+       CSV37#0 DS      64
6920      ;+       DPB37#1 DS      DPBL
6921      ;+       ALV37#1 DS      50
6922      ;+       CSV37#1 DS      64
6923      ;+       DPB37#2 DS      DPBL
6924      ;+       ALV37#2 DS      50
6925      ;+       CSV37#2 DS      64
6926      ;+       ENDF
6927
6928      ;+       IF      H47T
6929      ;+       ALV47#0 DS      77
6930      ;+       CSV47#0 DS      64
6931      ;+       ALV47#1 DS      77
6932      ;+       CSV47#1 DS      64
6933      ;+       ENDF
6934
6935      ;+       IF      H67T
6936      ;+       DPB67#0 DS      DPBL
6937      ;+       ALV67#0 DS      256
6938      ;+       ALV67#1 DS      77
6939      ;+       CSV67#1 DS      64
6940      ;+       IF      H67PART2
6941      ;+       DPB67#2 DS      DPBL
6942      ;+       ALV67#2 DS      256
6943      ;+       ENDF
6944      ;+       ENDF
6945
```



```

6947
6948 ;*****
6949 ;
6950 ; THE FOLLOWING AREAS CANNOT OVERLAY THE COLD BOOT CODE, SINCE
6951 ; THEY CAN/ARE USED DURING COLD BOOT.
6952 ;
6953 ; IF HOST BUFFER + RUN-TIME VARIABLES OCCUPY LESS SPACE THAN THE
6954 ; COLD BOOT CODE, IT IS NECESSARY TO REORG PAST THE COLD BOOT CODE.
6955 ;
6956 ;*****
6957
6958 IF ((HSTBUF)-CLEN) SHR 15
6959 108C ORG HSTBUF+CLEN
6960 ENDIF
6961
6962
6963 108C DPBX: DS 2
6964 108E HSTDPB: DS 2
6965
6966 1090 DMAB: DS 2 ;DMA BUFFER - USED TO STORE STARTING ADDRESS
6967 ; OF TRACK DURING WARM BOOT
6968 1092 SPT: DS 1 ;NUMBER OF SECTORS PER TRACK (DURING WBOOT)
6969 1093 XLTW: DS 2 ;SECTOR XLATE TABLE (DURING WBOOT)
6970 1095 SPTI: DS 1 ;DITTO, BEYOND TRACK 0
6971 1096 XLTW1: DS 2 ;DITTO, BEYOND TRACK 0
6972
6973 1098 TRACK: DS 1 ; TRACK (# < 256)
6974 1099 SECTOR: DS 1 ; SECTOR
6975 109A SIDE: DS 1
6976 109B RWOP: DS 1 ;I/O TYPE OPERATION
6977 ;0=READ 1=WRITE
6978 109C LSP: DS 1 ;LOGICAL SECTORS PER PHYSICAL
6979 109D ERRCNT: DS 1 ;RETRY COUNTER
6980 109E ERRYP: DS 1 ;TYPE OF ERROR
6981 109F TRKPT: DS 2 ;CONTAINS POINTER TO TRACK REGISTER
6982 ;FOR CURRENT DRIVE
6983 ;
6984 10A1 SEKDSK: DS 1 ;SEEK DISK NUMBER
6985 10A2 SEKTRK: DS 2 ;SEEK TRACK NUMBER
6986 10A4 SEKSEC: DS 1 ;SEEK SECTOR NUMBER
6987 ;
6988 10A5 HSTDSK: DS 1 ;HOST DISK NUMBER
6989 10A6 HSTTRK: DS 2 ;HOST TRACK NUMBER
6990 10A8 HSTSEC: DS 1 ;HOST SECTOR NUMBER
6991 ;
6992 10A9 SEKHST: DS 1 ;SEEK SHR SECSHF
6993 ;
6994 10AA UNADSK: DS 1 ;LAST UNALLOC DISK
6995 10AB UNATRK: DS 2 ;LAST UNALLOC TRACK
6996 10AD UNASI: DS 1 ;LAST UNALLOC SECTOR INDEX INTO XLT TABLE
6997 ;
6998 10AE ERFLAG: DS 1 ;ERROR REPORTING
6999 10AF RSFLAG: DS 1 ;READ SECTOR FLAG
7000 10B0 READOP: DS 1 ;1 IF READ OPERATION
7001 10B1 WRTYPE: DS 1 ;WRITE OPERATION TYPE
7002 10B2 DMAADR: DS 2 ;LAST DMA ADDRESS

```

```
.....
7003
7004 10B4      HSAV: DS      2      ;SAVED HL DURING INTERRUPT SERVICE
7005 10B6      RETSAV: DS     2      ;SAVED RETURN ADDRESS DURING INT SERVICE
7006 10B8      OLDSP: DS     2      ;SAVE SP DURING INTERRUPT SERVICE
7007
7008          IF      INTINP
7009
7010 10BA      CRTBUF: DS     40      ;CRT TYPE-AHEAD BUFFER
7011 10E2 =     CRTBND EQU     $
7012 0028 =     CRTLEN EQU     CRTBND-CRTBUF
7013
7014 10E2      DS     16      ;LOCAL STACK FOR CRT INTERRUPT SERVICE
7015 10F2 =     LCLSTK EQU     $
7016
7017          ENDIF
7018
7019 10F2      DS     32      ;STACK AREA DURING COLD & WARM BOOT
7020 1112      STACK DS     0
7021
7022 1112 =     BIOSEND EQU     $
7023
7024 1112      END
```


CBTF4	OFAA	6657	6677	6681	6697#				
CBTF6	OFB2	6675	6686	6708#					
CBTF7	OFC1	6602	6615	6720#					
CBTFA	OFD6	6626	6652	6741#					
CBTFIL	OF2D	6343	6396	6454	6507	6592#			
CBTFIL1	OF33	6596#	6617						
CBTFIL2	OF50	6613	6619#						
CBTIA	OFD7	6594	6610	6660	6666	6688	6727	6742#	
CCP	EA00	94#	95	1184	1194	1217	1278		
CCPCLR	EA03	95#	1279						
CDA	016F	1214	1238	1295#					
CHKLAB	0894	2768	3951	4824#					
CHKLAB1	089A	4829#	4833						
CHKUNA	0291	1528	1552	1570#					
CHKUNAS	02D0	1599	1603#						
CHKUNAS6	02DA	1602	1607#						
CLEN	035A	6887#	6895	6896	6958	6959			
CLK0	0844	4670	4673#						
CLK1	0850	4684	4689	4695	4701	4716	4722	4728#	
CLK2	0850	4734	4739#						
CLK3	0866	4748	4755#						
CLK4	087A	4745	4758	4761	4769#				
CLKE	0002	491#							
CLKR2	088A	4800	4804	4806#					
CLKRET	087A	4679	4774	4787	4790	4798#			
CLKVEC	0008	493#	6029	6030					
CLOCK	082E	4658#	6028						
CONDRQ	0002	285#	2981	3102					
CONDS0	0010	288#	1041	3336	4793				
CONDS1	0020	289#	1053	3336	4793				
CONDS2	0040	290#	1065	3336	4793				
CONDS3	0080	291#	3336	4793					
CONIN	0906	912	1284	1950	4996#				
CONIRQ	0001	284#	3031	3312					
CONMFM	0004	286#	2751	3309					
CONMO	0008	287#	3312	3317	4780	6405			
CONOUT	0914	913	1956	5005#	5854	5876	6211	6761	6765
CONS	08E9	4971	4977#						
CONST	08E1	911	4971#						
CPHLDE	08A2	3962	3971	4499	4510	4844#			
CR	000D	557#	559	1952	1988	5882	5887	6269	6279
CRLF	OCFE	1863	1882	1959	5887#				
CRT	0001	572#	586						
CRTB	0D07	5102	5168	5210	5239	5252	5292	5897#	
CRTBAUD	0039	972#	6092						
CRTBND	10E2	5174	5248	7011#	7012				
CRTBUF	10BA	5176	5250	5288	5898	5899	7010#	7012	
CRTCTS	0D03	5509	5891#						
CRTGET	0D08	5170	5177	5289	5898#				
CRTIN	0996	4999	5001	5059	5139#				
CRTIN1	0996	5163#	5164						
CRTIN2	09AF	5175	5177#						
CRTIS1	09D7	5207#	5223						
CRTIS1A	09E9	5220#	5223						
CRTIS1B	09F4	5219	5226#	5231					
CRTIS1C	0A02	5225	5233#						

CRTIS1D	0A08	5234	5237#						
CRTIS2	0A11	5212	5243#						
CRTIS3	0A20	5249	5251#						
CRTIS4	0A27	5255#	5264						
CRTIS5	0A35	5241	5263#						
CRTIS6	0A39	5196	5266#						
CRTISR	09B5	5184#	6033						
CRTLEN	0028	5211	5240	7012#					
CRT01	0A59	5351	5358#						
CRT05	0B3C	5020	5345	5508#					
CRT0S1	0B49	5497	5503	5515#					
CRT0S1A	0B4C	5506	5516#						
CRT0S2	0B56	5521	5526#						
CRT0S3	0B61	5513	5538#						
CRT0S4	0B6E	5544	5549#						
CRT0SB	0B5F	5517	5535#	5540					
CRT0UT	0A48	5008	5033	5048	5345#	5347			
CRTPUT	0D0A	5244	5251	5290	5899#				
CRTS2	0973	5108#							
CRTS2A	0988	5110	5122#						
CRTS2B	0992	5124	5127#						
CRTS3	0993	5117	5120	5129#					
CRTSTAT	096E	4980	4982	4992	5084#	5163			
CSV0	0E8E	998	6909#						
CSV1	0EDA	1012	6911#						
CSV2	0EF6	1024	6913#						
CTLC	0003	555#							
CTLPRT	000D	495#	4663	6038					
DADA	08A8	1343	1416	1604	3660	4050	4483	4855#	5066 6710
DAY	000F	25#	6277	6278					
DBD	0ACD	5035	5436#	5438					
DBD1	0AE7	5445	5450#						
DBDCTS	0D06	5638	5894#						
DBDOS	0BE4	5022	5436	5637#					
DBDOS1	0C06	5642	5658#						
DBDOS2	0C13	5663	5668#						
DBDOSB	0C1C	5647	5652	5659	5679#				
DCIE	0040	183#							
DCLPOS	0D01	5411	5423	5607	5889#				
DCOPY	000B	192#							
DCRES	0002	184#	3715						
DDMNT	000C	598#	1943						
DDR	0003	595#	1810						
DDRES	0009	597#							
DDSEL	0000	594#	1379						
DDWR	0006	596#	1828						
DECHK	0008	160#	2076						
DEFIOB	0034	941#	6024						
DEHCK	0004	159#	2505						
DEHSY	0002	158#	2485						
DELAY37	060F	307#	3035						
DELAYS	060F	154#	2044						
DEMDS	0020	162#	2062						
DERNF	0010	161#	2498						
DETRK	0001	157#	2161	2492					
DEUNR	0080	164#	2141	2298					

DEVCTL	000F	497#	2124	2231	2322	2441	2651	4750	4752	4763	4765
		6346									
DEWRP	0040	163#	2092	2141							
DFDI	0020	130#	2436								
DFHD	0001	133#	2274								
DFMO	0010	129#	2318	2324	4751	6345					
DFMT	000D	193#									
DFMTD	000E	194#									
DFMTD2	000F	195#									
DFSD	0008	136#	2623								
DFST	0040	131#	2444	2446							
DFTO	0002	134#	2418	6369							
DFWP	0004	135#	2091								
DIOB	00A9	586#	941								
DIRBUF	0E32	977	1011	1023	1038	1050	1062	1077	1086	1098	1109
		1120	6905#								
DLY	0731	2461#	2553								
DLY1	0736	2464#	2465								
DLYH	082C	4655#									
DLYH37	0024	311#									
DLYMO	082B	2045	2233	2313	4654#	4742					
DLYMO37	0023	310#	3036	3304	3395	4771					
DLYW	082D	2258	2350	2402	2406	2477	3341	3450	3460	3502	4656#
		4801									
DMAADR	10B2	1215	1470	1754	7002#						
DMAB	1090	1201	1295	6966#							
DMYIN	0C1E	5057	5465	5686#							
DMYOUT	0C20	5046	5484	5687#							
DPB17S	0D0C	977	1011	1023	5904#						
DPBAL0	0009	657#									
DPBAL1	000A	658#									
DPBASE	0052	990#	4884	6342	6395	6453	6506				
DPBBLM	0003	653#									
DPBBSH	0002	652#									
DPBCKS	000B	659#									
DPBDRM	0007	656#									
DPBDSM	0005	655#									
DPBEXM	0004	654#									
DPBL	000F	661#	689	2903	3988	6917	6920	6923	6936	6941	
DPBOFF	000D	660#									
DPBSPT	0000	651#	652	653	654	655	656	657	658	659	660
DPBX	108C	1350	1531	1542	1593	1616	1647	2718	2729	2745	2771
		2783	2888	3624	3685	3938	3956	3965	3976	3997	4069
		6963#									
DPDC	007F	124#	2090	2125	2230	2273	2319	2417	2443	2445	2447
		2531	2539	2563	2573	2622	2653	4753	4766	6368	
DPE0	0052	995#	6342	6357							
DPE1	006A	1009#									
DPE2	0082	1021#									
DPE2S	0001	628#	2789	2826	3269	3603	3609	3617	3687	3793	3794#
		4074	4110	4116							
DPE48R0	0010	620#	2890	3091	3428						
DPE96T	0008	622#	2785	3197							
DPE96TM	0001	642#									
DPEASGN	0004	623#	1358	6567							
DPEDD	0002	627#	1040	1052	1064	2731	2747	2773	2789	3307	3606

EPB150	0004	832#					
EPB180	0008	836#					
EPB192	000F	843#					
EPB200	0009	837#					
EPB240	000A	838#					
EPB300	0005	833#	980	6844			
EPB360	000B	839#					
EPB480	000C	840#					
EPB600	0006	834#					
EPB720	000D	841#					
EPB960	000E	842#					
EPBR5	000F	807#					
EPCL	000C	786#					
EPCL5	0000	787#					
EPCL6	0004	788#					
EPCL7	0008	789#					
EPCL8	000C	790#	6849				
EPCMD	0003	763#	6108	6113	6833	6835	6854
EPDATA	0000	759#	5790	5796	5797#	6859	6862
EPDCD	0040	775#					
EPDSC	0004	770#					
EPDSR	0080	776#					
EPDTR	0002	813#	6110	6115	6857		
EPFE	0020	773#					
EPI	0C70	5381	5788#	5789			
EPI1	0C76	5790#					
EPIE	0001	897#					
EPINT	0004	896#					
EPMBRF	0003	780#					
EPMODE	0002	762#	6840				
EPMR2U	00F0	808#					
EPNORM	0000	821#	6857				
EPNSC	0080	802#					
EPO	0C7B	5404	5795#				
EPQE	0010	772#					
EPQM	00C0	820#					
EPQM1	0040	822#					
EPQMLL	0080	823#					
EPQMRL	00C0	824#					
EPOS	0C68	5505	5781#				
EPPC	0010	792#					
EPPE	0008	771#					
EPPT	0020	793#					
EPRESE	0010	817#	6857				
EPRTS	0020	818#	6857				
EPRXEN	0004	814#	6857				
EPRXR	0002	768#	5776				
EPS	0C60	5393	5774#	5788			
EPS1X	0000	781#					
EPSB1	0040	796#	6845				
EPSB15	0080	797#					
EPSB2	00C0	798#	6847				
EPSBRK	0008	815#					
EPSD	0020	774#					
EPSDLE	0008	816#					
EPSTAT	0001	760#	5774	5781			

IPINX	0A41	5194	5200	5229	5279	5335#			
IUI1	0A40	5205	5276	5286	5328#				
LABBUF	0000	682#	683	685					
LABCS	001C	689#	691						
LABDPB	000D	688#	689	2902	3987				
LABEL	0004	685#	686	691	2776	4827			
LABHTH	0005	687#	688	2787	2825	3961	3970	3979	
LABLEN	0019	691#	2775	4826					
LABTYP	0004	686#	687						
LABVER	0000	680#	2925						
LCLSTK	10F2	5191	7015#						
LEVEL	0020	23#	6276						
LF	000A	558#	1988	5882	5887	6269	6269	6279	6323
LYST	0932	914	5009	5010	5028#				
LISTST	0922	924	5015#						
LOGDSK	0004	98#	1275	1392	6184	6261			
LOOP1	102E	6811#	6814						
LPS	073F	2057	2097	2477#					
LPS0	073C	2475#	2479						
LPS1	0748	2483#	2511						
LPS2	0772	2486	2493	2499	2507#				
LPSA	0014	140#	2481						
LPT	0002	579#	586						
LPTBAUD	003F	976#	6137	6151					
LPTCTS	0D04	5420	5563	5892#					
LPTOS	0B76	5021	5415	5563#					
LPTOS0	0BB8	5594	5598#						
LPTOS1	0BC9	5604	5610#						
LPTOS2	0BBF	5580	5602#						
LPTOS3	0B9E	5568	5582#						
LPTOS4	0BDE	5619	5623#						
LPTOS4A	0BE1	5621	5625#						
LPTOS5	0B96	5576	5578#						
LPTOSB	0BE2	5579	5584	5600	5628#				
LPTOU1	0AAC	5415#	5417						
LPTOU2	0AB3	5413	5419#						
LPTOUT	0AA5	5034	5411#						
LSP	109C	1670	1729	1740	6978#				
M1	03A3	1747#	1749						
M1H	0020	489#							
M2	03A8	1745	1751#						
MAI	0710	2182	2388	2436#					
MAO	0715	2189	2397	2422	2438#				
MA01	0716	2437	2439#						
MATCH	0392	1712	1740#						
MDCTS	0D05	5496	5893#						
MDIN	0AEE	5058	5462#						
MDOS	0B1C	5485	5495#						
MDOUT	0B0A	5047	5482#						
MDOUT1	0B12	5485#	5487						
MDSTAT	0AFC	4991	5472#						
MIJMP	00C3	483#	1256	6027	6399				
MNMSG	04D2	1947	1988#						
MNMSGA	04DD	1936	1989#						
MNMSGB	04E8	1941	1990#						
MNTH17	0624	2004	2215#						

PPBS4	0008	882#							
PPBS5	000A	883#							
PPBS6	000C	884#							
PPBS7	000E	885#							
PPBSSEL	000E	877#							
PPBSR	0001	887#							
PPCTL	0003	855#	5816	6876					
PPDATA	0000	852#	5811	5812#					
PPDATB	0001	853#							
PPDATC	0002	854#	5570						
PPDS	0001	901#	5819	5820#	5823	6881			
PPGAM0	0000	863#							
PPGAM1	0020	864#	6879						
PPGAM2	0040	865#							
PPGAMS	0060	862#							
PPGAPA	0010	867#							
PPGAPC	0008	868#	6879						
PPGBM0	0000	871#							
PPGBM1	0004	872#							
PPGBMS	0004	870#							
PPGBPB	0002	874#	6879						
PPGBPC	0001	875#							
PPMSF	0080	859#	6879						
PPD	0C7F	5430	5620	5810#					
PP01	0C8F	5822	5824#						
PP01A	0C90	5817	5825#						
PPRDY	0080	902#	5578						
PRTERR	041D	1858#	2202	3214	3749	4449			
PRTERR1	043B	1871	1873#						
PRTRDY	0035	942#	5598						
PTP	0001	574#							
PTR	0001	573#							
PUNCH	0942	915	5040#						
RD17	0549	2014	2053#						
RD171	054C	2055#	2079						
RD172	0562	2065#	2070						
RD17E	0575	2058	2063	2078#					
RD17M	050B	2001	2008#						
RDB	07BB	2065	2073	2488	2489	2495	2502	2592#	2594
RDH1	0520	2016	2018#						
RDMSG	0CE9	1869	5884#						
RDNUL	081C	4627	4633#						
RDPBAUD	0042	978#	6154						
RDRST	08F7	4981	4986#						
RDYH17	063A	2000	2255#						
RDYH17A	0640	2259#	2262						
RDYH17B	064F	2272#	2289						
RDYH17B1	065B	2282#	2284						
RDYH17C	065F	2276	2286#						
RDYH17D	0670	2292	2297#						
RDYH17E	0675	2295	2301#						
READ	022F	922	1222	1508#					
READA	0030	149#	2614						
READER	0953	916	5000	5053#					
READHST	03E3	1735	1802#						
READOP	10B0	1511	1524	1726	1756	7000#			

TTY11B	0045	980#	6134						
TTYBAUD	003C	974#	6148						
TTYCTS	0D02	5500	5890#						
TTYIN	0A68	4998	5056	5374#					
TTYIN1	0A79	5377	5380#						
TTYIN2	0A7F	5379	5382#						
TTYQS	0B25	5019	5399	5499#					
TTYOUT	0A93	5007	5032	5045	5399#	5401			
TTYSTAT	0A82	4979	4989	5388#					
TYDN	0FD9	6168	6750#						
TYDN1	0FDB	6751#	6754						
TYDN2	0FE4	6752	6756#						
U0	0002	126#	1000	2345	4764				
U1	0004	127#	1014	2345	4764				
U2	0008	128#	1026	2345	4764				
UC1	0003	581#							
UDLY	07B6	2567	2584#	2585					
UI	0C52	5149	5378	5466	5750#	5751			
UI1	0C58	5649	5752#						
UL1	0003	584#							
UNACNT	0D31	1509	1536	1570	1576	1638	1847	6005#	
UNADSK	10AA	1538	1578	6994#					
UNASI	10AD	1551	1566	1600	1603	1608	6996#		
UNATRK	10AB	1540	1584	1627	1629	6995#			
U0	0C31	5356	5405	5428	5439	5488	5531	5623	5674
U0S	0C29	5515	5583	5658	5705#				
UP1	0002	578#	586						
UP2	0003	583#							
UPDP	007C	119#	2596	2633	2679				
UPFC	007D	120#							
UPSC	007E	122#	2618						
UPSR	007E	123#	2619						
UPST	007D	121#	2592	2674					
UR1	0002	577#	586						
UR2	0003	582#							
US	0C21	5094	5391	5476	5646	5698#	5750		
VERS	0004	22#	940	6276	6276				
WBOOT	009A	910	1137#	1285					
WBOOTE	0003	910#	1257						
WBT02	00CE	1193	1197#						
WBT1	00D1	1199#	1250						
WBT2	00D8	1203#	1236						
WBT3	0108	1218	1220	1232#					
WBT4	012C	1229	1252#						
WBTE	0163	1146	1225	1282#					
WHD	07A3	2563#	2565						
WHDA	0014	143#	2281	2566					
WHNA	0014	144#	2576						
WNB	07FF	2112	2118	2120	2121	2122	2658	2673#	
WNB1	0800	2674#	2676						
WNH	07AE	2551	2573#	2575					
WR17	057E	2027	2088#						
WR171	0581	2090#	2129						
WR172	059A	2104#	2105						
WR173	05A5	2111#	2115						
WR17E	05C3	2093	2098	2128#					

WR17M	0524	2002	2021#		
WRALL	0000	1502#			
WRDIR	0001	1503#	1770		
WRH1	0539	2029	2031#		
WRITA	0014	146#	2103		
WRITB	000A	147#	2107		
WRITC	0010	148#	2108		
WRITE	0243	923	1523#		
WRITE0	027E	1549	1554#		
WRITE1	0284	1558#	1563		
WRITE2	028D	1559	1565#		
WRITEHST	03F3	1717	1779	1821#	1842
WRKVAR	0001	6295#	6296		
WRKVARX	0001	6294#	6295		
WRMSG	0CEF	1872	5885#		
WRNUL	081C	4628	4634#		
WRTYPE	10B1	1514	1526	1769	7001#
WRUAL	0002	1504#	1513	1527	
WSC	07C9	2061	2484	2614#	
WSC0	07CB	2615#	2616		
WSC1	07D8	2622#	2626		
WSC2	07E5	2624	2633#		
WSCA	0050	145#	2620		
WSP	07EA	2109	2646#	2647	
WSP1	07F4	2657#	2660		
XIT	053E	2042#	2080	2130	2302
XLT17	0D1B	995	1009	1021	5972#
XLTW	1093	1151	1178	1205	1244 6969#
XLTW1	1096	1150	1243	6971#	
XOK	053D	2041#	2075	2126	6381
YEAR	0052	26#	6278	6278	



